

**Panasonic®**

Servo Drives

## Quick Start Guide

Position control by  
block operation using  
Modbus commands  
(MINAS A6)



QS2002\_V1.0\_EN

2019.07

[www.panasonic-electric-works.com](http://www.panasonic-electric-works.com)

## Liability and copyright

---

This manual and everything described in it are copyrighted. You may not copy this manual, in whole or part, without written consent of Panasonic Electric Works Europe AG (PEWEU).

PEWEU pursues a policy of continuous improvement of the design and performance of its products. Therefore we reserve the right to change the manual/product without notice. In no event will PEWEU be liable for direct, special, incidental, or consequential damage resulting from any defect in the product or its documentation, even if advised of the possibility of such damages.

Please direct support matters and technical questions to your local Panasonic representative.

# Table of contents

<b>1 Introduction.....</b>	<b>4</b>
1.1 Before you start.....	4
1.2 About this document.....	4
1.3 Related documents.....	4
1.4 Available software.....	5
<b>2 Functional overview.....</b>	<b>6</b>
<b>3 Wiring.....</b>	<b>7</b>
3.1 Recommendations for wiring.....	7
3.2 Connectors of the servo driver.....	7
<b>4 Make parameter settings in PANATERM.....</b>	<b>10</b>
4.1 Basic parameters overview.....	10
4.2 Pr0.00 (Motor rotation direction).....	11
4.3 Pr0.01 (Control mode).....	11
4.4 Pr0.08 (Number of pulse signals per motor revolution).....	11
4.5 Pr4.05 (Function assignment for pin 29 of X4 connector).....	12
4.6 Pr5.29 (RS232C baud rate).....	12
4.7 Pr5.30 (RS485 baud rate).....	12
4.8 Pr5.31 (Axis number).....	12
4.9 Pr5.37 (Communication protocol).....	13
4.10 Pr5.38 (Modbus parity and stop bit setting).....	13
4.11 Pr5.39 (Modbus response waiting time).....	13
4.12 Pr6.28 (Block operation mode).....	13
<b>5 Function test.....</b>	<b>14</b>
<b>6 Help us improve.....</b>	<b>16</b>
<b>7 Record of changes.....</b>	<b>17</b>

# 1 Introduction

## 1.1 Before you start

Before operating this product, read the safety instructions in the related *Operating Instructions*.

This product is for industrial use only.

Electrical connections must be made by qualified electrical personnel.

## 1.2 About this document

This *Quick Start Guide* is intended to help you set up a MINAS servo drive system. It is based on information from the MINAS series manuals and the practical experience of our engineers.

Step-by-step instructions will guide you through connecting a PLC to a MINAS servo driver and setting the most important parameters in the PC configuration software PANATERM.

## 1.3 Related documents

Please refer to the original servo drive manuals for detailed information. Click on the following links to download the documents from our Panasonic Download Center.

- Information on wiring, position control, and parameters:

[\*Operating Instructions \(Overall\) AC Servo Motors & Driver MINAS A6 series\*](#)

[\*Technical Reference – Modbus communication and block operation specification SX-DSV03042\*](#)

- Information on using the PANATERM configuration software:

[\*Operation Manual: Set up support software PANATERM Ver. 6.0\*](#)

- Information on how to reduce electromagnetic interference (EMI):

[\*Recommendations for EMC-compliant wiring of servo drivers and motors\*](#)

- Other Quick Start Guides:

[\*QS2000, Position control by pulse and direction signals \(MINAS A5/A5E/A6SG/A6SF\)\*](#)

[\*QS2001, Position control by block operation using input signals \(MINAS A6SG/A6SF\)\*](#)

[\*QS2003, Position control in EtherCAT networks MINAS A5B/A6B\*](#)

[\*QS2004, Position control using RTEX \(MINAS A5N/A6N\)\*](#)

[\*QS3000, Velocity control \(MINAS A5/A6F\)\*](#)

[\*QS4000, Torque control \(MINAS A5/A6\)\*](#)

- [QS5000, PANATERM - Trial run](#)
- [QS5001, PANATERM - Auto-tuning](#)
- [QS5002, PANATERM - Fit gain tuning](#)

## 1.4 Available software


The following software is available free of charge in our Panasonic Download Center. Click on the link to start the download.

- [PC configuration software PANATERM](#)
- [PC programming software Control FPWIN Pro 7](#)
- [MC\\_Modbus\\_Library with demo program for block operation](#)

## 2 Functional overview

Position control is a control mode in which the motor moves the load to a specified target position.

The servo driver can be controlled by a pulse train in the frequency range between 1Hz and 8MHz from a host controller such as a PLC or a CNC controller or by block operation. With block operation, the user defines the positioning parameters in command blocks. The MINAS A6 servo driver has a block memory capacity of 256 command blocks. All command blocks are saved in a block operation table in the servo driver.



No.	Setting
0	Jump, Block No.:2, Transition condition:0
1	Homing, Type of homing:HOME, Return direction:Positive side, Transition condition:3
2	Absolute positioning, Velocity No.:V2, Acceleration No.:A2, Deceleration No.:D2, Transition condition:3, Absolute position:1000
3	Start-up decrement counter, Transition condition:3, Counter setting value[1ms]:2000
4	Relative positioning, Velocity No.:V4, Acceleration No.:A4, Deceleration No.:D4, Transition condition:3, Relative movement distance:10...
5	Start-up decrement counter, Transition condition:3, Counter setting value[1ms]:2000
6	Relative positioning, Velocity No.:V6, Acceleration No.:A6, Deceleration No.:D6, Transition condition:3, Relative movement distance:-1...
7	Output signal control, B-CTRL1:HOLD, B-CTRL2:HOLD, B-CTRL3:HOLD, B-CTRL4:HOLD, B-CTRL5:HOLD, B-CTRL6:HOLD, Transition...
8	Jump, Block No.:0, Transition condition:0
9	JOG, Velocity No.:V9, Acceleration No.:A9, Deceleration No.:D9, JOG direction:Positive side, Transition condition:0
10	Jump, Block No.:0, Transition condition:0
11	Not set


### Block operation table

You can set the command blocks using the PANATERM configuration software or by Modbus commands if you are using a PLC with a Modbus RTU communication interface. The command blocks are either started by digital signals (e.g. STB, B-SEL1 to B-SEL128) from a PLC, a trigger switch, or by Modbus commands.

This *Quick Start Guide* explains how to wire and configure the servo driver for block operation using Modbus commands.

### Example

An FP0H PLC and a MINAS A6SF servo driver are connected to control the driver by Modbus commands.



*Data transmission between PLC with Modbus RTU interface and servo driver via serial communication cable*

## 3 Wiring

### 3.1 Recommendations for wiring

It is the customer's responsibility to apply the countermeasures that they consider necessary to comply with current regulations on wiring, safety and reducing EMI.


Do not forget to meet the specifications indicated in the hardware manual for each of the devices being wired. If any specifications in the manual conflict with the information in this document, the manufacturer's manual takes preference.

For detailed information on reducing EMI, please refer to [Recommendations for EMC-compliant wiring of servo drivers and motors](#).

### 3.2 Connectors of the servo driver

#### XA connector (main power connector)


Connect the power supply cable to the XA connector. For a 1-phase power supply of 230V, connect a 2-wire cable to the servo driver as illustrated. The L2 pin is not used in 1-phase mode.



*Wiring of the XA connector for a power supply of 230V*

#### XB connector (motor connector)


Connect the motor cable to the XB connector. The wires are labeled with the letters U, V, and W. Do not change the sequence of the motor phases, e.g. by connecting V to W.



*Wiring of the XB connector for the motor power supply*

### X6 connector (encoder connector)


Connect the encoder cable to the X6 connector.



*Wiring of the X6 connector for the encoder connection*

### X2 connector (serial communication interface)


Connect the serial communication cable DV0PM20024CAB to the X2 connector and to COM port 0 (RS232C interface) of the FP0H PLC.



*Connector X2 for serial communication cable*

### X1 connector (USB connector for PC connection)

The servo driver is configured using the PC configuration software PANATERM. Use a commercially available USB A to mini-B cable to connect the PC to the servo driver.




*Connector X1 for PC connection*

## 4 Make parameter settings in PANATERM


Use the PC configuration software PANATERM to configure the MINAS servo driver.

Click on the following link to download PANATERM from our Panasonic Download Center:  
[PC configuration software PANATERM](#)

1. Connect your PC to the X1 connector and turn on the servo driver.
2. Start the PANATERM configuration software.  
 The software automatically detects the type of servo driver connected.
3. Select “OK” and confirm the connected series by selecting your type of servo driver.
4. Select the “Parameter” tab.



5. In the “Selection of parameter to be read” dialog, select “Read the default”. There is a message if the parameter values in the servo driver are not the default values. To overwrite the parameters in the servo driver, select the “Trans” icon.
6. Select the parameter list for your type of servo driver.



7. To change a parameter setting, select the desired parameter class and enter a value. For parameter descriptions, please refer to the Operating Instructions. You can find each parameter by its unique parameter number. The parameter number is written in the format PrX.YY (X: Class, YY: No.).
8. Depending on the parameter, select the “Trans” or the “EEP” icon to transfer a setting to the servo driver. For yellow parameters, select the “EEP” icon. The parameters will be saved in the EEPROM of the servo driver. To activate the settings, you need to restart the servo driver.

All other parameters are transferred simply by selecting the “Trans” icon.

### 4.1 Basic parameters overview

There are basic parameters which are associated to position control.

The following table shows the setting range and description of the basic parameters.

Parameter	Range	Description
Pr0.00	0 or 1	Motor rotation direction
Pr0.01	0 to 6	Control mode
Pr0.08	0 to 1048576 [pulse] (MINAS A5) 0 to 8388608 [pulse] (MINAS A6)	Number of pulse signals per motor revolution
Pr4.05	0 to 16777215	Function assignment for pin 29 of X4 connector
Pr5.29	0 to 7	RS232C baud rate
Pr5.30	0 to 7	RS485 baud rate
Pr5.31	0 to 127	Axis number
Pr5.37	0 to 2	Communication protocol
Pr5.38	0 to 5	Modbus parity and stop bit setting
Pr5.39	0 to 10000	Modbus response waiting time
Pr6.28	0 to 2	Block operation mode

## 4.2 Pr0.00 (Motor rotation direction)

PANATERM parameter: “Rotational direction setting”

Setting range: 0 or 1

The default value is 1: Rotation in CCW direction (counterclockwise direction).

## 4.3 Pr0.01 (Control mode)

PANATERM parameter: “Control mode setting”

Setting range: 0 to 6

The default value is 0: Position control

Select 0: Position control (block operation mode only supports position control)

## 4.4 Pr0.08 (Number of pulse signals per motor revolution)

PANATERM parameter: “Command pulse number per one motor revolution”

Setting range: 0 to 1048576 [pulse] (MINAS A5), 0 to 8388608 [pulse] (MINAS A6)

The default value is 10000 pulses per motor revolution.

#### 4.5 Pr4.05 (Function assignment for pin 29 of X4 connector)

---

PANATERM parameter: “SI6 input selection”

Setting range: 0 to 16777215

The default value is 197379: servo-on input

Select 0 to disable the default pin assignment.

#### 4.6 Pr5.29 (RS232C baud rate)

---

Set this parameter if the servo driver is connected via RS232C.

PANATERM parameter: “RS232 communication baud rate setting”

Setting range: 0 to 7 (2400 to 230400bit/s)

The default value is 2 (9600bit/s).

Make sure the baud rate setting in the PLC program and in the servo driver are identical. In this example, select 6: 115200bit/s.

#### 4.7 Pr5.30 (RS485 baud rate)

---

Set this parameter if the servo driver is connected via RS485.

PANATERM parameter: “RS485 communication baud rate setting”

Setting range: 0 to 7 (2400 to 230400bit/s)

The default value is 2 (9600bit/s).

Make sure the baud rate setting in the PLC program and in the servo driver are identical. In this example, select 6: 115200bit/s.

#### 4.8 Pr5.31 (Axis number)

---

PANATERM parameter: “Axis number”

Setting range: 0 to 127

The default value is 1.

Select a value between 1 and 127. 0 is not accepted with Modbus RTU. Make sure the axis number setting in the PLC program and in the servo driver are identical. In this example, set axis 1.

## 4.9 Pr5.37 (Communication protocol)

PANATERM parameter: “Modbus connection setting”

Setting range: 0 to 2

The default value is 0 (MINAS standard protocol).

Select 1: Modbus-RTU (RS232 communication) or (RS485 communication), depending on your requirements.

## 4.10 Pr5.38 (Modbus parity and stop bit setting)

PANATERM parameter: “Modbus communication setting”

Setting range: 0 to 5

The default value is 0: Even/1 bit

Make sure the parity and stop bit setting in the PLC program and in the servo driver are identical.

In this example, select “Odd/1 bit”.

## 4.11 Pr5.39 (Modbus response waiting time)

PANATERM parameter: “Modbus response waiting time”

Setting range: 0 to 10000

The default value is 0.

Set 5ms for the FP0H. (If you are using a different PLC type, set 0ms for the FP7 and 50ms for the FP-X or FPΣ).

## 4.12 Pr6.28 (Block operation mode)

PANATERM parameter: “Special function selection”

Setting range: 0 to 1

The default value is 0.

Select 1: Block operation valid (Modbus)

## 5 Function test

To quickly test your settings, use one of the demo programs included in our MC\_Modbus\_Library


Click on the following link to download the library from our Panasonic Download Center:  
[MC\\_Modbus\\_Library with demo program for block operation](#)

### ⚠ CAUTION



Conduct trial operation on the servo motor only with the motor shaft disconnected from the machine to avoid any unexpected accidents.

1. Connect the PLC to the servo driver as described in this *Quick Start Guide*.
2. Install the MC\_Modbus library by executing the setup file.
3. Select “FP0R Example” or “FP7 Example” from “Start” menu. FPWIN Pro starts and opens the demo project included in the library.
4. Select “Online” > “PLC type” and set the connected PLC type.
5. Check the communication settings of the serial port you are using and make sure the system register settings match the settings in PANATERM.  
The “Communication mode” must be “Modbus RTU master/slave”.  
The baud rate setting in this demo program is 115200 baud, the parity is odd, and the number of stop bits is 1.
6. Select “Online” > “Online mode”. When asked, select “Compile all” and “Download program code and PLC configuration to PLC” to download the demo program to the connected PLC.
7. Select “Online” > “Change PLC mode” or double-click on “PROG” in the status bar to switch to RUN mode
8. Double-click the POU “\_999\_Sample\_MoveRelative” in the navigator.  
The POU opens in the programming window:



*POU “\_999\_Sample\_MoveRelative” of MC\_Modbus\_Library in Control FPWIN Pro 7*

This program performs a relative movement on axis 1. Make sure the same axis is set in PANATERM.

9. Set **g\_bUseAxis1** of **MB\_MC\_InitializeAxis** to TRUE. When data transmission to axis 1 starts, the SD/RD LED of the selected COM port begins to flicker.
10. Set **bEnablePower** of **MB\_MC\_Power** to TRUE to send a servo ON request signal to the servo driver. When the servo is on, **bPower** will be TRUE.
11. Set **bEnableRelativePositioning** of **MB\_MC\_ConfigBlock\_MoveRelative** to TRUE to transmit the positioning parameters specified with this function to block operation table of the servo driver.
12. Set **bRun** of **MB\_MC\_StartBlockOperationNumber** to TRUE to start the movement.

## 6 Help us improve

---

Please feel free to contact us if you have any questions, or if you have any suggestions for improvement. In that case, we ask you to include the Quick Start Guide number in the email subject line. You can find the number starting with "QS" on the cover page.

[Servo.pewe@eu.panasonic.com](mailto:Servo.pewe@eu.panasonic.com)

+49 (0) 8945354-2750

## 7 Record of changes

---

QS2002\_V1.0\_EN, 2019.07

First edition



## North America

## Europe

## Asia Pacific

## China

## Japan

## Panasonic Electric Works

Please contact our Global Sales Companies in:

### Europe

► Headquarters	<b>Panasonic Electric Works Europe AG</b>	Robert-Koch-Straße 100, 85521 Ottobrunn, Tel. +49 89 45354-1000, Fax +49 89 45354-2111, <a href="http://www.panasonic-electric-works.com">www.panasonic-electric-works.com</a>
► Austria	<b>Panasonic Electric Works Austria GmbH</b>	Josef Madersperger Str. 2, 2362 Biedermannsdorf, Tel. +43 (0) 2236-26846, Fax +43 (0) 2236-46133 <a href="http://www.panasonic-electric-works.at">www.panasonic-electric-works.at</a>
	<b>Panasonic Industrial Devices Materials Europe GmbH</b>	Ennshafenstraße 30, 4470 Enns, Tel. +43 (0) 7223 883, Fax +43 (0) 7223 88333, <a href="http://www.panasonic-electronic-materials.com">www.panasonic-electronic-materials.com</a>
► Benelux	<b>Panasonic Electric Works Sales Western Europe B.V.</b>	De Rijn 4, (Postbus 211), 5684 PJ Best, (5680 AE Best), Netherlands, Tel. +31 (0) 499 372727, Fax +31 (0) 499 372185, <a href="http://www.panasonic-electric-works.nl">www.panasonic-electric-works.nl</a>
► Czech Republic	<b>Panasonic Electric Works Europe AG, organizační složka</b>	Administrative centre PLATINIUM, Veverí 3163/111, 616 00 Brno, Tel. +420 541 217 001, Fax +420 541 217 101, <a href="http://www.panasonic-electric-works.cz">www.panasonic-electric-works.cz</a>
► France	<b>Panasonic Electric Works Sales Western Europe B.V.</b>	Succursale française, 10, rue des petits ruisseaux, 91370 Verrières Le Buisson, Tél. +33 (0) 1 6013 5757, Fax +33 (0) 1 6013 5758, <a href="http://www.panasonic-electric-works.fr">www.panasonic-electric-works.fr</a>
► Germany	<b>Panasonic Electric Works Europe AG</b>	Robert-Koch-Straße 100, 85521 Ottobrunn, Tel. +49 89 45354-1000, Fax +49 89 45354-2111, <a href="http://www.panasonic-electric-works.de">www.panasonic-electric-works.de</a>
► Hungary	<b>Panasonic Electric Works Europe AG</b>	Magyarországi Közvetlen Kereskedelmi Képviselet, 1117 Budapest, Neumann János u. 1., Tel. +36 2236 26846-25, Mobile: +36 20 264 9896, Fax +43 2236 46133, <a href="http://www.panasonic-electric-works.hu">www.panasonic-electric-works.hu</a>
► Ireland	<b>Panasonic Electric Works UK Ltd.</b>	Irish Branch Office, Dublin, Tel. +353 (0) 14600969, Fax +353 (0) 14601131, <a href="http://www.panasonic-electric-works.co.uk">www.panasonic-electric-works.co.uk</a>
► Italy	<b>Panasonic Industry Italia srl</b>	Via del Commercio 3-5 (Z.I. Ferlina), 37012 Bussolengo (VR), Tel. +39 0456752711, Fax +39 0456700444, <a href="http://www.panasonic-electric-works.it">www.panasonic-electric-works.it</a>
► Nordic Countries	<b>Panasonic Electric Works Europe AG</b>	Filial Nordic, Knarrnäsgatan 15, 164 40 Kista, Sweden, Tel. +46 859476680, Fax +46 859476690, <a href="http://www.panasonic-electric-works.se">www.panasonic-electric-works.se</a>
	<b>Panasonic Fire &amp; Security Europe AB</b>	Jungmansgatan 12, 21119 Malmö, Tel. +46 40 697 7000, Fax +46 40 697 7099, <a href="http://www.panasonic-fire-security.com">www.panasonic-fire-security.com</a>
► Poland	<b>Panasonic Electric Works Polska sp. z o.o.</b>	ul. Wołoska 9A, 02-583 Warszawa, Tel. +48 42 230 9633, <a href="http://www.panasonic-electric-works.pl">www.panasonic-electric-works.pl</a>
► Spain	<b>Panasonic Electric Works España S.A.</b>	Barajas Park, San Severo 20, 28042 Madrid, Tel. +34 913293875, Fax +34 913292976, <a href="http://www.panasonic-electric-works.es">www.panasonic-electric-works.es</a>
► Switzerland	<b>Panasonic Electric Works Schweiz AG</b>	Grundstrasse 8, 6343 Rotkreuz, Tel. +41 (0) 41 7997050, Fax +41 (0) 41 7997055, <a href="http://www.panasonic-electric-works.ch">www.panasonic-electric-works.ch</a>
► United Kingdom	<b>Panasonic Electric Works UK Ltd.</b>	Sunrise Parkway, Linford Wood, Milton Keynes, MK14 6LF, Tel. +44 (0) 1908 231555, Fax +44 (0) 1908 231599, <a href="http://www.panasonic-electric-works.co.uk">www.panasonic-electric-works.co.uk</a>

### North & South America

► USA	<b>Panasonic Industrial Devices Sales Company of America</b>	Two Riverfront Plaza, 7th Floor, Newark, NJ 07102-5490, Tel. 1-8003-442-112, <a href="http://www.pewa.panasonic.com">www.pewa.panasonic.com</a>
-------	--	---

### Asia Pacific/China/Japan

► China	<b>Panasonic Electric Works Sales (China) Co. Ltd.</b>	Tower C 3rd Floor, Office Park, NO.5 Jinghua South Street, Chaoyang District, Beijing 100020, Tel. +86-10-5925-5988, Fax +86-10-5925-5980
► Hong Kong	<b>Panasonic Industrial Devices Sales (HK) Co., Ltd.</b>	Suite 301, 3/F, Chinachem Golden Plaza, 77 Mody Road, TST East, Kowloon, Hong Kong, Tel. +852-2529-3956, Fax +852-2528-6991
► Japan	<b>Panasonic Corporation</b>	1006, Oaza Kadoma, Kadoma-shi, Osaka 571-8501, Japan, Tel. +81-6-6908-1121, <a href="http://www.panasonic.net">www.panasonic.net</a>
► Singapore	<b>Panasonic Industrial Devices Automation Controls Sales Asia Pacific</b>	No.3 Bedok South Road, Singapore 469269, Tel. +65-6299-9181, Fax +65-6390-3953