

# Panasonic INSTRUCTION MANUAL


## Digital Fiber Sensor FX-100-Z series

MJE-FX100ZC No.0082-34V

Thank you very much for purchasing Panasonic products. Read this Instruction Manual carefully and thoroughly for the correct and optimum use of this product. Kindly keep this manual in a convenient place for quick reference.

- ### WARNING
- Never use this product as a sensing device for personnel protection.
  - In case of using sensing devices for personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection applicable in each region or country.

## 1 PART DESCRIPTION



## 2 MOUNTING

### <When using a DIN rail>

- Fit the rear part of the mounting section of the amplifier on DIN rail.
- Press down the rear part of the mounting section of the unit on the DIN rail and fit the front part of the mounting section to the DIN rail.

### How to remove the amplifier

- Push the amplifier forward.
- Lift up the front part of the amplifier to remove it.

Note: Take care that if the front part is lifted without pushing the amplifier forward, the hook on the rear portion of the mounting section is likely to break.

### <When using screws with washers>

- Use M3 screws with washers for mounting. The tightening torque should be 0.5N·m or less.

### How to connect the fiber cable

Be sure to fit the attachment to the fibers first before inserting the fibers to the amplifier. For details, refer to the Instruction Manual enclosed with the fibers.

- In cover open condition, snap the fiber lock lever down, till it stops completely.
- Insert the fiber cables slowly into the inlets until they stop. (Note 1)
- Return the fiber lock lever to the original position, till it stops.

Notes: 1) In case the fiber cables are not inserted to a position where they stop, the sensing range reduces. Since a flexible fiber is easily bent, take care when it is inserted.  
2) With the coaxial reflective type fiber, such as **FD-420** or **FD-616**, insert the single-core fiber cable into the beam-emitting inlet "P" and the multi-core fiber cable into the beam-receiving inlet "D". If they are inserted in reverse, the sensing performance will deteriorate.  
3) When disconnecting the fiber cable, make sure the fiber lock lever has been snapped down all the way. If the fiber lock is not disengaged completely, disconnecting the fiber cable in that condition can cause off the sheath surface and may cause clogging of the hole in the fiber amplifier.

## 3 WIRING

- Make sure to use the cable with connector **CN-24A-C** (optional) when connecting to this product.
- Tighten the fixing ring of the cable with connector completely by hand when mounting. (The tightening torque: 0.3 to 0.4N·m)
- Make sure to hold the side surface of this product when tightening or loosening the fixing ring of the cable with connector.
- If the fixing ring is tightened by a tool such as pliers, it may cause connector damage.
- If the tightening torque is not enough, the fixing ring may loosen due to vibration, etc.

### Connection method

- Insert the cable with connector **CN-24A-C** (optional) into this product's connector area as shown in the right figure.

### Disconnection method

- Loosen the fixing ring, and, holding the fixing ring, pull to separate the connector.


Note: Before disconnecting, make sure to check that the fixing ring is completely loosened. If the cable is pulled by excessive force (15N or more) when the fixing ring is tightened, the cable may break.

### <Connector pin arrangement>


Connector pin No.	Terminal name
1	+V
2	External input
3	0V
4	Output

## 4 I/O CIRCUIT DIAGRAMS

### NPN output type



### PNP output type




\*1 Non-voltage contact or NPN open-collector transistor  
\*2 Non-voltage contact or PNP open-collector transistor

## 5 RUN MODE

### <Digital display>


- When turning ON the power, the product name is indicated on the green digital display, while the emission frequency is indicated on the red digital display. Then switches into RUN mode [digital display (green: threshold value, red: incident light intensity)].

- When selecting emission halt in the external input setting mode and receiving the signal externally, "E-oF" is indicated on the red digital display.
- When selecting ECO in the external input setting mode, key operation on the main body is invalid during external input.
- When selecting 2-point teaching in the external input setting mode, "2-Pt" is indicated on the green digital display after inputting the first point.
- When ECO setting mode is ON, the digital display turns off in approx. 20 sec. In case of lighting up the digital display again, press any key for 2 sec. or more.
- For the settings of external input and ECO, refer to **8 PRO MODE**.



### Threshold value fine adjustment function


- Fine adjustment of threshold value can be done when in RUN mode.
- Press the set value UP key or set value DOWN key to change threshold value. (Hold down the key to make the value change faster.)
- The threshold value is stored after 3 sec.



### Keylock function

- The keylock function prevents key operations so that the conditions set in each setting mode are not inadvertently changed.
- In the keylock condition, "Loc on" is displayed when pressing any key.

### <Keylock set>





### <Keylock released>
























## 6 SETTING MODE




















- Setting mode appears after pressing **MODE key for 2 sec. in RUN mode**.
- RUN mode appears when **MODE key** is pressed for 2 sec. while setting and the changed contents have been set.
- Make sure to return to RUN mode before turning OFF the power. If the power is turned OFF while setting, the changed contents have not been set.


















## <For output ON when in object absent condition>



## <For output ON when in object absent condition>




## <External input setting mode>



## 9 EXTERNAL INPUT SETTING

- When selecting emission halt in the external input setting mode and receiving the signal externally, "E-oF" is indicated on the red digital display.
- When selecting ECO in the external input setting mode, key operation on the main body is invalid during external input.
- When selecting 2-point teaching in the external input setting mode, "2-Pt" is indicated on the green digital display after inputting the first point.
- For the setting of external input, refer to **8 PRO MODE**.

### <Time chart when setting external input>




Notes: 1) Output may turn ON / OFF when emission is halted or is released depending on setting of threshold value.  
2) When emission starts, output operation will be undetermined only during the response time.  
Example: For the FX-101-Z with emission frequency 0 (response time 250µs or less)  
Time period: 20ms + 0.25ms (250µs) + 20ms = 40.25ms

- After teaching is complete, output operation will be undetermined only during the response time. If the output signal is received by something such as a PLC, set the timer to the amplifier response time or greater. The threshold value will be set based on the incident light intensity at the instant when teaching is verified.
- Move the sensing object past once during the time that the external input signal is being input.
- After teaching is complete, output operation will be undetermined only during the response time. If the output signal is received by something such as a PLC, set the timer to the amplifier response time or greater.

### <Alert output of external input teaching>

- When conducting limit teaching or 2-point teaching by external input, if the alert output of external input teaching "In-Lt" is set in the threshold value margin setting mode, output turns ON / OFF every 100ms in case the rate of reference incident light intensity and threshold value after teaching is 200% or more, or in case it is less than half of the shift amount.
- For the setting method, refer to **<Threshold value margin setting mode>** under **8 PRO MODE**.




Notes: 1) In case the margin is no good, output turns ON / OFF every 100ms during the time that the external input signal is being input after teaching.  
2) In case the margin is no good, output turns ON / OFF every 100ms during the time that the external input signal is being input after the second teaching.

## 10 SETTING COPY FUNCTION

- This can copy the settings of the master side amplifier to the slave side amplifier.
- Be sure to use the setting copy function between the identical models. This function cannot be used between different models.
- Only one sensor can be connected on slave side with a master side sensor for the setting copy function.
- Threshold value, output operation setting, timer operation setting, threshold value-storing setting, ECO setting, inverting digital display setting, and threshold value margin setting can be copied.

### Setting procedures

- Set the setting copy mode of the master side amplifier to "Copy sending ON," and press **MODE key** so that "CoPY rEdY" is shown on the digital display and the sensor is in copy ready state. For the setting method, refer to **<Setting copy mode>** in **8 PRO MODE**.
- Turn off the master side amplifier.
- Connect the master side amplifier with the slave side amplifier as shown below.



- Turn on the master side amplifier and the slave side amplifier at the same time. (Note)
- "CoPY" is shown on the green digital display of the master side amplifier and 4-digit code is shown on the red digital display of the slave side amplifier.
- When the copying is completed, "9999" is shown on the green digital display of the slave side amplifier, while the 4-digit code (the same code as the master side amplifier) is shown on the red digital display of it.
- Turn off the power of the master side amplifier and the slave side amplifier and disconnect the wire.
- If copying the settings to another amplifier repeatedly, follow the steps 3 to 7.


Note: Take care that if the power is not turned on at the same time, the settings contents may not be copied.

### To cancel the setting copy mode of the master side amplifier

- While the slave side amplifier is disconnected, turn on the power of the master side amplifier.
- Press **MODE key** for approx. 2 sec.

## 11 QUICK SETTING FUNCTION

- Simply by selecting a setting number, output operation, emission amount, timer, and emission frequency can be set.
- For the setting numbers, refer to **<Table of quick setting numbers>**.
- Make sure to return to RUN mode before turning OFF the power. If the power is turned OFF while setting, the changed contents have not been set.




Notes: 1) Cancellation is possible when pressing **MODE key** for 2 sec. or more before finalizing, then returns to RUN mode.  
2) When the present setting is out of the quick setting range, "-99-" is shown. When "-99-" is selected, the set contents are not changed.

### <Table of quick setting numbers>

No.	Output operation	Emission amount setting	Timer	No.	Output operation	Emission amount setting	Timer
-00-	D-ON	Level 3	non	-10-	L-ON	Level 2	on and 40ms
-01-	D-ON	Level 2	non	-11-	L-ON	Level 3	on and 40ms
-02-	D-ON	Level 3	old 10ms	-12-	L-ON	Level 2	on and 10ms
-03-	D-ON	Level 2	old 10ms	-13-	L-ON	Level 3	on and 10ms
-04-	D-ON	Level 3	old 40ms	-14-	L-ON	Level 2	old 40ms
-05-	D-ON	Level 2	old 40ms	-15-	L-ON	Level 3	old 40ms
-06-	D-ON	Level 3	old 10ms	-16-	L-ON	Level 2	old 10ms
-07-	D-ON	Level 2	old 10ms	-17-	L-ON	Level 3	old 10ms
-08-	D-ON	Level 3	old 40ms	-18-	L-ON	Level 2	non
-09-	D-ON	Level 2	old 40ms	-19-	L-ON	Level 3	non

## 12 CODE SETTING FUNCTION

- By selecting codes arbitrarily, output operation, timer, emission amount, emission frequency, ECO, external input, and shift amount can be set.
- For the codes, refer to **<Code table>**.
- Make sure to return to RUN mode before turning OFF the power. If the power is turned OFF while setting, the changed contents have not been set.



Notes: 1) Although the quick setting function appears 2 sec. after the set value UP key and set value DOWN key are pressed, keep pressing the key.  
2) Cancellation is possible when **MODE key** is pressed for 2 sec. or more before the digit blinks, then returns to RUN mode.  
3) Cancellation of set value is possible when **MODE key** is pressed for 2 sec. or more while the digit is blinking.  
4) When the fourth digit is determined, the settings are reflected.

### <Code table>

Code	Output operation	Timer	Emission amount setting	Emission frequency	ECO	External input	Shift (Note 5)
0							
1							
2	D-on	non	Level 3	0	2	OFF	Limit teaching [+]
3		old 10ms		2	3		Limit teaching [-]
4		old 10ms		3	4		Full-auto teaching
5		old 40ms		0	1		ECO
6		non		1	2		Emission halt
7	L-on	old 10ms		2	3		Limit teaching [+]
8		old 40ms		3	4	ON	Limit teaching [-]
9		old 40ms		0	1		Full-auto teaching
A				1	2		ECO
b				2	3	OFF	2-level teaching
c				3	4		Incident light intensity test
d				0	1	ON	2-level teaching
e				1	2		Incident light intensity test
F				2	3		

Notes: 5) When the present setting is out of the code setting range, "-1-" is shown. When "-1-" is selected, the set contents of the digit is not changed.  
6) The factory setting is "0000".

## 13 ERROR INDICATION

- In case of errors, attempt the following measures.

Display	Error description	Measures
E-oF	EEPROM writing error	Turn off the power.
E-1	The load has short-circuited and excess current is flowing.	Turn off the power, then check the load.
E-5	Communication error (Disconnection, connection failure, etc.)	Check the wiring before using the setting copy function.

## 14 SPECIFICATIONS

Type	Standard	Long sensing range
Model No. NPN output	FX-101-Z	FX-102-Z
Item (Note 1) PNP output	FX-101P-Z	FX-102P-Z
Supply voltage	12 to 24V DC ±10% Ripple P-P 10% or less (within the rated range)	
Power consumption	Normal operation: 220mW or less (Current consumption 30mA or less at 24V supply voltage) ECO mode: 600mW or less (Current consumption 25mA or less at 24V supply voltage)	
Output	*NPN output type*	*PNP output type*
	NPN open-collector transistor	PNP open-collector transistor
	Maximum sink current: 100mA Applied voltage: 30V DC or less (between output and 0V)	Maximum source current: 100mA Applied voltage: 30V DC or less (between output and +V)
	Residual voltage: 1.5V or less (at 100mA sink current)	Residual voltage: 1.5V or less (at 100mA source current)
Output operation	On/Off	On/Off, On/Off selectable