

Flexible Wire-Saving System

## S-LINK V

# USER'S MANUAL

---



# Contents

<b>Before Using This System</b> .....	<b>5</b>	<b>Chapter 2</b> .....	<b>35</b>
Introduction .....	6	<b>Wiring</b> .....	<b>35</b>
Warnings .....	6	Flowchart .....	36
Instructions for Safe Use .....	7	Basic Procedures .....	37
Ambient conditions .....	7	Connector hook-up work .....	37
Instructions for Use .....	8	Cutting of exclusive 4-core flat cable .....	37
Instructions for Designing .....	8	How to use exclusive hook-up pliers (SL-JPS, SL-JPC, SL-JPE) .....	38
Fail-safe function .....	8	Hook-up of Connector .....	39
Conformity to EC Directives .....	8	Hook-up method of SL-JK connector for cable end and SL-JK1 connector for 'T'-branch .....	39
Use with S-LINK system .....	8	Hook-up method of <b>SL-J1A</b> connector for 'T' - branch and SL-J3A connector for cable extension .....	41
Instructions for Installation .....	9	Hook-up method of <b>SL-CP1</b> , <b>SL-CP2</b> , and SL-CP3 snap male connectors and <b>SL-CJ1</b> and <b>SL-CJ2</b> snap female connectors .....	44
Hook-up cable connectors .....	9	Connection to Terminal Block .....	46
Wiring .....	9	Extension of Main / Branch Line Cable .....	47
Others .....	9	Extension of exclusive 4-core flat cables .....	47
Instructions for Disposal .....	9	Extension of cable excluding exclusive 4-core flat cables .....	47
Designing / Installation Procedures .....	10	Extension of cable to I/O device .....	47
MEMO .....	12	Installation .....	48
<b>Chapter 1</b> .....	<b>13</b>	Installation of each unit .....	48
<b>Designing System</b> .....	<b>13</b>	Construction .....	50
System Configuration .....	14	Power Supply .....	50
Outline of Design .....	16	Power supply to system .....	50
Selection of Controller or Control board .....	16	Connection of Each Unit .....	51
I/O Control Points .....	16	Connection of controller .....	51
Transmission Distance .....	16	Connection of bus direct-connection type controller and control board .....	52
Outputting Error Signals .....	17	Connection of PLC I/O Connector .....	53
Connection of End Unit .....	18	Connection of I/O unit .....	55
Selection of Control Cable and Connector		Connection of I/O device .....	56
Link Cable .....	18	Connection of main line cable to end unit .....	57
Control cable selection method:		Connection of local power supply unit .....	58
(For use of <b>SL-VCU1</b> only) .....	18	Local power supply to system .....	58
Connector link cable selection method: (For use of <b>SL-VCU1</b> only) .....	18	Installation method of batteries .....	59
Making of Branch Lines Using Cable		MEMO .....	60
Connectors .....	19	<b>Chapter 3</b> .....	<b>61</b>
Power Supply Capacity of System .....	20	<b>Starting System</b> .....	<b>61</b>
Calculation of Total Current Consumption Value .....	20	Flowchart .....	62
Example: Calculation of current consumption .....	22	Wiring Check .....	64
Calculation of Voltage Drop Value .....	23	Check before Starting .....	64
Rated voltage (V) .....	23	Check of wiring conditions of controller and control board .....	64
Necessity of Local Power Supply Unit .....	24	Check of PLC I/O connectors .....	65
Designing of system using local power supply method .....	24	Check of cable for short-circuit .....	65
Connection of DC 2-Wire Output Device to Input Unit .....	26	Starting .....	66
Example: Connection of DC 2-wire sensor .....	27	Power-on (Main Power and Local Power) .....	66
Transmission Delay Time .....	28	CONFIG mode .....	66
Response delay time .....	28	Check of Recognized Addresses .....	70
Operation at power-on .....	30	CHECK mode .....	70
Error signal outputting delay time .....	30		
System setting time .....	31		
Selection of Output Holding Function for Output Unit .....	32		
Output holding function setting method .....	32		
Address Setting .....	33		
Setting of PLC I/O connector numbers .....	33		
Setting of I/O unit addresses .....	33		
Example: Address setting .....	34		

**Chapter 4**..... 71

**Specifications** ..... 71

Specifications ..... 72

Common Specifications ..... 72

Address setting switches ..... 72

Specifications of Each Unit ..... 75

Controller ..... 75

Bus direct-connection type controller for FP2 / FP2SH Series ..... 79

Bus direct-connection type controller for FP7 Series ..... 83

Mitsubishi MELSEC-Q Series PLC bus direct-connection type controller ..... 87

Control board ..... 91

Control module ..... 95

PLC I/O connector ..... 97

I/O unit ..... 100

Input terminal ..... 103

Output terminal ..... 107

Connector input unit ..... 111

Connector output unit ..... 115

MIL connector input unit ..... 119

MIL connector output unit ..... 122

Analogue input unit ..... 125

Analogue output unit ..... 131

Relay output terminal ..... 136

Input module ..... 139

Output module ..... 141

Picking switch ..... 143

Picking switch for shutter ..... 146

Address setting remote controller ..... 149

End unit ..... 151

Handy monitor ..... 153

Cable ..... 157

Hook-up connector ..... 157

List of programmable logic controllers (PLC) (upper models) ..... 159

List of Models ..... 160

Controller ..... 161

Control board ..... 161

Control module ..... 161

List of I/O units ..... 162

List of connectors ..... 163

Handy monitor ..... 163

Address setting remote controller ..... 163

Others ..... 164

**Chapter 5**.....165

**Troubleshooting** .....165

Troubleshooting ..... 166

Flowchart for taking corrective action for detected error ..... 166

Flowchart for power supply condition check ..... 169

How to identify error unit after error detection ..... 171

How to extinguish error indicator ..... 172

Utilization of output holding function ..... 172

**Appendix** .....173

Appendix ..... 174

List of error numbers ..... 174

Flowchart for error detection ..... 175

Selection of connector link cable ..... 176

Setting of connector numbers, ..... 180

addresses, and number of I/O control points ..... 180

Glossary ..... 181

FAX Sheet for Asking Question ..... 183

MEMO ..... 184

# Before Using This System

---

---

# Introduction

The **S-LINK V** is a flexible wire-saving that uses our original transmission system to enable high-speed and highly reliable signal transmissions.  
Fully understand the functions and performance of this system before constructing this system.

This manual provides information necessary for construction of the **S-LINK V** flexible wire-saving system. Before constructing the **S-LINK V** system, carefully read this manual and fully understand the system. In addition, be sure to observe the cautions, and correctly use the system. The controllers listed below have their own user's manuals. For a detailed description, refer to that documentation.

**SL-VGU1-C, SL-VGU1-D** : **SL-VGU1-C / SL-VGU1-D** User's Manual

**SL-VGU1-EC** : **SL-VGU1-EC** User's Manual

**SL-VGU1-485** : **SL-VGU1-485** User's Manual

**SL-VMEL-Q** : **SL-VMEL-Q** User's Manual

**SL-VFP7** : **SL-VFP7** User's Manual

For other controllers, refer to the instruction manuals enclosed with the controllers.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

## Warnings

This manual uses three types of warnings depending on the hazard level. They are '**DANGER**,' '**WARNING**,' and '**CAUTION**.' To safely use the **S-LINK V** system, be sure to observe these warnings.

### **DANGER**

'**DANGER**' indicates that mishandling of this system may result in death or serious injury, and this word is limitedly used in the extremely hazardous situations.

### **WARNING**

'**WARNING**' indicates that mishandling of this system may result in death or serious injury.

### **CAUTION**

'**CAUTION**' indicates that mishandling of this system may result in injury or damage of the system.



'**NOTE**' provides caution or information to you in order to prevent operation errors.

### Remarks

- 1) Panasonic Industrial Devices SUNX Co., Ltd. holds the copyright of this document. For this reason, do not copy this document without our permission.
- 2) The contents of this document may be subject to change without prior notice for the reasons of improvement.
- 3) The product specifications shown in this document were determined in September 2020.

# Instructions for Safe Use

## WARNING

The **S-LINK V** system does not have any control functions, such as accident preventive function and safety function. For this reason, do not use the **S-LINK V** system if malfunction of the system may affect human lives or assets.

Even if this system is not used as an accident preventive system or safety system, if this system is used for a nuclear power control system, railroad facility, aviation facility, vehicle, combustion system, medical equipment, or the like, be sure to design a system having enough capacity, and adopt safety measures for the system, such as a fail-safe function. In addition, please contact our sales division.



## Ambient conditions

Do not use this system at the following places:


Place where the ambient temperature is out of the specified range of 0 to +55°C (Note 1)

Notes:

- 1) The optimum ambient temperature depends on the product type. For this reason, check the specifications of this product shown in Chapter 4.
- 2) If this product is incorporated in the control box together with the other unit, the unit may generate heat to change the ambient temperature. In this case, install a cooling fan so that the ambient temperature cannot exceed the rated upper limit temperature.




Place where the ambient temperature extremely varies and dew condensation may be caused.




Place where the ambient humidity is out of the specified range of 35 to 85% RH (Note)


Note  
The optimum ambient humidity depends on the product type. For this reason, check the specifications of this product shown in Chapter 4.




Place where there is a corrosive or flammable gas




Steamy or dusty place or place near water, oil, or chemical source



Place where vibration or shock of more than the specified level may be directly applied to the system main body



Place where direct sunlight may enter



Closed place  
However, if a ventilation hole or a fan is installed, such a place can be used.

# Instructions for Use

## Instructions for Designing

### Fail-safe function

#### CAUTION


Disconnection of a signal line, instantaneous power failure, or abnormal signal may cause a problem. For this reason, please adopt a fail-safe function for the entire system by yourself. To ensure safety, be sure to incorporate the interlock circuit, limit circuit, or the like, in the external circuit excluding the **S-LINK V** system circuit.

To incorporate the **S-LINK V** system in your equipment, be sure to adopt a fail-safe function. Regarding the fail-safe function, if you have an unclear or doubtful point, please contact our sales division.

### Conformity to EC Directives

#### WARNING

- Each unit of the **S-LINK V** series conforms to various standards. However, to incorporate a unit in the system, check that entire system can conform to various standards.
- The lightning surge preventive function is not adopted for the I/O module (**SL-VM**□ / **VMP**□). To conform to the requirements of EN 61000-6-2, incorporate the following circuit in your board.



Surge absorber  
Recommended part: ERZV05D390 manufactured by Panasonic Corporation (Note)

Note: If a different part is used, a resistor may be needed between the power supply unit and the surge absorber. Check whether a resistor is needed.

- If it is not necessary for the relay output terminal (**SL-VTPR4/8**) to conform to the EC Directives, use of 250V AC, 3A is possible.

To conform to the EC Directives, the **S-LINK V** system is tested in accordance with the EMC Directive standards, such as EN 61000-6-4 of the EMI standard and EN 61000-6-2 of the EMS standard. When you incorporate the **S-LINK V** system in your machine or equipment, check that the wiring condition conforms to the requirements of the EC Directives.

To use the **SL-VGU1-C** together with the PLC (programmable logic controller) manufactured by Mitsubishi Electric Corporation and to conform to the requirements of the EMC Directive, install the system in accordance with the PLC User's Manual prepared by Mitsubishi, and be sure to observe the following items:


- Be sure to put the PLC and the **SL-VGU1-C** in a conductive box.
- Be sure to ground the shielded cable that connects the PLC to the **SL-VGU1-C** in the 300mm area of the **SL-VGU1-C**.
- If the shielding effect is not enough, install a ferrite core.

### Use with S-LINK system


The **S-LINK V** system cannot be used together with the **S-LINK** system. Use with a system may cause abnormal operation or damage. Separately construct the **S-LINK V** system and the **S-LINK** system.

However, if gateway controllers are used as the child station of the open network (CC-Link, DeviceNet, RS-485 / RS-232C, EtherCAT), 2 systems can be used together on the same network.

Not good



Good



## Instructions for Installation



### CAUTION

- Select a power supply unit equipped with the short-circuit protective function (fuse, etc.).
- The power of the **S-LINK V** system passes through the inside of each unit and is then supplied to the main cable or I/O device side. However, the short-circuit protective function is not adopted for this power supply circuit. For this reason, adopt a short-circuit protective function, such as a fuse, for the power supply circuit.
- Take care that wrong wiring will damage the product.
- Before starting the following works, be sure to turn off the power of the PLC (programmable logic controller), personal computer main body, **S-LINK V** units, and also turn off the power supply unit of the I/O device.
  - Machine assembly (installation)
  - Removal or reinstallation of a **S-LINK V** unit or connection of I/O device
  - Cable connection
  - Address setting / change
- Before handling this product, remove any electrostatic charge that may be present on your body. There is a danger of this product getting damaged due to the electrostatic charge.

## Hook-up cable connectors

To hook-up an exclusive cable connector, use the exclusive tool, and correctly hook-up the connector by following the procedure specified in this manual.

If a connector is not correctly hooked-up, the **S-LINK V** system will not operate.

In addition, observe the following items:

- After checking the cable type and the purpose, select the right type of connector.
- Before hook-up a connector, be sure to check the colors of cables to be connected.
- Use the exclusive hook-up pliers (**SL-JPS**, **SL-JPC** or **SL-JPE**) to hook-up the connectors.

For the hook-up procedure of each connector, refer to pages 37 to 45.

- If a connector is once hooked-up, do not reuse the connector.

The performance of such a connector may be deteriorated.

## Wiring

Observe the following items to distribute cables:

- Keep cables away from the power line and the high-voltage line.
- Do not completely fold down any cables.
- Do not pull any cables with a strong force.
- Do not apply any weight to any cable.
- Do not touch a cable to any other system cables.  
This is because signals of different systems may interfere with each other.
- Do not bend cables many times.
- Wind insulation tape on the end of each cable, if necessary.

## Others

- Apply the specified torque to tighten terminal screws of each unit.
- Check the connectors for looseness.
- Do not disassemble or modify this product.


## Instructions for Disposal

- Request a waste disposal company to dispose of this product.

# Designing / Installation Procedures



## Chapter 1 Designing System

- Determine the system design.
  - Determine the necessary number of I/O points for the I/O device.
  - Determine the cable length necessary for transmission.
  - Select the transmission speed.
  - Set the address.
  - Calculate the power supply capacity of the system.
  - Determine the connection method for the input device of DC 2-wire output type.
  - Determine the transmission delay time.
  - Set the output holding function.




## Chapter 2 Wiring

- This chapter describes the wiring methods to be used for actual installation.
  - Caution regarding cutting of exclusive 4-core flat cable
  - Connector hook-up method
  - Cable extension method
  - Connection to I/O device
  - Connection of local power supply unit
  - Connection to terminal block




## Chapter 3 Starting System

- Check the system before starting.
  - Check the cable for short-circuit.
  - Check the system before starting.
  - Caution regarding power-on
  - Description of CONFIG mode
  - Description of CHECK mode



## Chapter 4 Specifications

- Select **S-LINK V** units optimum for the purpose of your system.
  - **S-LINK V** control units
  - **S-LINK V** input units
  - **S-LINK V** output units
  - Hook-up connector
  - Exclusive 4-core flat cable



## Chapter 5 Troubleshooting

- This chapter describes how to solve the problem if the **S-LINK V** system does not operate properly.
  - Troubleshooting after error indication
  - Power supply check procedure
  - How to extinguish the error indicators

## Appendix

- List of error numbers
- Flowchart for error detection
- Selection of connector link cable for PLC
- Fax sheet for asking questions

This manual is prepared for the designer and the installer of the **S-LINK V** system. The following items are common to both the designer and the installer:

- **Before Using This System**
- **'Chapter 4 Specifications'**
- **'Chapter 5 Troubleshooting'**
- **Appendix**

In addition, the designer should refer to **'Chapter 1 Designing System,'** and the installer should refer to **'Chapter 2 Wiring'** and **'Chapter 3 Starting System.'**

---

# MEMO



Before Using This System

# **Chapter 1**

# **Designing System**

---


---

# System Configuration

## Example of system configuration

An example of the S-LINK V system is shown below.  
For the specifications of each unit, refer to Chapter 4.

### Control board



Bus direct-connection type S-LINK V controller for FP2 / FP2SH series  
**SL-VFP2**

Bus direct-connection type S-LINK V controller for FP7 series  
**SL-VFP7**

Bus direct-connection type S-LINK V controller for MELSEC-Q series PLC manufactured by Mitsubishi Electric Corp.  
**SL-VMEL-Q**

### Gateway controller (Note)

S-LINK V gateway controller for CC-Link  
**SL-VGU1-C**

S-LINK V gateway controller for DeviceNet  
**SL-VGU1-D**

S-LINK V gateway controller for RS-485 / RS-232C  
**SL-VGU1-485**

S-LINK V gateway controller for EtherCAT  
**SL-VGU1-EC**


Note: For a detailed description of the following controllers, refer to their respective user's manuals.  
**SL-VGU1-C, SL-VGU1-D:** SL-VGU1-C / SL-VGU1-D User's Manual  
**SL-VGU1-EC:** SL-VGU1-EC User's Manual  
**SL-VGU1-485:** SL-VGU1-485 User's Manual  
**SL-VMEL-Q:** SL-VMEL-Q User's Manual  
**SL-VFP7:** SL-VFP7 User's Manual




For flexible wire-saving system

● I/O module

[Input module]  
SL-VM8 / VM16




[Output module]  
SL-VMP8 / VMP16




● Cables and hook-up connectors

[Exclusive 4-core flat cable]  
SL-RCM100□ / RCM200




Flat cables are available so that 'T' - branch can be easily formed by using hook-up connectors.

[Hook-up connectors]




There are various types of hook-up connectors that enable easy connection of cables.

● Picking switch  
SL-VPK01 SL-VPK02



● Handy monitor  
SL-VHM1



e-CON type 8-channel connector input unit  
SL-VT8E

1-channel input unit  
SL-VCH10

2-channel input unit  
SL-VCH20

2-channel I/O mixed unit  
SL-VCH21

1-channel output unit  
SL-VCH11

2-channel output unit  
SL-VCH22

8-channel connector input unit  
SL-VT8J

e-CON type 4-channel connector input unit  
SL-VT4E

16-channel MIL connector input unit  
SL-VT16C1

4-channel connector input unit  
SL-VT4J

Analog input unit  
SL-VTAD1

4-channel input terminal  
SL-VTB4

8-channel input terminal  
SL-VTB8


16-channel input terminal  
SL-VTB16

32-channel input terminal  
SL-VTB32

4-channel relay output terminal  
SL-VTPR4

8-channel relay output terminal  
SL-VTPR8

End unit  
SL-VEU



# Outline of Design

## Selection of Controller or Control board

Select a **S-LINK V** controller or a **S-LINK V** control board optimum for the upper machines (PLC, PC, PCI bus computer, VME bus computer, open network).

## I/O Control Points

The system needs the following I/O control points. Design the system considering these points.

- Each controller or control board can control up to 256 nodes (number of I/O units connected to the system) and 512 points (512 points × 2 for the **SL-VVMES2**). To control more than 512 points (512 points × 2 for the **SL-VVMES2**) of I/O device, connect two or more controllers as the other systems.
- To cope with various PLC connection types of various manufacturers, we can provide 8 types of PLC input connectors and 7 types of PLC output connectors. For a detailed description, refer to pages 159 and 160. Each PLC I/O connector has 32 points for any model.



Each system needs one controller or one control board.  
Two or more controllers or control boards cannot be connected to one system.  
The above described number of I/O control points (512 points or 512 points × 2 for the **SL-VVMES2**) and the number of nodes (256 nodes) are the maximum values.  
This means that these values depend on the total cable length and the conditions of the connected machine (total current consumption, voltage drop, etc.).  
For a detailed description, refer to pages 16 to 25.

## Transmission Distance


The following two types of cables can be used for the **S-LINK V** system.

- Exclusive 4-core flat cable (recommended cable)
- 4-core VCTF cable (0.3 to 2.0mm<sup>2</sup>, non-shielded) commercially available

Note: The VCTF cable is the vinyl cabtyre cable that conforms to the requirements of JIS C 3306 'Polyvinyl chloride insulated flexible cords.'

To wire the **S-LINK V** system, use 4-core cables so that the wire system can consist of 2 power supply lines (+24V, 0V) and 2 signal transmission lines (D, G).

The cable length depends on the total cable length and the transmission distance.





- The main line is the longest route distributed from the controller or control board.
- The branch lines are the routes branched from the main line.

The total cable length should satisfy the conditions shown in the following table:

Transmission mode	Total cable length (m)
A	100
B	400
C	1,600

The maximum transmission distance (between D and G) is as follows:

• **Mode A: 50m**

The maximum length is 50m regardless of the cable conductor cross section (0.3 to 2.0mm<sup>2</sup>) and the number of nodes (1 to 256 nodes).

• **Mode B**

Conductor cross section (mm <sup>2</sup> )	Number of nodes and maximum transmission length (m)	
	Up to 224 nodes	Up to 256 nodes
0.3	200 (full specification for mode B)	180
0.5		
0.75		
1.25		
2.0		

• **Mode C**

Conductor cross section (mm <sup>2</sup> )	Number of nodes and maximum transmission length (m)							
	Up to 32 nodes	Up to 64 nodes	Up to 96 nodes	Up to 128 nodes	Up to 160 nodes	Up to 192 nodes	Up to 224 nodes	Up to 256 nodes
0.3	570	440	350	300	260	220	200	180
0.5		710	580	490	420	370	330	300
0.75				780	670	590	530	480
1.25				800 (full specification for mode C)				
2.0								



- Voltage drop between +24V and 0V is not considered. For this reason, calculate this voltage drop value, and use a local power supply unit, etc. to prevent voltage drop. For a detailed description, refer to page 23.
- The conductor cross section of the exclusive 4-core flat cable **SL-RCM**□ is 0.5mm<sup>2</sup>.
- Wire the **S-LINK V** system while observing the communication distance specifications described above. In addition, use the cables that satisfy the specifications described above.
- To select applicable cables, refer to the section describing cables. For a detailed description, refer to page 157.
- The picking switch **SL-VPK0**□ cannot be used in mode A (transmission mode).

## Outputting Error Signals

If the controller is equipped with the error signal output function, the controller can output an error signal after detection of an error.

To output an error signal, the **S-LINK V** system will be turned on properly. If an error occurs, the NPN output transistor will be turned off.

For each type of error, you can select whether the error signal should be output.

For the Troubleshooting, refer to page 165.

For the error, refer to page 166.

## Connection of End Unit

### CAUTION


Each system needs at least 1 **SL-VEU** end unit. If the **SL-VEU** unit is not connected, the system may not operate properly.  
If the cable lengths are the same, connect the end unit to the line having fewer nodes (units).

Be sure to connect 1 **SL-VEU** end unit to the end of the main line.


If the branch line length exceeds 80% of the maximum transmission distance, connect 1 **SL-VEU** unit to the end of the branch line, too.

Up to 2 **SL-VEU** end units can be connected for 1 system.

<If the branch line length is equal to the main line length>



<If the branch line length is 80% of the main line length or more>



Notes: 1) The maximum transmission distance depends on the cable conductor cross section and the number of nodes.  
For the maximum transmission distance, refer to page 17.

2) Even if the cable lengths are the same, if both the main and branch line lengths exceed 80% of the maximum transmission distance, connect two **SL-VEU** end units.

## Selection of Control Cable and Connector Link Cable

### Control cable selection method: (For use of **SL-VCU1** only)


Check the distance from the **SL-VCU1** to the PLC I/O connector, and then select the applicable control cable:  
**SL-VC1000** (1m long) or **SL-VC2000** (2m long).  
One control cable is needed for every 8 PLC I/O connectors.

### Connector link cable selection method: (For use of **SL-VCU1** only)

The PLC I/O connector installation direction (vertical) and layout depend on the PLC manufacturers.  
Check the connection distance of the PLC I/O connector, and then select the applicable connector link cable:  
**SL-VF70** (70mm), **SL-VF150** (150mm), or **SL-VF250** (250mm).  
For a detailed description, refer to page 176.

# Making of Branch Lines Using Cable Connectors

Branch lines can be made by using connectors and terminal blocks.  
 In addition, for this product, cables or connectors that are commercially available can be used.




CAUTION

The exclusive hook-up connectors can connect the exclusive 4-core flat cables only.

	Exclusive 4-core flat cable	4-core VCTF cable commercially available (non-shielded) (Note)
Exclusive 4-core flat cable	Making of 'T' - branch line using exclusive hook-up connector <b>SL-J1A...1</b>	Intermediate connector commercially available or intermediate terminal block commercially available
	Extension using exclusive hook-up connector <b>SL-J3A...2</b>	
	Connection of branch line using exclusive hook-up connector <b>SL-JK1 and SL-CP3...3</b> <b>SL-JK and SL-CP3...4</b>	
4-core VCTF cable commercially available (non-shielded) (Note)	Intermediate connector commercially available...5 Intermediate terminal block commercially available...6	Intermediate connector commercially available or intermediate terminal block commercially available Note: Use the same diameter cable.

Note: The VCTF cord is the vinyl cabtyre cord that conforms to the requirements of JIS C 3306 'Polyvinyl chloride insulated flexible cords.'



# Power Supply Capacity of System

This section describes how to calculate the total current consumption value and voltage drop value in order to determine the power supply capacity (capacity of 24V DC power supply unit).

## Calculation of Total Current Consumption Value

To determine the total current consumption, check the current consumption of each I/O unit.  
Calculate the power supply capacity while referring to the list of current consumption values shown below.

Designation	Model No.	Current consumption (mA)
Controller	SL-VCU1	135
Bus direct-connection <b>S-LINK V</b> controller for FP2 / FP2SH series	SL-VFP2	60
Bus direct-connection <b>S-LINK V</b> controller for FP7 series	SL-VFP7	80
Mitsubishi MELSEC-Q PLC bus direct-connection <b>S-LINK V</b> controller	SL-VMEL-Q	70
Control board for PCI bus	SL-VPCI	85
Control board for VME bus	SL-VVMES2	88 (Note 1)
Control module	SL-VMC1	60
Gateway controller for CC-Link	SL-VGU1-C	300
Gateway controller for DeviceNet	SL-VGU1-D	300
Gateway controller for RS-485 / RS-232C	SL-VGU1-485	300
Gateway controller for EtherCAT	SL-VGU1-EC	300
Input connector for PLC	SL-VS□	30
Output connector for PLC	SL-VP□	73
End unit	SL-VEU	10
1-channel input unit	SL-VCH10	20
2-channel input unit	SL-VCH20	28
2-channel I/O mixed unit	SL-VCH21	24
1-channel output unit	SL-VCH11	16
2-channel output unit	SL-VCH22	20
4-channel connector input unit	SL-VT4J, SL-VT4E	70 (Note 2)
8-channel connector input unit	SL-VT8J, SL-VT8E	105 (Note 2)
16-channel MIL connector input unit	SL-VT16C1	80 (Note 2)
Analogue input unit	SL-VTAD1	80
8-channel input module	SL-VM8	18
16-channel input module	SL-VM16	20 (Note 2)
4-channel connector output unit	SL-VTP4J, SL-VTP4E	60 (Note 2)
8-channel connector output unit	SL-VTP8J, SL-VTP8E	90 (Note 2)
16-channel MIL connector output unit	SL-VTP16C1(-S)	50 (Note 2)
Analogue output unit	SL-VTDA1	90
8-channel output module	SL-VMP8	60
16-channel output module	SL-VMP16	95 (Note 2)
4-channel relay output terminal	SL-VTPR4	90 (Note 2, 3)
8-channel relay output terminal	SL-VTPR8	150 (Note 2, 3)
Picking switch	SL-VPK01	25
Picking switch for shutter	SL-VPK02	25 (when shutter operation: 450)
Handy monitor	SL-VHM1	500

Designation	Model No.	Current consumption (mA)	
		Unit side	I/O side (Note 4)
4-channel input terminal	<b>SL-VTB4</b>	25	45
8-channel input terminal	<b>SL-VTB8</b>	30	75
16-channel input terminal	<b>SL-VTB16</b>	35	150
32-channel input terminal	<b>SL-VTB32</b>	45	300
4-channel output terminal	<b>SL-VTBP4</b>	25	40
8-channel output terminal	<b>SL-VTBP8</b>	30	60
16-channel output terminal	<b>SL-VTBP16</b>	40	100
32-channel output terminal	<b>SL-VTBP32</b>	45	180


- Notes: 1) **SL-VVMES2**, the value for 1 port is shown in the above table.
- 2) Regarding the **SL-VTPR□**, **SL-VT□J**, **SL-VT□E**, **SL-VT□16C1(-S)**, and **SL-VM□16**, if the ambient temperature is not in the specified range, turning on of all the points may not be possible.  
For a detailed description, refer to the specifications of each product shown in **Specifications**.
- 3) The **SL-VTPR□** limits the output current depending on the ambient operation temperature and the number of ON points.  
For the characteristics of the product when using PhotoMOS relay, refer to the '**Panasonic Industrial Devices SUNX website**: <https://panasonic.net/id/pidsx/global>'.
- 4) The value shown in the 'Unit side' area indicates the current consumption in the main circuit.  
The value shown in the 'I/O side' area indicates the current consumption in the I/O circuit.



The values shown in the above table does not include the current supplied to the PLC module and current consumption of sensors and loads.  
In addition to the above units, when additional units (products) are connected, such as the 3-line sensor and output load, to the same 24V DC power supply unit, add the current consumption values of the additional units to the power supply capacity value.

## Example: Calculation of current consumption

<System configuration for control of 8 sensors and 4 output loads>




Designation	Model No.	Qty	Current consumption (mA)
Controller	SL-VCU1	1	135
End unit	SL-VEU	1	10
Input connector for PLC	SL-VS1	1	30
Output connector for PLC	SL-VP1	1	73
8-channel connector input unit	SL-VT8J	1	105
4-channel connector output unit	SL-VTP4J	1	60
8-channel input terminal	SL-VTB8	1	30 + 75 = 105
Sensors (Average current consumption: approx. 30mA)	—	8	30 × 8 = 240
Output loads (Average current consumption: approx. 20mA)	—	4	20 × 4 = 80
Total			838

## Calculation of Voltage Drop Value

The transmission cables of the **S-LINK V** system may cause voltage drop due to the conductor resistance of the cables themselves. For this reason, calculate the voltage drop value between +24V and 0V, and supply the rated voltage to all the **S-LINK V** I/O units. However, it is not necessary to consider the voltage drop between the D and G, and that of the control cables and connector link cables.


### CAUTION

Use of a longer cable will cause more voltage drop. If the voltage drops below the rated voltage, the I/O units will not work. In this case, use the local power supply unit.



$$\text{Voltage drop (V)} = \text{Cable length (m)} \times 2 \times \text{conductor resistance } (\Omega/\text{m}) \times \text{current (A)}$$

Relation between the ambient temperature and allowable passing current when exclusive S-LINK V cable SL-RCM100□ / RCM200 or SL-CBM100 / CBM200 (conductor cross section = 0.5mm<sup>2</sup> for each cable) is used.



## Rated voltage (V)

### CAUTION

The rated voltage depends on the unit. Check the rated voltage, and then select the right power supply unit and cables.

Supply the rated voltage to each unit.

- Since the rated voltage to be supplied to the controller is +24V (-5%), the voltage supplied to the controller should not be dropped below the following value:  
 $24 - (24 \times 0.05) = 22.8\text{V}$
- Since the rated voltage to be supplied to the I/O units and end unit is +24V (-10%), the voltage supplied to these units should not be dropped below the following value:  
 $24 - (24 \times 0.1) = 21.6\text{V}$

## Necessity of Local Power Supply Unit

The 24V DC power supply unit that drives the system uses either the centralized power supply method (use of only one power supply unit) or the decentralized power supply method (use of additional local power supply unit) to supply power to each unit.

At first, calculate the total current consumption value (sum total of current consumption values of all units '+' sum total of load current values of I/O devices).

After that, from the obtained calculation result, cable length, and conductor resistance, calculate the voltage drop value, and determine the voltage to be supplied to each unit.

If the voltage supplied to each unit is above the rated voltage (22.8V or more for the controller, 21.6V or more for the I/O unit), you can design the system using the centralized power supply method.

If the voltage supplied to a unit is out of the rated voltage range, connect a local power supply unit, and use the local power supply method.

### Designing of system using local power supply method



To use a local power supply unit, turn on the local power supply unit first, and then turn on the main power supply unit, or turn on these power supply units at the same time.  
If the main power supply unit is turned on first, the system may not operate properly.

In the following cases, connect a local power supply unit:


- The communication distance is too long, and voltage drop is too large.  
For this reason, it is not possible to supply the rated voltage to the I/O units.
- A 2-core cable is used for connection of the I/O unit (for the D-G line only).
- The main power supply unit and the local power supply unit should be the small capacity type.
- An I/O device that generates a large noise should be used.

**<Reference value>**

Conductor cross section (mm <sup>2</sup> )	Conductor resistance (Ω/m)
0.3	Approx. 0.065
0.5	Approx. 0.040
0.75	Approx. 0.025
1.25	Approx. 0.015
2.0	Approx. 0.010

Notes: 1) The conductor resistance values shown in the above table are reference values.  
To determine the conductor resistance values for the actual cables, contact the cable manufacturer.  
2) The conductor cross section of the exclusive 4-core flat cable should be 0.5mm<sup>2</sup>.


To determine whether a local power supply unit is necessary, refer to the flowchart shown on the next page.



# Connection of DC 2-Wire Output Device to Input Unit

## CAUTION

If you have to connect a DC 2-wire output device to an input unit, recommend our product. If a product manufactured by another company is used, the conditions should be checked by following the procedure shown in the following flowchart. This is because the output device of another company does not fit our input unit.



**Example: Connection of DC 2-wire sensor**

- To connect DC 2-wire proximity sensor **GX-12MU** to 8-channel connector input unit **SL-VT8J**

$V_{THON}$  : **SL-VT8J** ON voltage = 17V or more (between +24V and data input)  
 $V_{THOFF}$  : **SL-VT8J** OFF voltage = 4V or less (between +24V and data input)  
 $R_1$  : Input impedance of **SL-VT8J** = 3.3k $\Omega$   
 $V_A$  (residual voltage in ON mode) of **GX-12MU** = 3V or less  
 Specified operation voltage range of **GX-12MU** = 12 to 24V DC  $^{+100\%}_{-5\%}$  = 10.2 to 26.4V DC  
 Minimum load current of **GX-12MU** = 3mA  
 $A_1$  (leakage current) of **GX-12MU** = 0.8mA

**Check 1**

$21.6V - 17V = 4.6V \geq 3V$   
 $21.6V - 4V = 17.6V$  (in range of 10.2 to 26.4V)  
 Since the requirements of both formulas are satisfied, carry out checks 2 and 3.


**Check 2**

$$\frac{21.6V - V_A \text{ of DC 2-wire input device}}{R_1} \approx \frac{21.6V - 3V}{3.3k\Omega} = \frac{18.6V}{3.3k\Omega} \approx 5.64mA \geq 3mA$$

**Check 3**

$$\frac{V_{THOFF}}{R_1} = \frac{4V}{3.3k\Omega} \approx 1.21mA \geq 0.8mA$$

Since the requirements of Checks 2 and 3 are satisfied, the bleeder resistor is not necessary.



# Transmission Delay Time



Due to difference in communication protocols, the transmission delay time of the **S-LINK V** system differs from that of the conventional **S-LINK** system.

For transmission, there are fastest transmission time and the slowest transmission time. Since this product uses the serial transmission method, transmission will be carried out as shown in the following figure.

For a detailed description of the following controllers, refer to their respective user's manuals.

**SL-VGU1-C, SL-VGU1-D** : **SL-VGU1-C / SL-VGU1-D** User's Manual

**SL-VGU1-EC** : **SL-VGU1-EC** User's Manual


**SL-VGU1-485** : **SL-VGU1-485** User's Manual

**SL-VMEL-Q** : **SL-VMEL-Q** User's Manual

**SL-VFP7** : **SL-VFP7** User's Manual

## Response delay time

<In case of SL-VCU1>



### • Response delay of S-LINK V system


- Input response time (2 + 3 + 4 + 5)

$$\begin{aligned} \text{MIN.} &= 0.2 + \text{From Table 1} + \text{From Table 2} + 0.001 \text{ (ms)} \\ \text{MAX.} &= 0.2 + \text{From Table 1} + \text{From Table 2} + 0.001 \text{ (ms)} \end{aligned}$$

- Output response time (7 + 8 + 9 + 10)

$$\begin{aligned} \text{MIN.} &= 0.015 + \text{From Table 1} + \text{From Table 2} + 0.35 \text{ (ms)} \\ \text{MAX.} &= 0.015 + \text{From Table 1} + \text{From Table 2} + 0.35 \text{ (ms)} \end{aligned}$$

<In case of SL-VFP2, SL-VMEL-Q, SL-VPCI, SL-VVMES2>



• Response delay of S-LINK V system

- Input response time (2 + 3 + 4 + 5)

$$\begin{aligned} \text{MIN.} &= 0.2 + \text{From Table 1} + \text{From Table 2} + \text{From Table 2 (ms)} \\ \text{MAX.} &= 0.2 + \text{From Table 1} + \text{From Table 2} + \text{From Table 2 (ms)} \end{aligned}$$

- Output response time (7 + 8 + 9)

$$\begin{aligned} \text{MIN.} &= \text{From Table 2} + \text{From Table 2} + 0.35 \text{ (ms)} \\ \text{MAX.} &= \text{From Table 2} + \text{From Table 2} + 0.35 \text{ (ms)} \end{aligned}$$


<Table 1 Filtration time>

Filtration time (ms)					
A mode		B mode		C mode	
MIN.	MAX.	MIN.	MAX.	MIN.	MAX.
0.05	0.06	0.19	0.26	0.77	1.02

<Table 2 Refresh time, Internal memory max.1 refresh time>

Number of I/O control points	Refresh time, Internal memory max.1 refresh time (ms)					
	A mode		B mode		C mode	
	MIN.	MAX.	MIN.	MAX.	MIN.	MAX.
32		1.50		6.01		24.03
64		2.09		8.36		33.44
96		2.68		10.71		42.85
128		3.27		13.06		52.26
160		3.85		15.42		61.66
192		4.44		17.77		71.07
224		5.03		20.12		80.48
256		5.62		22.47		89.89
288		6.21		24.82		99.30
320		6.79		27.18		108.70
352		7.38		29.53		118.11
384		7.97		31.88		127.52
416		8.56		34.23		136.93
448		9.15		36.58		146.34
480		9.73		38.94		155.74
512		10.32		41.29		165.15
		0.29		1.18		4.70

## Operation at power-on




• **READY output delay time (1 + 2 + 3)**

1 (Depending on supplied power) + 2 (From Table 3) + 3 (0.5 ms)

<Table 3 Time required for transmission check at starting controller>

Number of I/O control points	Time required for transmission check at starting cotroller (ms)		
	A mode	B mode	C mode
32	69.5	134.3	422.1
64	82.6	186.8	632.2
96	100.4	258.1	917.5
128	123.0	348.3	1278.1
160	150.2	457.2	1713.9
192	182.2	585.0	2225.0
224	218.8	731.6	2811.4
256	260.2	897.0	3473.0
288	306.2	1081.2	4209.9
320	357.0	1284.3	5022.1
352	412.4	1506.1	5909.5
384	472.6	1746.8	6872.2
416	537.5	2006.3	7910.1
448	607.1	2284.6	9023.4
480	681.3	2581.7	10211.8
512	760.3	2897.6	11475.6

## Error signal outputting delay time



• **Error output delay time (1 + 2)**

1 (From Table 4 or 5) + 2 (0.5ms)


<Table 4 Time required for error check (errors 3, 4, and 5)>

Number of I/O control points	Time required for error check (errors 3, 4, and 5) (ms)		
	A mode	B mode	C mode
32	43.5	174.0	695.8
64	93.4	373.6	1494.3
96	162.1	648.4	2593.8
128	249.6	998.6	3994.4
160	356.0	1424.0	5696.0
192	481.2	1924.7	7698.7
224	625.2	2500.6	10002.4
256	788.0	3151.8	12607.2
288	969.6	3878.3	15513.1
320	1170.0	4680.0	18720.0
352	1389.2	5557.0	22228.0
384	1627.3	6509.2	26037.0
416	1884.2	7536.8	30147.1
448	2159.9	8639.6	34558.2
480	2454.4	9817.6	39270.4
512	2767.7	11070.9	44283.6

<Table 5 Time required for error check (errors 1 and 2)>

Time required for error check (errors 1 and 2) (ms)		
A mode	B mode	C mode
1.33	5.32	21.28

System setting time



<Table 6 Time required for system setting>

Number of I/O control points	Time required for system setting (ms)		
	A mode	B mode	C mode
32	142.7	427.0	1593.0
64	235.3	797.4	3074.8
96	342.0	1224.3	4782.3
128	462.8	1707.7	6715.7
160	597.8	2247.5	8874.9
192	746.8	2843.7	11259.8
224	910.0	3496.4	13870.6
256	1087.3	4205.5	16707.1
288	1278.7	4971.1	19769.5
320	1484.2	5793.1	23057.6
352	1703.8	6671.6	26571.5
384	1937.6	7606.5	30311.2
416	2185.4	8597.9	34276.7
448	2447.4	9645.7	38468.0
480	2723.4	10750.0	42885.1
512	3013.6	11910.7	47528.0

<Table 7 Time required for refreshing stop>

Number of I/O control points	Time required for refreshing stop (ms)		
	A mode	B mode	C mode
32	15.7	62.8	251.3
64	37.7	150.9	603.5
96	69.1	276.5	1106.2
128	110.0	439.9	1759.4
160	160.2	640.8	2563.2
192	219.8	879.4	3517.5
224	288.9	1155.6	4622.3
256	367.4	1469.4	5877.7
288	455.2	1820.9	7283.6
320	552.5	2210.0	8840.0
352	659.2	2636.7	10546.9
384	775.3	3101.1	12404.4
416	900.8	3603.1	14412.4
448	1035.7	4142.7	16570.9
480	1180.0	4720.0	18880.0
512	1333.7	5334.9	21339.6

<Table 8 Time required for transmission check>

Number of I/O control points	Time required for transmission check (ms)		
	A mode	B mode	C mode
32	69.5	134.3	422.1
64	82.6	186.8	632.2
96	100.4	258.1	917.5
128	123.0	348.3	1278.1
160	150.2	457.2	1713.9
192	182.2	585.0	2225.0
224	218.8	731.6	2811.4
256	260.2	897.0	3473.0
288	306.2	1081.2	4209.9
320	357.0	1284.3	5022.1
352	412.4	1506.1	5909.5
384	472.6	1746.8	6872.2
416	537.5	2006.3	7910.1
448	607.1	2284.6	9023.4
480	681.3	2581.7	10211.8
512	760.3	2897.6	11475.6

# Selection of Output Holding Function for Output Unit

Output units are equipped with the output holding function.


If a transmission error is detected, the output holding function will be activated to hold the output condition detected just before occurrence of the error.

## Output holding function setting method

### CAUTION

Before setting the output holding function, fully understand the function, and check the operation condition of the output-to device. If this function is not set correctly, a serious problem may occur.

The output hold setting switch is at the end of the address setting switch panel. Set the 'HOLD' switch to ON / OFF to set the output holding function.




Output hold setting switch	Operation in normal transmission mode	Operation in transmission error mode
OFF	Output operation	Turning off of output
ON		Holding of output condition detected just before occurrence of error

### <If output module is SL-VMP8 or SL-VMP16>

If the line between HOLD (pin No. 29) and ADD. (COM.) (pin No. 28) is opened, the output holding function will be canceled ('HOLD OFF' mode).

If this line is shorted, the output holding function will be set ('HOLD ON' mode).



- Before delivery, the output hold setting switch is set to OFF (the 'HOLD OFF') mode is set.
- If it takes a long time to turn off the power of the controller, the output holding function may not operate properly.



The **S-LINK V** system uses one controller to send up to 512 points (512 points × 2 for **SL-VVMES2**) (256 nodes) of signal in the serial transmission mode.  
To clarify the sent-from and sent-to units, assign a number to each I/O device.  
These numbers are referred to as 'addresses.'  
To properly operate the **S-LINK V** system, correctly set the addresses.

## Setting of PLC I/O connector numbers



### CAUTION

Be careful not to set the same address for the PLC I/O connectors.  
Considering the set connector numbers, set the optimum I/O control points for the controller.  
For the address setting examples, refer to page 180.

Using the connector number setting switches, you can set a connector number consisting of 32 points for each PLC I/O connector. (The same connector number setting method can be used for any types of PLC I/O connectors.)  
For the connector number setting examples, refer to page 73.

## Setting of I/O unit addresses



### CAUTION

- Be careful not to set the same address for the **S-LINK V** I/O units.
- Set the addresses of **S-LINK V** I/O units while observing the I/O area set by the PLC I/O connectors.  
Note that any address exceeding the I/O control points cannot be set.


Using the address setting switches, assign addresses to I/O units.  
For each I/O unit, the assigned address will be the first number of the address, and the rest of the address will be set depending on the specified number of I/O points.  
For a detailed description, refer to page 74.

- **When using the picking switch SL-VPK0**□

To assign the address, use the address setting remote controller **SL-VAR1** and send it to the **SL-VPK0**□.  
For a detailed description, refer to the User's Manual that came with the address setting remote controller **SL-VAR1**.

## Example: Address setting

- If PLC I/O connector is connected to the A1SX42 (input module) and the A1SY42 (output module) manufactured by Mitsubishi Electric Corporation:



PLC I/O connector		I/O	PLC I/O connector model	Address
No.	Connector No.			
1	0	Input	<b>SL-VS3</b>	0 to 31
2	1		<b>SL-VS3</b>	32 to 63
3	2	Output	<b>SL-VP3</b>	64 to 95
4	3		<b>SL-VP3</b>	96 to 127

	'F side of A1SX42' and <b>SL-VS3 1</b>				'L side of A1SX42' and <b>SL-VS3 2</b>			
	Signal name	Address	Signal name	Address	Signal name	Address	Signal name	Address
Input A1SX42	X00	0	X10	16	X20	32	X30	48
	X01	1	X11	17	X21	33	X31	49
	X02	2	X12	18	X22	34	X32	50
	X03	3	X13	19	X23	35	X33	51
	X04	4	X14	20	X24	36	X34	52
	X05	5	X15	21	X25	37	X35	53
	X06	6	X16	22	X26	38	X36	54
	X07	7	X17	23	X27	39	X37	55
	X08	8	X18	24	X28	40	X38	56
	X09	9	X19	25	X29	41	X39	57
	X0A	10	X1A	26	X2A	42	X3A	58
	X0B	11	X1B	27	X2B	43	X3B	59
	X0C	12	X1C	28	X2C	44	X3C	60
	X0D	13	X1D	29	X2D	45	X3D	61
	X0E	14	X1E	30	X2E	46	X3E	62
	X0F	15	X1F	31	X2F	47	X3F	63

	'F side of A1SY42' and <b>SL-VP3 3</b>				'L side of A1SY42' and <b>SL-VP3 4</b>			
	Signal name	Address	Signal name	Address	Signal name	Address	Signal name	Address
Output A1SY42	Y40	64	Y50	80	Y60	96	Y70	112
	Y41	65	Y51	81	Y61	97	Y71	113
	Y42	66	Y52	82	Y62	98	Y72	114
	Y43	67	Y53	83	Y63	99	Y73	115
	Y44	68	Y54	84	Y64	100	Y74	116
	Y45	69	Y55	85	Y65	101	Y75	117
	Y46	70	Y56	86	Y66	102	Y76	118
	Y47	71	Y57	87	Y67	103	Y77	119
	Y48	72	Y58	88	Y68	104	Y78	120
	Y49	73	Y59	89	Y69	105	Y79	121
	Y4A	74	Y5A	90	Y6A	106	Y7A	122
	Y4B	75	Y5B	91	Y6B	107	Y7B	123
	Y4C	76	Y5C	92	Y6C	108	Y7C	124
	Y4D	77	Y5D	93	Y6D	109	Y7D	125
	Y4E	78	Y5E	94	Y6E	110	Y7E	126
	Y4F	79	Y5F	95	Y6F	111	Y7F	127

To set addresses as shown in the above table, set the I/O control points of the controller to 128 points.

If the control points is set to under 128 points, transmission with a unit set to 128 points of I/O points or more will not be possible.

For a detailed description, refer to page 180.

# Chapter 2

## Wiring




# Flowchart

To wire each unit, follow the procedure shown in the following flowchart:

**⚠ DANGER**

Before disconnecting or reconnecting a cable or connector, be sure to turn off the power.



## Connector hook-up work

This section describes the knowledge and setup method to be learned before starting connector hook-up work.



### CAUTION

- If a connector is not hooked-up correctly, the **S-LINK V** system will not work.
- If a connector is once hooked-up, do not use the connector again.  
This is because the performance of a used connector may be deteriorated.
- Before starting hook-up work, be sure to turn off the power.
- When you disconnect or reconnect a connector, be sure to grab the connector main body.  
If you pull the cable to disconnect or reconnect a connector, the cable may be disconnected.
- Do not hook-up any connector in a cold weather, such as outdoors in winter.


## Cutting of exclusive 4-core flat cable

Cut the exclusive 4-core flat cable so that the end face of the cable can be orthogonal.



### CAUTION

- Cut the exclusive 4-core flat cable so that the end face of the cable can be orthogonal.  
If the end face is not orthogonal, the connector may not be hooked-up properly.
- Do not peel the sheath of the exclusive 4-core flat cable.
- After cutting the exclusive 4-core flat cable, check that the cores are not in contact with each other.



**Good**

**Not good**


**Not good**

**Not good**


## How to use exclusive hook-up pliers (SL-JPS, SL-JPC, SL-JPE)

### CAUTION


If there is a clearance between the guide of the exclusive hook-up pliers and the connector, the connector may not be hooked-up properly.




1. Adjust the protrusion of the connector to the guides of the hook-up pliers.



2. Slide the connector to the guides till it stops, and check if there is no clearance between them.



3. Adjust the exclusive hook-up pliers so that the pliers can be orthogonal to the cable. After that, press the connector until it clicks.



# Hook-up of Connector

## Hook-up method of SL-JK connector for cable end and SL-JK1 connector for 'T'- branch


### CAUTION

- Before starting the connector hook-up work, fully understand the hook-up work and the setup work (See pages 37, 38.)
- Use the exclusive 4-core flat cable.

1. Prepare a set of **SL-JK** or **SL-JK1** connector housing and the cover.

**SL-JK** hook-up connector for cable end: Light blue

**SL-JK1** hook-up connector for 'T' - branch: Blue




A hook-up connector consists of a housing and a cover. Do not attach a housing to a cover having different color.

2. Hook-up the main / branch line flat cable to the cover. Fix the cable using 4 claws.


### CAUTION

Fix the brown (+24V) line of the exclusive 4-core flat cable to the recognition mark side of the cover (▲ mark side on the top or the +24V indication line on the side.)

#### <SL-JK connector for cable end>




#### <SL-JK1 cable for 'T' - branch>




There are recognition marks on the top (▲ mark) and the side (+24V indication line) of the cover so that the miswiring can be prevented.


3. Place the housing on the cover, and then lightly press the cover to temporarily fix it.



- If the housing is placed in a wrong direction, it will not be engaged with the cover.
- If the connector is attached to the cable end, check the cable condition through the confirmation window. The cable should be in contact with the back of the connector.




4. Hook-up the connector using the exclusive hook-up pliers (SL-JPS).  
 (For the caution regarding the exclusive hook-up pliers and the hook-up procedure, refer to pages 37, 38.)



5. Check the hook-up condition of the connector.

<Check items>

- Check that the claws of the housing are properly pressed to the cover.
- If the connector is attached to the cable end, check the condition of the main / branch line flat cable through the confirmation window. The cable should be in contact with the back of the connector.



## Hook-up method of SL-J1A connector for 'T' - branch and SL-J3A connector for cable extension

### **CAUTION**

- Before starting the connector hook-up work, fully understand the hook-up work and the setup work (See pages 37, 38.)
- Use the exclusive 4-core flat cable.


**1.** Prepare a set of **SL-J1A** or **SL-J3A** connector covers (A) and (B), and housing.

**SL-J1A** hook-up connector for 'T' - branch: Gray


**SL-J3A** hook-up connector for cable extension: Black

<SL-J1A>


Cover (A)



Cover (B)




Housing




<SL-J3A>


Cover (A)





Cover (B)



Housing




**2.** Touch the end face of the flat cable to cover (A), and then fix the cable using the cable stopper.




Touch the cable to the cover,  
and then fix the cable.

3. Place the housing on cover (A), and then lightly press the cover to temporarily fix it.




- If the housing is placed in a wrong direction, it will not be engaged with the cover.
- Check the cable condition through the confirmation window. The cable should be in contact with the back of the connector.




4. Place another flat cable on cover (B) (for the SL-J3A, touch the cable to the wall), and then fix cable using the cable stopper.

<SL-J1A>



<SL-J3A>


Touch the cable to the cover, and then fix the cable.



- Place the temporarily fixed housing (see step 3) on cover ②, and then lightly press the housing to temporarily fix it.


**CAUTION**

Before temporarily fixing the housing, be sure to check that the same color lines of both cables are aligned with each other.



**NOTE** Check the cable condition through the confirmation window. The cable should be in contact with the back of the connector.


- Hook-up the connector using the exclusive hook-up pliers (SL-JPS).  
(For the caution regarding the exclusive hook-up pliers and the hook-up procedure, refer to pages 37, 38.)



- Check the hooked-up condition.

**<Check items>**

- Check that the claws are properly pressed.
- Check the condition of the flat cable through the confirmation window. The cable should be in contact with the back of the connector.






## Hook-up method of SL-CP1, SL-CP2, and SL-CP3 snap male connectors and SL-CJ1 and SL-CJ2 snap female connectors


### CAUTION

- Before starting the snap male / female connector hook-up work, fully understand the hook-up work and the setup work (See pages 37, 38 and 44, 45).
- Do not use the single-core cable, but use the stranded cable.
- Use the cable having a vinyl chloride or soft polyethylene insulator.  
Do not use the cable if the insulator is irradiated or cross-linked (hard type).
- Do not use the cable if the diameter is not specified in the following table.



**1.** For the cable, select a connector applicable for the conductor cross section and the lead wire diameter of the cable.

#### <Snap male connector>

Applicable connector	Color	Conductor cross section	Lead wire diameter	Allowable overcurrent	Allowable voltage
 <b>SL-CP1</b>	White	0.08 to 0.2mm <sup>2</sup> (AWG28 to AWG24)	ø0.7 to ø1.2mm	1A	30V DC
 <b>SL-CP2</b>	Black	0.3mm <sup>2</sup> (AWG22)	ø1.1 to ø1.6mm	2A	
 <b>SL-CP3</b>	Bluish green	0.5mm <sup>2</sup> (AWG20)	ø1.7 to ø2.5mm	3A	



#### <Snap female connector>

Applicable connector	Color	Conductor cross section	Lead wire diameter	Allowable overcurrent	Allowable voltage
 <b>SL-CJ1</b>	White	0.08 to 0.2mm <sup>2</sup> (AWG28 to AWG24)	ø0.7 to ø1.2mm	1A	30V DC
 <b>SL-CJ2</b>	Black	0.3mm <sup>2</sup> (AWG22)	ø1.1 to ø1.6mm	2A	

2. Peel the sheath of the cable.



**CAUTION**

If it is not necessary to peel the sheaths of the lead wires.


3. Insert the lead wires (4 wires) into the connector holes until the wire ends come in contact with the connector wall.

**CAUTION**

For the lead wire insertion positions, refer to the following figure. Miswiring may cause malfunction or damage of the system.

Connector terminal arrangement (for connection to connector I/O unit):

	Connection to input unit: 1 : +24V 2 : 0V 3 : Input 4 : Not connected	Connection to output unit: 1 : +24V 2 : 0V 3 : Not connected 4 : Output
--	-----------------------------------------------------------------------------------	-------------------------------------------------------------------------------------




4. Hook-up the cable using the exclusive hook-up pliers (SL-JPC or SL-JPE).  
 (For the caution regarding the exclusive hook-up pliers and the hook-up procedure, refer to pages 37, 38.)

5. Check the hooked-up condition.

<Check items>

- Check that the claws are properly pressed.
- Check that each partition is not broken.
- Check the condition of the cable through the confirmation window. The cable should be in contact with the connector wall.



## Connection to Terminal Block

### ⚠ WARNING

Before starting the wiring work, be sure to turn off the power. If the power is not turned off, the system may be shorted or damaged, and you may get an electric shock.

### ⚠ CAUTION

Correctly connect wires to the terminal block. Miswiring may cause malfunction or damage of the system.

1. Hook-up the crimp-style terminal to the cable.
2. The crimp-style terminals having insulating sheath for copper wires are recommended.
3. For the **SL-VTB□4**, use the general crimp-style terminals for M3. The dimensions of the crimp-style terminals are not restricted.

#### <Applicable crimp-style terminals>

(Unit: mm)


Y-shaped terminal	Round terminal

Recommended crimp-style terminals (manufactured by J.S.T Mfg Co., Ltd.):  
 Round crimp-style terminal with vinyl insulator (V2-S3.3)  
 Round crimp-style terminal with nylon insulator (N2-S3.3)  
 Y-shaped crimp-style terminal with vinyl insulator (V1.25-B3A, V2-N3A)

4. Check the connect-to terminals and the cable, and then connect the cable using a screwdriver.



Tightening torque: 0.29 to 0.49N·m for controller  
 0.5N·m or less for I/O terminal  
 The terminal block is separated into two. Connect wires to the lower terminal block first.



## Extension of Main / Branch Line Cable

### **CAUTION**

- If you do not use the exclusive 4-core flat cable, be sure to use the 4-core VCTF cable (non-shielded) having 0.3 to 2.0mm<sup>2</sup> conductor cross section. In addition, if you connect cables of different types to each other, be sure to select cables having the same cross section. If you connect cables having different cross sections to each other, abnormal communication signals may be output, and abnormal operation of the system may be caused.
- The cables commercially available have different performances. Before using these cables, be sure to check operation.

Note: The VCTF cord is the vinyl cabtyre cord that conforms to the requirements of JIS C 3306 'Polyvinyl chloride insulated flexible cords.'

### Extension of exclusive 4-core flat cables


Hook-up the cables using the **SL-J3A** hook-up connector for cable extension to extend the cable. (For a detailed description of the hook-up method, refer to pages 37, 38 and 41 to 43.)

### Extension of cable excluding exclusive 4-core flat cables

Use a connector or junction terminal block commercially available to extend the cable.

### Extension of cable to I/O device

Use the snap male connector (**SL-CP1**, **SL-CP2**, or **SL-CP3**) and the snap female connector (**SL-CJ1** or **SL-CJ2**) to extend the cable to the I/O device.



The snap male connector and the snap female connector cannot be connected to each other if they are in a wrong direction. To connect these connectors, be sure to check the terminal number marked on each connector.

# Installation

## Installation of each unit

There are 3 unit installation methods.

Considering the installation conditions, select an optimum installation method.

- Installation using screws
- Installation on 35mm width DIN rail
- Installation on board (for **SL-VMC1** and **SL-VM□ / VMP□** only)

### CAUTION

Regarding the ambient conditions, check the following items, and then install each unit:

- Check that the address setting switches, etc. are valid.
- Check that covers can be opened or closed.
- Check that a heat radiation space (10mm or more) can be secured between the unit and the wall.
- Check that indicators are visible.
- Check that cables can be disconnected and reconnected.


#### • Installation using screws

Install each unit using M4 pan head screws.

For the screw tightening torque, refer to the product specifications (**Chapter 4**).


#### • Installation on 35mm width DIN rail

1. Preliminarily attach the DIN rail stopper to the unit.
2. Attach the back of the installed stopper to the 35mm width DIN rail.
3. Press the front of the unit to the rail so that the front of the installed stopper can be attached to the 35mm width DIN rail.



#### • Removal from 35mm width DIN rail


Insert a flathead screwdriver into the DIN rail stopper, and then pull out the stopper until the stopper can be locked.



Prepare M4 pan head screws and 35mm width DIN rail separately.


#### • Installation on board (for **SL-VMC1** and **SL-VM□ / VMP□** only)

Solder pins and terminals at 260°C or less within 10 seconds.




● **To install the picking switch SL-VPK0□ on the pipe:**

1. Remove the socket head hex bolt used for fixing the holder [M6 (length 15 mm)].  
When doing this, remove the pipe mounting holder as well.
2. Align the connecting piece of the product with the connecting piece of the pipe mounting holder so that the pipe is gripped between these pieces.  
You can align the connecting pieces easily by shifting them up and down during alignment work.
3. Install the product using the socket head hex bolt for fixing the holder that you removed in step 1.



● **To attach a shutter on the picking switch for shutter, SL-VPK02:**

- Attach the shutter to the movable arm on this product.  
Use the accessory arm plate, plate-fixing screws [M4 truss head screws (length: 12mm)], and plate-fixing spring washers to attach the shutter.



# Construction

## Power Supply


### DANGER

Observe the following items to connect a power supply unit:

- Select a power supply unit having short-circuit protective function (fuse, etc.).
- The power of the **S-LINK V** system passes through the inside of each unit and is then supplied to the main cable or I/O device side. However, the short-circuit protective function is not adopted. For this reason, adopt a short-circuit protective function, such as a fuse, for the power supply circuit.
- Before starting the wiring work, be sure to turn off the power. If the power is not turned off, the system may be shorted or damaged, and you may get an electric shock.
- Take care that wrong wiring will damage the product.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- Do not use during the initial transient time after the power supply is switched on. Note that if the READY output signal of the **SL-VCU1** or **SL-VMC1** is off, or if the controller, control board, control module, or handy monitor is in the BUSY mode (in the power-on or system setting), transmission will not be possible.
- In this section, the main power supply unit means the power supply unit that activates the communication and connection units of the **S-LINK V** system. In addition, for the control units (PLC, personal computer, etc.) to which the **S-LINK V** units are connected, separate power supply units that conform to the specifications of the control units are needed. For a detailed description, refer to the instruction manual of each unit.
- If it takes a long time to turn on or off the power, use a timer relay so that the power can be supplied after stabilization.

## Power supply to system

Supply the stabilized power (24V DC  $\pm 10\%$ ) to the system.



- For the I/O devices to be controlled by the **S-LINK V** system, separately connect local power supply units considering the installation conditions and power supply conditions.
- For the I/O units, the supply voltage should be 24V DC  $\pm 10\%$ . Refer to pages 100.

# Connection of Each Unit


## Connection of controller

**NOTE**

- For a detailed description of the following controllers, refer to their respective user's manuals.
  - SL-VGU1-C, SL-VGU1-D** : **SL-VGU1-C / SL-VGU1-D** User's Manual
  - SL-VGU1-EC** : **SL-VGU1-EC** User's Manual
  - SL-VGU1-485** : **SL-VGU1-485** User's Manual
  - SL-VMEL-Q** : **SL-VMEL-Q** User's Manual
  - SL-VFP7** : **SL-VFP7** User's Manual
- For a detailed description of the control module, refer to the '**S-LINK V Control Module Product Specifications.**'
- For a detailed description of the handy monitor, refer to the '**S-LINK V Handy Monitor Instruction Manual.**'

1. Connect the power supply unit and the F.G. terminal to the controller.  
(For the caution regarding connection of the power supply unit, refer to page 50.)
2. Connect the control cable and the transmission cable to the controller.

	Terminal No.	Cable color	Terminal name
Control cable	1	Black	G
	2	White	D
	3	Blue	0V
	4	Brown	+24V
Transmission cable	9	Black	G
	10	White	D
	11	Blue	0V
	12	Brown	+24V




**NOTE** Before connection, check the cable color and the terminal number for correct connection.

3. Connect the error output cable to the controller, if necessary.

Terminal No.	Output
5	ERROR OUT 1
6	ERROR OUT 2
7	READY
8	COM.

Note: The COM. (terminal No.8) and 24V (terminal No.16) terminals are connected internally.  
For a detailed description, refer to page 78.



## Connection of bus direct-connection type controller and control board

1. Connect the power supply unit and the F.G. terminal to the control board.
2. Connect the exclusive 4-core flat cable (0.5mm<sup>2</sup>) or 4-core VCTF cable (non-shielded) having conductor cross section of 0.3 to 2.0mm<sup>2</sup> to the control board.


Note: The VCTF cord is the vinyl cable cord that conforms to the requirements of JIS C 3306 'Polyvinyl chloride insulated flexible cords.'

### <SL-VFP2,SL-VFP7, SL-VMEL-Q>


Pin No.	Terminal name	Remarks
1	F.G.	Frame ground
2	+24V	External power input
3	0V	
4	+24V	Brown
5	0V	Blue
6	D	White
7	G	Black

- Applicable terminal block connector  
**SL-VFP2, SL-VFP7:** ECH381RM-07P (with flange)  
 (Manufactured by DINKLE ENTERPRISE CO., LTD.)  
**SL-VMEL-Q:** 2ESDVM-07P (with flange)  
 (Manufactured by DINKLE ENTERPRISE CO., LTD.)

### <SL-VFP2> <SL-VFP7>



### <SL-VMEL-Q>




### <SL-VPCI>

Terminal No.	Terminal name	Remarks
1	G	Black
2	D	White
3	0V	Blue
4	+24V	Brown
5	0V	External power input
6	+24V	
7	F.G.	Frame ground

- Applicable terminal block connector  
 MSTB 2517-STF-5.08 (with flange)  
 (Manufactured by Phoenix Contact)

### <SL-VPCI>




### <SL-VVMES2>

Terminal No.	Terminal name	Remarks
1	F.G.	Frame ground
2	+24V	External power input
3	0V	
4	+24V	Brown
5	0V	Blue
6	D	White
7	G	Black

- Applicable terminal block connector  
 MSTB 2517-STF-5.08 (with flange)  
 (Manufactured by Phoenix Contact)

### <SL-VVMES2>



Before connection, check the cable color and the terminal number for correct connection.


## Connection of PLC I/O Connector

To connect the system to the PLC, use the PLC I/O connector applicable for the I/O module of each manufacturer.

1. Insert the PLC I/O connector into the input and output modules, respectively.


### CAUTION

Turn off the power, and then insert the PLC input and output connectors all the way into the PLC (so that the connectors cannot be disconnected).  
If a connector is not inserted all the way, the connector may cause imperfect contact, and the system may malfunction.




- Connect the PLC input connector to the input module of the PLC, and the PLC output connector to the output module of the PLC.
- Be sure to check the manufacturer (model number) of the PLC, and confirm that the PLC I/O connector is applicable for the PLC. For a detailed description, refer to pages 159 to 160.

2. Using screws, fix the PLC input and output connectors to the PLC input and output modules.




(The MIL connectors (SL-VS1 / VP1, SL-VS6 / VP6, and SL-VS8 / VP8) are designed for the I/O modules manufactured by Panasonic Industrial Devices SUNX Co., Ltd., Hitachi, Ltd., Toshiba Machine Co., Ltd., or Rockwell Automation Japan (Allen Bradley), and these connectors do not have any screws. This is because the PLC I/O modules manufactured by these companies are equipped with the lock function.)

- 3.** Using the connector link cable, connect the PLC input and output connectors to each other. Each PLC I/O connector has 2 connector terminals. The connector link cable can be connected to either terminal. Be sure to attach the connector cap to the unused connector terminal at the end. (To select a connector link cable, refer to page 176.)




For each controller, up to 16 PLC I/O connectors (16 connectors × 32 points = 512 points) can be connected.

- 4.** Using the control cable, connect the controller to the PLC I/O connectors.




- One control cable can connect up to 8 PLC I/O connectors to the controller.
- To connect 9 or more PLC I/O connectors, use 2 control cables. When connecting the control cables to the controller use crimp-style terminals. In this case, overlap the crimp-style terminals of both cables, and connect them to the terminals.



## Connection of I/O unit


To connect an I/O unit to the exclusive 4-core flat cable, select the optimum connection method depending on the specifications of the I/O unit cable.

- If the I/O unit cable is a flat cable having conductor cross section of 0.5mm<sup>2</sup>:
  - Use the **SL-J1A** or **SL-J3A** hook-up connector for connection.  
(For the hook-up method, refer to pages 37, 38 and 41 to 43.)



Before connecting a hook-up connector, check that the wire colors of both cables are in the same order.

- If the I/O unit is connected to the terminal block:
  - Connect the cable to the terminal block.  
Attach the crimp-style terminals to the exclusive 4-core flat cable.  
After that, check the wire colors and the terminal names, and then tighten the screws of the terminal block.  
(Both the 'T' - branch and the crossover wiring are possible.)  
For the connection method, refer to page 46.  
For the terminal arrangement, refer to the drawings shown on pages 105 and 109.



Connection of I/O device

**CAUTION**

Connect input device to the **SL-VT□E**, and connect output device to the **SL-VTP□E**. If it is connected wrong, it may cause breakage.

The I/O device connection method depends on the connection-to unit.

- To connect an I/O device to the **SL-VT□J** and **SL-VTP□J**


1. Attach the **SL-CP1**, **SL-CP2**, or **SL-CP3** snap male connector to the cable distributed from the I/O device. (For the hook-up method, refer to pages 37, 38, and 44, 45.)

Pin No.	Input device	Output device
1		+24V
2		0V
3	Input	No connection
4	No connection	Output

2. Connect the snap connector to the connector I/O unit.

**CAUTION**


Insert the snap male connector all the way into the slot. If the connector is not inserted all the way into the slot, the connector may cause imperfect contact, and the system may malfunction.



- To connect an I/O device to the **SL-VT□E** and **SL-VTP□E**
- Connect an e-CON conforming connector (4P type) that is launched by various manufactures to the cable distributed from the I/O device. (For the instruction of e-CON spec. based connector, contact manufactures of e-CON conforming connector.)


Pin No.	Input device	Output device
1		+24V
2		N.C.
3		0V
4	Input	Output

Note: Make sure that the pin configuration is different between **SL-VT□J** and **SL-VT□E**.



- To connect an I/O device to a 16-channel MIL connector I/O unit:

1. Connect the cable equipped with MIL connector to the input or output device.
2. Connect the cable equipped with MIL connector to the I/O unit.



- To connect an I/O device to an I/O terminal:

1. Hook-up the crimp-style terminals to the input or output device cable.  
(For a detailed description, refer to page 46.)
2. Connect the I/O device cable to the I/O terminal using a screwdriver.

## Connection of main line cable to end unit

Connect the **SL-VEU** end unit as follows:

- **Connect the end unit to the end of the main line.**  
(For the hook-up method, refer to pages 37, 38 and 41 to 43.)
- **If a branch line length exceeds 80% of the maximum communication distance, connect an end unit to the end of the branch line.**  
(For a detailed description, refer to page 18.)

## Connection of local power supply unit

Considering various conditions (total current consumption, voltage drop, etc.), if you judge that a local power supply unit is necessary for the **S-LINK V** system, connect a local power supply unit.

### **DANGER**


Observe the following items to connect a power supply unit:

- Select a power supply unit having short-circuit protective function (fuse, etc.).
- The power of the **S-LINK V** system passes through the inside of each unit and is then supplied to the main cable or I/O device side.  
However, the short-circuit protective function is not adopted for this power supply circuit.
- Do not connect the main power supply to the local power supply, or connect two local power supplies.
- Before starting the wiring work, be sure to turn off the power. If the power is not turned off, the system may be shorted or damaged, and you may get an electric shock.
- Take care that wrong wiring will damage the product.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- Do not use during the initial transient time after the power supply is switched on.
- For the control units (PLC, personal computer, etc.) to which the **S-LINK V** units are connected, separate power supply units that conform to the specifications of the control units are needed. For a detailed description, refer to the instruction manual of each unit.
- If it takes a long time to turn on or off the power, use a timer relay so that the power can be supplied after stabilization.


## Local power supply to system

Supply local power to the **S-LINK V** system from the I/O terminal or a commercial junction terminal block. Be sure to supply stabilized power (24V DC  $\pm 10\%$ ).

### <To supply local power to I/O terminal>



### <To supply local power to main line>




## Installation method of batteries

The address setting remote controller **SL-VAR1** requires two AAA alkaline batteries. For a detailed description to install the batteries, refer to following procedure.


### CAUTION

Be sure to turn OFF the power of the product before installing or replacing the batteries.


1. Remove the body from the silicon cover.




2. Slide the battery cover on the back side of the body to remove the cover.




3. Pay attention to the "+" and "-" directions, and install the AAA alkaline batteries into the battery box.



4. Slide the battery cover onto the body to attach the cover.



5. Turn over the body and insert it into the silicon cover.



---

# MEMO


# **Chapter 3**


# **Starting System**

---

---

# Flowchart





Note: If both the main and local power supply units are connected, be sure to turn on the local power supply unit first.

# Wiring Check

## Check before Starting

Before turning on the power of the **S-LINK V** system, be sure to check the following items:

- Check the wiring conditions of the controller and the control board.
- Check the PLC I/O connectors.
- Check the cable for short-circuit.
- Check the connected condition of the end unit.

## Check of wiring conditions of controller and control board



- For a detailed description of the following controllers, refer to their respective user's manuals.  
**SL-VGU1-C, SL-VGU1-D** : **SL-VGU1-C / SL-VGU1-D** User's Manual  
**SL-VGU1-EC** : **SL-VGU1-EC** User's Manual  
**SL-VGU1-485** : **SL-VGU1-485** User's Manual  
**SL-VMEL-Q** : **SL-VMEL-Q** User's Manual  
**SL-VFP7** : **SL-VFP7** User's Manual
- For a detailed description of the control module, refer to the '**S-LINK V Control Module Product Specifications.**'
- For a detailed description of the handy monitor, refer to the '**S-LINK V Handy Monitor Instruction Manual.**'

Visually check the terminals and connection cables (connection-to units) of the controller and the control board.

### <SL-VCU1>

Pin No.	Terminal name	Connected to	
1	G (BK)	Black	Control cable
2	D (WH)	White	
3	0V (BU)	Blue	
4	+24V (BN)	Brown	
5	ERROR OUT 1	External control unit	
6	ERROR OUT 2		
7	READY		
8	COM.		
9	G (BK)	Black	Transmission cable
10	D (WH)	White	
11	0V (BU)	Blue	
12	+24V (BN)	Brown	
13	F.G.	Controller power supply unit	
14	F.G.		
15	0V		
16	+24V		

### <SL-VPCI>

Pin No.	Terminal name	Connected to	
1	G	Black	Transmission cable
2	D	White	
3	0V	Blue	
4	+24V	Brown	
5	0V	External power input	
6	+24V		
7	F.G.	Frame ground	

### <SL-VVMES2>

Pin No.	Terminal name	Connected to	
1	F.G.	Frame ground	
2	+24V	External power input	
3	0V		
4	+24V	Brown	Transmission cable
5	0V	Blue	
6	D	White	
7	G	Black	

### <SL-VFP2,SL-VFP7,SL-VMEL-Q>

Pin No.	Terminal name	Connected to	
1	F.G.	Frame ground	
2	+24V	External power input	
3	0V		
4	+24V	Brown	Transmission cable
5	0V	Blue	
6	D	White	
7	G	Black	

## Check of PLC I/O connectors

Check each PLC I/O connector for the following items:

- Check that the PLC I/O connector is applicable for the I/O module manufactured by the PLC manufacturer.
- Check that a PLC input connector is connected to the PLC input module, and a PLC output connector to the PLC output module.
- Check that the PLC I/O connector numbers are correctly set.
- Check that a connector link cable is used for connection of the PLC input and output connectors to each other.
- Check that a connector cap is attached to the unused PLC I/O connector terminal at the end.
- Check that a control cable is used for connection of PLC I/O connectors to the controller.
- Check that the number of PLC I/O connectors connected to each control cable is 8 connectors or less.

## Check of cable for short-circuit




### CAUTION

- Use an analogue tester to measure the resistance.  
If you use a digital tester, the tester may not indicate correct values.  
This is because the polarity of the tester inner circuit is not appropriate.
- Before measurement, disconnect the cable from the terminal block of the controller or the control board. If the cable is connected, correct measurement values cannot be obtained.
- Before disconnecting the cable, put a mark or lead wire color on the cable. If the cable is disconnected without any mark, you may reconnect the cable to a wrong terminal after measurement.

Disconnect the transmission cable from the terminal block of the controller or the control board.

Using an analogue tester, measure the resistance value at the following points:

- Between D and G (Resistance value: Several k $\Omega$  or more)
- Between +24V and 0V (Resistance value: Several k $\Omega$  or more)
- Between +24V and D (Resistance value: Several k $\Omega$  or more)



# Starting

## Power-on (Main Power and Local Power)

### CAUTION

- To use both the main and local power supply units, turn on the local power supply unit first, and then turn on the main power supply unit, or turn on these power supply units at the same time.
- To turn on the power for the first time after installing the system, be sure to set the mode selector switch to 'CONFIG.'
- When changing the transmission mode (A/B/C mode), do so after cutting OFF the power supply to the S-LINK V I/O unit.

At the completion of check before starting, turn on the power.  
The **S-LINK V** system will be activated.

## CONFIG mode

Settings for **SL-VCU1** are indicated in this section.




- For a detailed description of the following controllers, refer to their respective user's manuals.  
**SL-VGU1-C, SL-VGU1-D** : **SL-VGU1-C / SL-VGU1-D** User's Manual  
**SL-VGU1-EC** : **SL-VGU1-EC** User's Manual  
**SL-VGU1-485** : **SL-VGU1-485** User's Manual  
**SL-VMEL-Q** : **SL-VMEL-Q** User's Manual  
**SL-VFP7** : **SL-VFP7** User's Manual
- For a detailed description of the control module, refer to the '**S-LINK V Control Module Product Specifications**.'
- For a detailed description of the handy monitor, refer to the '**S-LINK V Handy Monitor Instruction Manual**.'

In the CONFIG mode, the displayed items depend on the CONFIG mode selection timing.















- **If the system is switched to the CONFIG mode before power-on:**
  - Each item can be set.
- **If the system is switched to the CONFIG mode after power-on:**  
Difference from the above-described case (CONFIG mode selection before power-on) is the following two points:
  - The default items will not be displayed.
  - The set value of each item is displayed, but changing the set value is not possible.













However, the display mode between the decimal number display mode and the hexadecimal number display mode can be switched. In addition, the system setting function can be activated.

In case of **SL-VCU1**



means that the displayed item will blink


Mode setting	Operation	Description / Function	Indication
Setting of transmission mode	In the CONFIG mode, turn on the power. Press ENTER key.	Displays the current transmission mode.  Blinks the displayed current transmission mode.	e.g.)   If A mode is selected: 
	Press ◀ key or ▶ key.	Selects the transmission mode from the three types (A mode, B mode and C mode ), and then displays the selected mode.	If B mode is selected:   If C mode is selected: 
	Press ENTER key.	Determines the transmission mode.	e.g.) 
Setting of number of I/O control points	Press ▶ key.	Displays the number of I/O control points.	e.g.) 
	Press ENTER key.	Blinks the displayed number of I/O control points.	If 512 points is selected: 
	Press ◀ key or ▶ key.	Selects the number of I/O control points in the range of 32 to 512 points. Selection is possible in increments / decrements of 32 points.	If 32 points is selected: 
	Press ENTER key.	Determines the number of I/O control points.	e.g.) 
Setting of error 1 output operation	Press ▶ key.	Displays the error 1 output operation.	e.g.) 
	Press ENTER key.	Blinks the displayed error 1 output operation.	Error output 1 
	Press ◀ key or ▶ key.	Selects the external output type for the detected error from the following three types: /: Turns off the error output 1 of the controller. 2: Turns off the error output 2 of the controller. - : Will not turn off any error output.	Error output 2   No error output 
	Press ENTER key.	Determines the error 1 output operation.	e.g.) 
Setting of error 2 to 5 output operation	Same as error 1 output operation ( Switching in the order of errors 2, 3, 4, and 5 )	Same as error 1	Same as error 1

Mode setting	Operation	Description / Function	Indication
Setting of display to decimal / hexadecimal number display	Press <b>▶</b> key.	Displays the code of the decimal / hexadecimal number setting.	e.g.) 
	Press ENTER key.	Blinks the displayed code of the decimal / hexadecimal number setting.	Decimal number display 
	Press <b>◀</b> key or <b>▶</b> key.	Selects either the decimal or hexadecimal number display.	Hexadecimal number display 
	Press ENTER key.	Determines the display. (If the hexadecimal number display is selected, the hexadecimal number display mode indicator will light up.)	e.g.) 
System setting	Press <b>▶</b> key.	Displays the code of the system setting.	
	Press and hold ENTER key until the displayed code flashes (for 3 seconds).	Enters the system setting (blinks).  Alternately displays the number of connected PLC I/O connectors and the number of connected nodes (number of connected I/O units).	e.g.)   If 2 PLC I/O connectors are connected:   If 4 I/O units are connected:   End 
Default setting	Press <b>▶</b> key.	Displays the code of the default setting mode.	
	Press and hold ENTER key (for 3 seconds).	Displays the indicator check pattern, and sets the default values.  Sets the items to the initial conditions (default values) in the CONFIG mode. Clears the addresses of all the units specified in the system setting.	End   


**Controller setting default values (values set in our factory before delivery:)**



Transmission mode



Number of I/O control points




Error 1 output operation




Error 2 output operation




Error 3 output operation



Error 4 output operation



Error 5 output operation



Decimal / Hexadecimal number display

## Check of Recognized Addresses


Set the mode selector switch to CHECK. In the CHECK mode, the number of connected PLC I/O connectors, number of connected nodes (number of connected I/O units), and recognized addresses will be displayed.

### CHECK mode

Operation	Description / Function	Decimal number display	Hexadecimal number display
Set the mode selection switch to CHECK.	Displays the number of recognized PLC I/O connectors.		
Press ▶ key.	Displays the number of recognized nodes (number of I/O units connected to the controller.)		
Press ▶ key. Press ▶ key. (Repeatedly press this key to display all the connected connectors)	Displays the recognized PLC I/O connector numbers from the smallest number to the largest number.	 ↓ ▶  :	 ↓ ▶  :
Press ▶ key. Press ▶ key. (Repeatedly press this key to display all the connected connectors)	Displays the recognized I/O connector address numbers from the smallest number to the largest number.	 ↓ ▶  :	 ↓ ▶  :

- Notes: 1) Use ◀ key to display the numbers in the reversed order.  
 2) Press and hold SELECT key (◀ key or ▶ key) to switch the displayed numbers at a high speed.  
 3) If the unit is the I/O mixed type, only the input addresses will appear.

#### Example: In the decimal number display



\* A recognized address means the first digit of a unit address (address set by the address setting switch).

# **Chapter 4**

# **Specifications**

---

---

# Specifications

## Common Specifications

Transmission method	Bidirectional time-division multiple transmission method
Synchronization method	Bit synchronization method, frame synchronization method
Transmission procedure	<b>S-LINK V</b> protocol
Transmission speed	A mode: 110kbps B mode: 27.5kbps C mode: 6.9kbps
Refresh time (Note 1)	A mode: 0.29 to 10.32ms B mode: 1.18 to 41.29ms C mode: 4.70 to 165.15ms
Number of I/O control points	Max. 512 points
Number of connected nodes	Max. 256 nodes
Transmission distance	A mode: Max. 50m B mode: Max. 200m C mode: Max. 800m
Total cable length	A mode: 100m or less B mode: 400m or less C mode: 1,600m or less
Transmission cable	Exclusive 4-core flat cable (0.5mm <sup>2</sup> ) or 4-core VCTF cable (non-shielded) having conductor cross section of 0.3 to 2.0mm <sup>2</sup> (Note 2)

Notes: 1) For a detailed description of refresh time and response delay time, refer to page 28.

2) The VCTF cord is the vinyl cabtyre cord that conforms to the requirements of JIS C3306 'Polyvinyl chloride insulated flexible cords.'

## Address setting switches

### CAUTION


To change the set position (ON / OFF position) of an address setting switch, use a tool having a hard and sharp tip, such as a flathead screwdriver.

To set the address of each **S-LINK V** unit, use the address setting switches installed on each unit.

### ● PLC I/O connector

### CAUTION

The connector number setting switches on each PLC I/O connector has different functions compared with the address setting switches on each I/O unit.




● Connector number setting switches

Be sure to set the PLC I/O connector numbers.

















Each PLC I/O connector number will be determined from the sum total of the values set by the connector number setting switches.

The connector number setting range is 0 to 15.

The relation between the PLC I/O connector numbers and the I/O unit addresses are shown in the following table.


 One control cable can control up to 8 PLC I/O connectors. To control 9 or more PLC I/O connectors, use 2 control cables so that the number of connectors for each cable can be 8 or less.

<Example: Setting of PLC I/O connector numbers>

Connector number setting switches	PLC I/O connector number	S-LINK V I/O unit address
	0	0 to 31
	1	32 to 63
	2	64 to 95
	3	96 to 127
	4	128 to 159
	5	160 to 191
	6	192 to 223
	7	224 to 255
	8	256 to 287
	9	288 to 319
	10	320 to 351
	11	352 to 383
	12	384 to 415
	13	416 to 447
	14	448 to 479
	15	480 to 511

## Specifications

### • Address setting switches



### CAUTION

The output unit has the 'HOLD' switch that can set the output holding function. When you set the address, also set the output holding function. For a detailed description of the output holding function, refer to page 32, and correctly set the function.

Be sure to set the address of each I/O unit.

Address is the numerical value set by the address setting switches. For the I/O module, the sum total of the address numbers [sum total of the ADD. (COM.)] (pin No.28) value and the shorted ADD. (256) to ADD. (1) (pin No.19 to 27) values will be the first address of the module. For a detailed description of the pin arrangement, refer to pages 140 and 142.


The address setting range is 0 to 511.



Set the address in the address setting range specified by the PLC I/O connector number.

### <Example of address setting>

- To set the address to '3':  
1 + 2 = 3



For the address setting list (ON / OFF statuses of address setting switches), refer to "our website: <https://panasonic.net/id/pidsx/global>."

When the system is set, the controller will recognize the addresses shown in the following table:

Type	Model	Address recognized by controller
PLC input connector	SL-VS□	Value set by connector number setting switches
PLC output connector	SL-VP□	
Input unit	SL-VCH10/20	Address set by address setting switches (first address)
	SL-VTB□	
	SL-VT□J	
	SL-VT□E	
	SL-VT16C1	
	SL-VTAD1	
Output unit	SL-VM□ (Note)	Address set by address setting switches (first address)
	SL-VCH11/22	
	SL-VTBP□	
	SL-VTP□J	
	SL-VTP□E	
	SL-VTP16C1(-S)	
	SL-VTDA1	
SL-VTPR□		
I/O mixed unit	SL-VMP□ (Note)	Address set by input-side address setting switches (first input address) The output address will not be recognized.
	SL-VCH21	

Note: Address setting switches are not incorporated in the SL-VM□ and SL-VMP□.

# Specifications of Each Unit


## Controller

**NOTE** For a detailed description of the following controllers, refer to their respective user's manuals.




<b>SL-VGU1-C, SL-VGU1-D</b>	: <b>SL-VGU1-C / SL-VGU1-D</b> User's Manual
<b>SL-VGU1-EC</b>	: <b>SL-VGU1-EC</b> User's Manual
<b>SL-VGU1-485</b>	: <b>SL-VGU1-485</b> User's Manual
<b>SL-VMEL-Q</b>	: <b>SL-VMEL-Q</b> User's Manual
<b>SL-VFP7</b>	: <b>SL-VFP7</b> User's Manual

Each system of the **S-LINK V** system needs one controller.

- **Part description**



# Specifications


No.	Designation	Function
1	Power supply terminal	13: F.G.
		14: F.G.
		15: 0V
		16: +24V
Supplies +24V, 0V, or F.G. power from the external power supply unit.		
2	Transmission cable terminal	9: G
		10: D
		11: 0V
		12: +24V
Supplies +24V, 0V, D, or G power to the I/O unit.		
3	Hexadecimal number display mode indicator (Orange)	Indicates the current display mode of the address display. <ul style="list-style-type: none"> <li>• ON: The hexadecimal number display mode is selected.</li> <li>• OFF: The decimal number display mode is selected.</li> </ul>
4	Address display (Red)	The displayed item depends on the mode ('RUN,' 'CHECK,' or 'CONFIG' mode). Use the mode selector switch to switch the mode.
		<p><b>&lt;RUN mode&gt;</b></p> <ul style="list-style-type: none"> <li>• Each transmission mode (3 modes in total) will be indicated by the following character, and the LED of each character will sequentially light just like rotating clockwise.</li> </ul> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>A Mode</p>  </div> <div style="text-align: center;"> <p>B Mode</p>  </div> <div style="text-align: center;"> <p>C Mode</p>  </div> </div> <ul style="list-style-type: none"> <li>• If an error occurs, the error message will appear.</li> </ul> <p>Note: After eliminating the cause of the error, press ENTER key and SELECT keys (2 types of keys) at the same time. The error message will disappear.</p> <p><b>&lt;CHECK mode&gt;</b></p> <ul style="list-style-type: none"> <li>• The number of connected nodes will be displayed first. After that, each time SELECT key is pressed, the recognized addresses will be displayed one after another.</li> </ul> <p>Number of connected nodes: Using the decimal or hexadecimal number, the number of I/O units and the number of PLC I/O connectors will be displayed.</p> <p>Address: Using the decimal or hexadecimal number, the addresses of the I/O units and the PLC I/O connectors will be displayed sequentially.</p> <p>Note: In the hexadecimal number display mode, the hexadecimal number indicator (orange) lights up.</p> <p><b>&lt;CONFIG mode&gt;</b></p> <ul style="list-style-type: none"> <li>• Settings will be displayed sequentially. To switch the displayed setting, use SELECT key.</li> <li>• When RUN mode is switched to CONFIG mode, different item will be displayed compared with the displayed item just after power-on. For a detailed description, refer to page 66.</li> </ul>
5	ENTER key	Press ENTER key to determine the set condition value. In the system setting mode, press and hold ENTER key for 3 seconds or more, then the system will be set.
6	SELECT keys	Use these keys to switch the displayed item or set item. Also use these keys to change the set condition value.
7	Transmission mode indicator (Green)	This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission speed.
8	Error indicator (Red)	This indicator indicates the error status as follows: <ul style="list-style-type: none"> <li>• Lights up when an error occurs.</li> <li>• Blinks when the cause of the error is eliminated.</li> </ul>
9	Mode selection switch	Switches the mode (RUN, CHECK, or CONFIG mode).
10	Output terminal	5: Error output 1
		6: Error output 2
		7: READY
		8: COM. (+24V)
Turns off the output transistor if an error occurs. For each error, you can select error output 1, 2, or no output. Turns on the output transistor if the system is ready for transmission. COM. terminal for READY signal output and error outputs 1 and 2		
11	PLC connector terminal	1: G
		2: D
		3: 0V
		4: +24V
Supplies +24V, 0V, D, or G power to the PLC I/O connector.		

• Specifications

Type	Controller		
Model No.	<b>SL-VCU1</b>		
Supply voltage	24V DC <sup>+10%</sup> <sub>-5%</sub>		
Current consumption	135mA or less (excluding the load drive current of error output)		
Connecting method	PLC I/O connector side: Multi-drop connection Signal transmission line side: 'T' - branch connection or multi-drop connection		
Output	READY output	NPN open-collector transistor • Maximum sink current: 100mA (without short-circuit protective function) • Applied voltage: 30V DC or less (between output and 0V) • Residual voltage: 1.5V or less (at 100mA sink current)	
	Error output 1		
	Error output 2		
Indicators	Transmission	Green LED (blinks during transmission)	
	Error	Red LED (lights up when an error occurs, blinks when the error is eliminated)	
	Hexadecimal number	Orange LED (lights up when the hexadecimal number display mode is selected to display the addresses)	
Address display	3 digit red LED display (displays the number of connected nodes, recognized addresses, error addresses, etc.)		
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation) (Note), Storage: -20 to +70°C	
	Ambient humidity	10 to 90% RH, Storage: 10 to 90% RH	
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)	
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure	
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure	
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each	
Shock resistance	294m/s <sup>2</sup> acceleration (30G approx.) in X, Y and Z directions for three times each		
Mounting	Mounted on DIN rail or by tightening screws		
Tightening torque	Terminal screw: 0.29 to 0.49N·m, Mounting screw: 0.78N·m or less		
Material	Enclosure: ABS, Terminal area: PBT (with glass fibers), Protective cover: Polycarbonate		
Weight	Approx.140g		
Accessory	<b>NPS-CV</b> (Protective cover): 1 pc.		

Note: If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.


## I/O circuit diagram and terminal layout drawing



13	14	15	16
FG	FG	0V	+24V
9	10	11	12
G (BK)	D (WH)	0V (BU)	+24V (BN)
<b>SL-VCU1</b>			
5	6	7	8
ERROR OUT1	ERROR OUT2	READY	COM.
1	2	3	4
G (BK)	D (WH)	0V (BU)	+24V (BN)

- Notes: 1) Shorting pieces are attached to connect terminal 11 to terminal 15 and terminal 12 to terminal 16. Do not remove these shorting pieces. If you remove these pieces, the system will not operate properly.  
 2) To connect a conductive load to the output line, be sure to use a protective device, such as a diode.  
 3) When an error occurs, ERROR OUT1 and OUT2 turn OFF.


## Dimensions (Unit: mm)






# Bus direct-connection type controller for FP2 / FP2SH Series

**NOTE** For a detailed description of the bus direct-connection type controller for **FP2 / FP2SH** series (**SL-VFP2**), refer to the '**Bus direct-connection type controller for FP2 / FP2SH series (SL-VFP2) Instruction Manual.**'

● Part description



# Specifications

No.	Designation	Function							
1	Hexadecimal number display mode indicator (Green)	Indicates the current display mode of the address display. <ul style="list-style-type: none"> <li>• ON: The hexadecimal number display mode is selected.</li> <li>• OFF: The decimal number display mode is selected.</li> </ul>							
2	Transmission mode indicator (Green)	This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission mode.							
3	Power indicator (Green)	Lights up when the power is supplied from the PLC to the <b>SL-VFP2</b> .							
4	Error indicator (Red)	This indicator indicates the error status as follows: <ul style="list-style-type: none"> <li>• Lights up when an error occurs.</li> <li>• Blinks when the cause of the error is eliminated.</li> <li>• Lights off when operation is normal.</li> </ul>							
5	Address display (Red)	<p>The displayed item depends on the mode ('RUN,' 'CHECK,' or 'CONFIG' mode). Use the mode selector switch to switch the mode.</p> <p><b>&lt;RUN mode&gt;</b></p> <ul style="list-style-type: none"> <li>• Each transmission mode (3 modes in total) will be indicated by the following character, and the LED of each character will sequentially light up just like rotating clockwise.</li> </ul> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>A Mode</p>  </div> <div style="text-align: center;"> <p>B Mode</p>  </div> <div style="text-align: center;"> <p>C Mode</p>  </div> </div> <ul style="list-style-type: none"> <li>• If an error occurs, the error message will appear.</li> </ul> <p>Note: After eliminating the cause of the error, press ENTER key and SELECT keys (2 types of keys) at the same time. The error message will disappear.</p> <p><b>&lt;CHECK mode&gt;</b></p> <ul style="list-style-type: none"> <li>• The number of connected nodes will be displayed first. After that, each time you press SELECT key, the recognized addresses will be displayed one after another.</li> </ul> <p>Number of connected nodes: Using the decimal or hexadecimal number, the number of I/O units' nodes will be displayed.</p> <p>Address: Using the decimal or hexadecimal number, the addresses of the I/O units will be displayed sequentially.</p> <p>Note: In the hexadecimal number display mode, the hexadecimal number indicator (green) will light up.</p> <ul style="list-style-type: none"> <li>• If an error occurs, the number of nodes having the error and the error addresses will be displayed sequentially (for errors 3, 4, and 5).</li> </ul> <p><b>&lt;CONFIG mode&gt;</b></p> <ul style="list-style-type: none"> <li>• Settings will be displayed sequentially. To switch the displayed setting, use SELECT key.</li> <li>• When the RUN mode is switched to CONFIG mode, different item will be displayed compared with the displayed item just after power-on.</li> </ul>							
6	SELECT keys	Use these keys to switch the displayed item or set item. Also use these keys to change the set condition value.							
7	ENTER key	Press ENTER key to determine the set condition value. In the system setting mode, press and hold ENTER key for 3 seconds or more. The system will be set.							
8	Mode selector switch	Switches the mode (RUN, CHECK, or CONFIG mode).							
9	S-LINK V terminal block connector	<table border="1" style="display: inline-table; vertical-align: top;"> <tr><td>7: G</td></tr> <tr><td>6: D</td></tr> <tr><td>5: 0V</td></tr> <tr><td>4: +24V</td></tr> <tr><td>3: 0V</td></tr> <tr><td>2: +24V</td></tr> <tr><td>1: F.G.</td></tr> </table> <p>Receives +24V, 0V, and F.G. from the external power supply unit, and supplies +24V, 0V, D, and G to the I/O units.</p>	7: G	6: D	5: 0V	4: +24V	3: 0V	2: +24V	1: F.G.
7: G									
6: D									
5: 0V									
4: +24V									
3: 0V									
2: +24V									
1: F.G.									

● Main specifications

Type	Bus direct-connection type <b>S-LINK V</b> controller for <b>FP2 / FP2SH</b> Series	
Model No.	<b>SL-VFP2</b>	
Supply voltage (Note 1)	[ <b>S-LINK V</b> system side] 24V DC $\pm 10\%$ [ <b>FP2</b> side] 5V DC $\pm 5\%$	
Current consumption	[24V DC] 60mA or less (Note 2) [5V DC] 150mA or less	
Allowable passing current	7A or less (Note 3)	
Number of I/O points	32 to 512 points (Set in units of 32 points)	
Number of connected nodes	Maximum 256 nodes	
Combination of inputs and outputs	Inputs and outputs can be set in units of 32 points.	
Indicators	Power supply	Green LED (lights up when 5V DC is supplied from the <b>FP2</b> bus side)
	Transmission	Green LED (blinks during transmission)
	Error	Red LED (lights up when an error occurs. Blinks when the error is eliminated. Lights off when operation is normal.)
	Hexadecimal number	Green LED (lights up when the hexadecimal number display mode is selected to display the addresses)
Address display	3 digit red LED display (displays the number of connected nodes, recognized addresses, error addresses, etc.)	
Applicable PLC	<b>FP2</b> [manufactured by Panasonic Industrial Devices SUNX Co., Ltd.]	
Unit type	<b>FP2</b> intelligent units	
Number of occupied points	Input: 16 points, Output: 16 points	
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation), Storage: -20 to +75°C
	Ambient humidity	5 to 95% RH, Storage: 5 to 95% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, using 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 9.8m/s <sup>2</sup> in X, Y and Z directions for ten times each
	Shock resistance	147m/s <sup>2</sup> in X, Y, and Z directions for three times each
Grounding method	F.G. terminal: C-connection, Enclosure: Floating	
Material	Enclosure: Polycarbonate + PBT alloy, Display part: Polycarbonate	
Weight	Approx. 160g	
Terminal block	Terminal block connector ECH381RM-07P (manufactured by DINKLE ENTERPRISE CO., LTD.)	


Notes: 1) 24V DC and 5V DC are insulated.

2) The current consumption shown in the above table is the current consumption of the controller, but does not include that of the **S-LINK V** I/O units.




3) This product is not equipped with any short-circuit protective function.  
For this reason, select a power supply unit having short-circuit protective function (fuse, etc.).

# Specifications

## • Terminal layout drawing




## • Dimensions (Unit: mm)



# Bus direct-connection type controller for FP7 Series

**NOTE** For a detailed description of the bus direct-connection type controller for FP7 series (SL-VFP7), refer to the 'Bus direct-connection type controller for FP7 series (SL-VFP7) Instruction Manual.'

• Part description



# Specifications

No.	Designation	Function
1	Power indicator (Blue)	• Turns on when the CPU unit power is ON.
2	Hexadecimal indicator (Orange)	• It indicates the display mode of the address display. · Lights up : Hexadecimal display mode · Lights off : Decimal display mode
3	Transmission indicator (Green)	• It blinks during transmission (signal generation). The frequency of blinking differs depending on the transmission mode.
4	Error indicator (Red)	• It shows the error condition. · Lights ON : Error occurrence · Lights OFF : Normal operation · Blinks : Error history display
5	Address display (Green)	<p>• The display contents differ in "RUN mode," "CHECK mode" and "CONFIG mode." The mode can be changed with the mode selection switch.</p> <p>&lt;RUN mode&gt;</p> <p>• LEDs light up in each transmission mode (3 types,) and trace out a rectangle in the clockwise direction.</p> <div style="text-align: center;"> </div> <p>• When an error occurs, the type of error is shown.</p> <p>&lt;CHECK mode&gt;</p> <p>• At first, the recognized connected node number is displayed. Subsequently, the addresses are displayed at every press of SELECT keys.            Connected node No.: I/O unit node No. is displayed in decimal / hexadecimal.            Address: I/O unit addresses are displayed successively in decimal / hexadecimal.</p> <p style="padding-left: 40px;">Note: In case of hexadecimal display, the hexadecimal indicator lights up.</p> <p>• When an error occurs, the node number having the error and the error addresses are displayed successively. (for errors 3, 4, and 5)</p> <p>&lt;CONFIG mode&gt;</p> <p>• Each setting is displayed successively. The settings can be changed by using SELECT key.</p> <p>• The display contents differ when power is switched on and when a change is made from RUN mode.</p> <p>• When the PLC stops in RUN or CHECK mode, "STP" is displayed. [If the operation in the event of PLC stoppage is set to (Stop communication when PLC stops)]</p> <div style="text-align: center;"> </div>
6	SELECT keys	• They are used to change the displayed item or setting item, and to change the numerical value of each setting.
7	ENTER key	• Press the ENTER key: To apply the settings • Hold down the ENTER key for 3 seconds: To execute the function
8	Mode selection switch	• It is used to change to RUN / CHECK / CONFIG modes.
9	Unit connector	• This connector is used to connect the internal circuits of two or more units.
10	S-LINK V terminal block connector	• +24V, 0V, and F.G. are supplied from the external power supply, and +24V, 0V, D, and G are supplied to I/O units. Further, the error output is connected to the external device.


## ● Main specifications

Designation	<b>FP7 Series Bus Direct Connection S-LINK V Controller</b>	
Model No.	<b>SL-VFP7</b>	
Supply voltage (Note 1)	[S-LINK V side]	+24V DC $\begin{matrix} +10 \\ -5 \end{matrix}$ %
	[FP7 side]	+24V DC +20% / -15%
Current consumption	[S-LINK V side]	80mA or less (Note 2)
	[FP7 side]	80mA or less
Allowable through current	7A or less (Note 3)	
Transmission method	Bidirectional time-divided multiple signal transmission	
Synchronization method	Bit synchronization, Frame synchronization	
Transmission procedure	<b>S-LINK V</b> protocol	
Transmission speed	A mode:110kbps B mode:27.5kbps C mode:6.9kbps	
Refresh time	A mode:0.29~10.32ms B mode:1.18~41.29ms C mode:4.70~165.15ms	
Connecting method	T-junction or multi-drop connection	
I/O points	32 to 512 points (Settable in units of 32 points)	
No. of connected nodes	Maximum 256 nodes	
Transmission distance	A mode:maximum 50m B mode:maximum 200m C mode:maximum 800m	
Total wiring length	A mode:100m or less B mode:400m or less C mode:1600m or less	
Transmission cable	Exclusive 4-core flat cable (0.5mm <sup>2</sup> ) or Conductor cross-section area 0.3 to 1.5mm <sup>2</sup> 4-core VCTF cable (without shield)	
I/O combination	I/O settable in units of 32 points	
Address display	Displays RUN / CHECK / CONFIG modes	
Indicator	Power	Blue LED (Lights up when the CPU unit power is ON.)
	Transmission	Green LED (Blinking during communication)
	Error	Red LED (Lights up when an error occurs,blinks after the cause of an error is eliminated, and remains unlit during normal operation)
	Hexadecimal	Orange LED (Lights up when the address display unit is in hexadecimal notation)
	Address display	3-digit green LED (Displays the number of connected nodes, recognized addresses, and error addresses)
Compatible PLC	<b>FP7 series</b>	
Unit type	<b>FP7</b> communication unit	
Mountable units	Units can be mounted in basic block section and expansion block section	
Number of units that can be mounted	64 units (Can be mounted in basic block section and expansion block section)	
Number of occupied words	Input: 1 word Output: 1 word	
Ambient temperature	0~+55° C (No dew condensation) , Storage : -40~+70° C	
Ambient humidity	10~95%RH[at+25° C, (No dew condensation) ], Storage:10~95%RH [at+25° C (No dew condensation) ]	
Vibration resistance	5 to 8.4 Hz, single amplitude of 3.5 mm, 1 sweep/min. (IEC61131-2)	
	8.4 to 150 Hz, constant acceleration of 9.8 m/s <sup>2</sup> , 1 sweep/min. (IEC61131-2) 10 min each in X, Y, and Z directions	
Shock resistance	147m/s <sup>2</sup> in X, Y, and Z directions for three times each (IEC61131-2)	
Grounding method	F.G. terminal : Capacities coupling Casing : Floating type	
Material	Enclosure : PC+PBT alloy	
	Display : PC	
Weight	120g	
Terminal block	Terminal block connector (Dinkle International Co. Ltd) ECH381RM-07P	
Regulations	EMC Directive Compliance	


- Notes: 1) The +24V DC power supply on the **S-LINK V** side and the +24V DC power supply on the **FP7** side are insulated.  
2) The current consumption shown above is that of the controller. This does not include the current consumption of the **S-LINK V** input and output units that are connected.  
3) This product is not equipped with a power supply short-circuit protection function. For the power supply to be used, select a product equipped with a short-circuit protection function (such as fuses).

# Specifications

## • Terminal layout drawing




## • Dimensions (Unit: mm)






# Mitsubishi MELSEC-Q Series PLC bus direct-connection type controller

**NOTE** For a detailed description of the Mitsubishi MELSEC-Q series PLC bus direct-connection type controller (SL-VMEL-Q), refer to the 'Mitsubishi MELSEC-Q series PLC bus direct-connection type controller (SL-VMEL-Q) Instruction Manual.'

• Part description



# Specifications

No.	Designation	Function							
1	Hexadecimal number display mode indicator (Green)	Indicates the current display mode of the address display. <ul style="list-style-type: none"> <li>• ON: The hexadecimal number display mode is selected.</li> <li>• OFF: The decimal number display mode is selected.</li> </ul>							
2	Address display (Red)	The displayed item depends on the mode ('RUN,' 'CHECK,' or 'CONFIG' mode). Use the mode selector switch to switch the mode.  <b>&lt;RUN mode&gt;</b> <ul style="list-style-type: none"> <li>• Each transmission mode (3 modes in total) will be indicated by the following character, and the LED of each character will sequentially light up just like rotating clockwise.</li> </ul> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>A Mode</p>  </div> <div style="text-align: center;"> <p>B Mode</p>  </div> <div style="text-align: center;"> <p>C Mode</p>  </div> </div> <ul style="list-style-type: none"> <li>• If an error occurs, the error message will appear.</li> </ul> <p>Note: After eliminating the cause of the error, press ENTER key and SELECT keys (2 types of keys) at the same time. The error message will disappear.</p> <b>&lt;CHECK mode&gt;</b> <ul style="list-style-type: none"> <li>• The number of connected nodes will be displayed first. After that, each time you press SELECT key, the recognized addresses will be displayed one after another.</li> </ul> <p>Number of connected nodes: Using the decimal or hexadecimal number, the number of I/O units' nodes will be displayed.</p> <p>Address: Using the decimal or hexadecimal number, the addresses of the I/O units will be displayed sequentially.</p> <p>Note: In the hexadecimal number display mode, the hexadecimal number indicator (green) will light up.</p> <ul style="list-style-type: none"> <li>• If an error occurs, the number of nodes having the error and the error addresses will be displayed sequentially (for errors 3, 4, and 5).</li> </ul> <b>&lt;CONFIG mode&gt;</b> <ul style="list-style-type: none"> <li>• Settings will be displayed sequentially. To switch the displayed setting, use SELECT key.</li> <li>• When the RUN mode is switched to CONFIG mode, different item will be displayed compared with the displayed item just after power-on.</li> </ul>							
3	ENTER key	Press ENTER key to determine the set condition value. In the system setting mode, press and hold ENTER key for 3 seconds or more. The system will be set.							
4	SELECT keys	Use these keys to switch the displayed item or set item. Also use these keys to change the set condition value.							
5	Mode selector switch	Switches the mode (RUN, CHECK, or CONFIG mode).							
6	Transmission mode indicator (Green)	This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission mode.							
7	Error indicator (Red)	This indicator indicates the error status as follows: <ul style="list-style-type: none"> <li>• Lights up when an error occurs.</li> <li>• Blinks when the cause of the error is eliminated.</li> <li>• Lights off when operation is normal.</li> </ul>							
8	S-LINK V terminal block connector	<table border="1" style="display: inline-table; vertical-align: top;"> <tr><td>7: G</td></tr> <tr><td>6: D</td></tr> <tr><td>5: 0V</td></tr> <tr><td>4: +24V</td></tr> <tr><td>3: 0V</td></tr> <tr><td>2: +24V</td></tr> <tr><td>1: F.G.</td></tr> </table> Receives +24V, 0V, and F.G. from the external power supply unit, and supplies +24V, 0V, D, and G to the I/O units.	7: G	6: D	5: 0V	4: +24V	3: 0V	2: +24V	1: F.G.
7: G									
6: D									
5: 0V									
4: +24V									
3: 0V									
2: +24V									
1: F.G.									
9	Power indicator (Green)	Lights up when the power is supplied from the PLC to the <b>SL-VMEL-Q</b> .							
10	RUN indicator (Green)	Lights up when the <b>SL-VMEL-Q</b> is running (Xn0 = ON at the same time). Also lights up when transmission with the CPU unit is started.							

● Main specifications

Type	Mitsubishi MELSEC-Q Series PLC bus direct-connection type S-LINK V controller	
Model No.	SL-VMEL-Q	
Supply voltage (Note 1)	[S-LINK V system side] 24V DC $\pm 10\%$ [MELSEC-Q side] 5V DC $\pm 5\%$	
Current consumption	[24V DC] 70mA or less (Note 2) [5V DC] 400mA or less	
Allowable passing current	7A or less (Note 3)	
Number of I/O points	32 to 512 points (Set in units of 32 points)	
Number of connected nodes	Maximum 256 nodes	
Combination of inputs and outputs	Inputs and outputs can be set in units of 32 points.	
Indicators	Power supply	Green LED (lights up when 5V DC is supplied from the MELSEC-Q bus side)
	RUN	Green LED (lights up when the control circuit operates properly)
	Transmission	Green LED (blinks during transmission)
	Error	Red LED (lights up when an error occurs. Blinks when the error is eliminated. Lights off when operation is normal.)
	Hexadecimal number	Green LED (lights up when the hexadecimal number display mode is selected to display the addresses)
Address display	3 digit red LED display (displays the number of connected nodes, recognized addresses, error addresses, etc.)	
Applicable PLC	MELSEC-Q [manufactured by Mitsubishi Electric Corp.]	
Unit type	MELSEC-Q intelligent function unit	
Number of occupied points	32 points	
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation), Storage: -20 to +75°C
	Ambient humidity	5 to 95% RH, Storage: 5 to 95% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, using 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 9.8m/s <sup>2</sup> in X, Y and Z directions for ten times each
	Shock resistance	147m/s <sup>2</sup> in X, Y, and Z directions for three times each
Grounding method	F.G. terminal: C-connection, Enclosure: Floating	
Material	Enclosure: PC-ABS alloy	
Weight	Approx. 160g	
Terminal block	Terminal block connector 2ESDVM-07P (manufactured by DINKLE ENTERPRISE CO., LTD.)	

Notes: 1) 24V DC and 5V DC are insulated.


2) The current consumption shown in the above table is the current consumption of the controller, but does not include that of the S-LINK V I/O units.

3) This product is not equipped with any short-circuit protective function.



For this reason, select a power supply unit having short-circuit protective function (fuse, etc.).

# Specifications

## • Terminal layout drawing



## • Dimensions (Unit: mm)




## Control board

There are 2 types of control boards: control boards for PCI bus, and VME bus.  
 Select a control board optimum for your bus.


• Part description

<SL-VPCI>



No.	Designation	Function
1	S-LINK V terminal block connector	1: G 2: D 3: 0V 4: +24V 5: 0V 6: +24V 7: F.G. Use these connectors to connect the power supply and signal lines of the S-LINK V system.
2	Board No. setting switches	Use these switches to set the SL-VPCI board No. Using the rotary switch, set the range to 0 to F, and you can set up to 16 board Nos. for the same bus.
3	Transmission mode setting switches I/O control points setting switches	Use the transmission mode setting switches to set the transmission mode to A mode, B mode, or C mode. Use the I/O control points setting switches to set the number of I/O control points. <div style="text-align: center;"> </div>
4	I/O setting switches	Use these switches to set the I/O (for I/O of every 32 points).
5	System setting button for port 1	Use this button to read and store the unit connection condition data. After this, the system will use this data to check for errors 3, 4, and 5.
6	Transmission indicator (Green)	This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission speed.
7	BUSY indicator (Orange)	This indicator will light up during system setting operation or transmission check operation.
8	Error indicator (Red)	This indicator indicates the error status as follows: <ul style="list-style-type: none"> <li>• Lights up when an error occurs.</li> <li>• Blinks when the cause of the error is eliminated.</li> </ul>

<SL-VVMES2>



No.	Designation	Function
1	S-LINK V terminal block connector for port 1	7: F.G.
		6: +24V
2	S-LINK V terminal block connector for port 2	5: 0V
		4: +24V
3	I/O first address setting switches	3: 0V
		2: D
4	Transmission mode setting switches for port 1 I/O control points setting switches for port 1	1: G
		7: F.G.
5	Transmission mode setting switches for port 2 I/O control points setting switches for port 2	6: +24V
		5: 0V
6	I/O setting switches for port 1	4: +24V
		3: 0V
7	I/O setting switches for port 2	2: D
		1: G
Use these connectors to connect the power supply and signal lines of the S-LINK V system.		
8	System setting button for port 1	Use these switches to set two upper digits of the first short address of the VME bus (address consists of 4 digits of hexadecimal numbers).
9	System setting button for port 2	Use the transmission mode setting switches to set the transmission mode to A mode, B mode, or C mode. Use the I/O control points setting switches to set the number of I/O control points.
10	Transmission indicator for port 1 (Green)	
11	Transmission indicator for port 2 (Green)	
12	BUSY indicator for port 1 (Orange)	Use these switches to set the I/O (for I/O of every 32 points).
13	BUSY indicator for port 2 (Orange)	
14	Error indicator for port 1 (Red)	Use this button to read and store the unit connection condition data. After this, the system will use this data to check for errors 3, 4, and 5.
15	Error indicator for port 2 (Red)	
16	Interruption level setting switches	This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission speed.
17	Status / ID setting switches	This indicator will light up during system setting operation or transmission check operation.
16	Interruption level setting switches	This indicator indicates the error status as follows: • Lights up when an error occurs. • Blinks when the cause of the error is eliminated.
17	Status / ID setting switches	Use these switches to set the VME bus interruption level (IRQ1 to IRQ7). Use these switches to set the status / ID using binary numbers. The status / ID will be transmitted at VME bus interruption.

## • Specifications


Type	For PCI bus	For VME bus	
Model No.	<b>SL-VPCI</b>	<b>SL-VVMES2</b>	
Supply voltage (Note 1)	[S-LINK V system side] 24V DC $^{+10\%}_{-5\%}$ [Bus side] 5V DC $\pm 5\%$		
Current consumption	[24V DC] 85mA or less (Note 2)	[24V DC] 88mA or less (Note 2)	
	[24V DC (power supply to load driving S-LINK V I/O unit)] Maximum current supplied: 7A (For one port for SL-VVMES2) (Note 3)		
	[5V DC] 315mA or less	[5V DC] 880mA or less	
Connecting method	'T'-branch connection or multi-drop connection		
Number of I/O control points	Maximum 512 points (Note 4) (using DIP switches, in increments / decrements of 32 points / I/O setting using the program in increments / decrements of 16 points is also possible).		
Indicators	Transmission	Green LED (blinks during transmission)	
	BUSY	Orange LED (Lights up at starting and during system setting operation, turns off during transmission)	
	Error	Red LED (Lights up when an error occurs, blinks when the cause of the error is eliminated, turns off when normal operation is performed.)	
Compatible bus	PCI bus (Note 5)	VME bus	
Environmental resistance	Ambient temperature (Note 6)	0 to +55°C (No dew condensation), Storage: -20 to +70°C	
	Ambient humidity (Note 6)	20 to 85% RH, Storage: 20 to 85% RH	
	Noise immunity (Note 6)	Power line: 500Vp, 10ms cycle, 1 $\mu$ s pulse width Common: 1,000Vp, 10ms cycle, 1 $\mu$ s pulse width (with noise simulator)	
	Voltage withstandability (Note 6)	1,000V AC for one min. between external terminal and ground	
	Insulation resistance (Note 6)	20M $\Omega$ , or more, with 500V DC megger between external terminal and ground	
	Vibration resistance (Note 6)	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each	
	Shock resistance (Note 6)	98m/s <sup>2</sup> acceleration (approx. 10G) in X, Y and Z directions for three times each	
Grounding method	Bracket: Floating, S-LINK V system side: C-connection		
Interruption function (Note 7)	Interruption will be performed if an error or input change occurs (enabling / disabling this function is possible).	Setting of 'Not used,' IRQ1 to IRQ7, and status / ID is possible. [Status / ID transfer capability: D08 (O)] Interruption will be performed if an error or input change occurs (enabling / disabling this function is possible).	

- Notes: 1) 24V DC and 5V DC are insulated from each other. For the SL-VVMES2, the S-LINK V transmission ports are also insulated.
- 2) The current consumption value is the total of the maximum current value (D-G line only) supplied to the S-LINK V I/O units and the current consumption value of the S-LINK V control board.
- 3) This product is not equipped with any short-circuit protective function.  
For this reason, select a power supply unit having short-circuit protective function (fuse, etc.).
- 4) For the SL-VVMES2, the maximum number of I/O control points is 1,024 points (512 points, maximum ' 2 ports).
- 5) If you need a driver, download the driver from "our Internet homepage: <https://panasonic.net/id/pidsx/global>."
- [We can provide drivers for DOS, Windows 95/98/Me(32bit), Windows NT 4.0(32bit), Windows2000/XP/7(32bit) and Windows 10(64bit).] If you cannot access to our Internet homepage, please contact the store where you bought our product or our sales office.
- 6) This value is for the control board single body. If the control board is installed on the computer, compare the specifications of the control board with those of the computer, and observe the specifications showing the lower value.
- 7) The interruption function can be enabled or disabled for each point. However, the interruption condition (ON→OFF / OFF→ON) is applied to all the input points, and application to each point is not possible.

# Specifications

## I/O circuit diagram and terminal layout drawing


<Common to all model>




Internal circuit ← Users' circuit

Note: The SL-VVMES2 is equipped with 2 ports.

<SL-VPCI>




<SL-VVMES2>




## Dimensions (Unit: mm)

<SL-VPCI>



<SL-VVMES2>



## Control module



For a detailed description of the control module, refer to the ‘**S-LINK V Control Module (SL-VMC1) Product Specification.**’

If you need the ‘**S-LINK V Control Module (SL-VMC1) Product Specification,**’ please contact the nearest sales office.

### • Specifications

Type	<b>S-LINK V control module</b>	
Model No.	<b>SL-VMC1</b>	
Supply voltage (Note 1)	[S-LINK V system side] 24V DC $^{+10\%}$ [Control module side] 5V DC $\pm 5\%$	
Current consumption	[24V DC] 60mA or less (Note 2) [5V DC] 200mA or less	
Number of I/O points	Maximum 512 points (Using DIP switches, in increments / decrements of 32 points is also possible.)	
Specifications for CPU side	Address occupation: 256 bytes (including area not used) from the specified address Address specification: Specified by the CS (chip selection signal) using the external logic Data bus width: 8 bits	
Interruption function (Note 3)	When the input is changed, or when an error occurs [Validity (valid or invalid) of interruption can be set.]	
Environmental resistance	Ambient temperature (Note 4)	0 to +55°C (No dew condensation), Storage: -20 to +70°C
	Ambient humidity (Note 4)	20 to 85% RH, Storage: 20 to 85% RH
	Noise immunity (Note 4)	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability (Note 4)	1,000V AC for one min. between external terminal and ground
	Insulation resistance (Note 4)	20MΩ, or more, with 500V DC megger between external terminal and ground
	Vibration resistance (Note 4)	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
	Shock resistance (Note 4)	98m/s <sup>2</sup> acceleration (approx. 10G) in X, Y and Z directions for three times each
Weight	Approx. 20g Parts kit: 1 set	
Accessories	( Common mode filter: 1 pc., Diode: 1 pc., Ceramic capacitor (blue): 2 pcs., Surge absorber (black): 1 pc., Poly switch: 2 pcs., Aluminum electrolytic capacitor: 1 pc.)	

Notes: 1) 24V DC and 5V DC are insulated.


2) The current consumption value is the total of the maximum current value (D-G line only) supplied to the **S-LINK V** I/O units and the current consumption value of the **S-LINK V** control module.

3) Validity (valid or invalid) of input interruption can be set for every point. The interruption condition (ON→OFF or OFF→ON), however, should be set in units of 32 points. If the input change interruption signal and the error occurrence interruption signal are output at the same time, the priority will be given to the error occurrence interruption signal.


4) Values of control module single body are shown in these areas. To mount this product on your device, these values may be subject to change so that the values can be optimum for both the control module and your device.

# Specifications


## Terminal layout drawing



## Dimensions (Unit: mm)



Pin No.	Description	
1	<b>S-LINK V-24V</b>	Operation power for <b>S-LINK V</b> side
2	N.C.	Not connected
3	D7	Data I/O
4	D6	
5	D5	
6	D4	
7	D3	
8	D2	
9	D1	
10	D0	
11	*RESET	Reset input
12	*RD	Read input
13	*WAT	Wait output
14	*WR	Write input
15	*CS	Chip selection input
16	GND	Grounding terminal for control module side
17	V <sub>DD</sub>	Operation power for control module side
18	SEND	Transmission indicator output
19	A0	Address input
20	A1	
21	A2	
22	A3	
23	A4	
24	A5	
25	A6	
26	A7	
27	*INT	<b>S-LINK V</b> interruption output
28	*READY	<b>S-LINK V</b> READY output
29	*24V MON.	<b>S-LINK V</b> supply voltage detection output
30	N.C.	Not connected
31	<b>S-LINK V-D</b>	D of <b>S-LINK V</b> side
32	<b>S-LINK V-G</b>	G of <b>S-LINK V</b> side and operation power of 0V




## PLC I/O connector


There are 8 types of PLC input connectors and 7 types of PLC output connectors.  
 Select PLC input and output connectors optimum for your PLC.  
 (For a detailed description, refer to pages 159 to 160.)

### • Part description

#### <Connector manufactured by Fujitsu Component>



#### <MIL connector>



No.	Designation	Function
1	Transmission indicator (Green)	This indicator blinks when the synchronization signal is sent from the controller.
2	Input indicators (Green) (For <b>SL-VS</b> □ only)	These indicators will light up when the corresponding signal is input from the controller (32 indicators for indication of 32 points).
	Output indicator (Orange) (For <b>SL-VP</b> □ only)	These indicators will light up when the corresponding signal is output to the controller (32 indicators for indication of 32 points).
3	Cascade cable connector	Used for connection of control cable or connector link cable. Control cable: Cable distributed from controller Connector link cable: Cable between PLC I/O connectors
4	Connector number setting switches	Used for setting of the PLC I/O connector number.
5	Mounting screw	Used for fixing the PLC I/O connector to the PLC.
6	PLC I/O module connector	Used for connection to the PLC I/O module.
7	Connector lock lever insertion port	Insert the connector lock lever of the PLC I/O module into this port to fix the main body.

# Specifications


## • Specifications

Type	PLC input connector	PLC output connector
Model No.	<b>SL-VS</b> □	<b>SL-VP</b> □
Supply voltage	24V DC±10% (Supplied from <b>SL-VCU1</b> )	
Current consumption	30mA or less (Excluding current supplied to PLC input module)	73mA or less (Excluding current supplied to PLC output module)
Connection	Up to 16 connectors can be connected to each <b>SL-VCU1</b> Up to 8 connectors can be connected to each control cable (Use of connector link cable)	
Compatible PLC module	Refer to pages 159 to 160.	
Connector number setting	Using switches, in the range of 0 to 15	
Number of I/O points	Input: 32 points	Output: 32 points
Indicators	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>SL-VCU1</b> )
	Input	Green LED×32
	Output	Orange LED×32
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation) (Note), Storage: -20 to +70°C
	Ambient humidity	10 to 90% RH, Storage: 10 to 90% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
	Shock resistance	147m/s <sup>2</sup> acceleration (approx. 15G) in X, Y and Z directions for three times each
Mounting	Connector manufactured by Fujitsu Component Ltd.: Mounting screws MIL connector: Connector with lock function	
Tightening torque	Connector manufactured by Fujitsu Component Ltd.: 0.4N·m	
Material	Enclosure: Polycarbonate	
Weight	Connector manufactured by Fujitsu Ltd.: approx. 45g, MIL connector: approx. 30g	
Accessory	Connector cap: 1 pc.	


Note: If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units. In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

• I/O circuit diagram and terminal layout drawing


<PLC input connector>




<Connector manufactured by Fujitsu Component>



<MIL connector>




<PLC output connector>




• Dimensions (Unit: mm)

<Connector manufactured by Fujitsu Component>



<MIL connector>




# Specifications

## I/O unit

There are several types of I/O units: 1-channel type, 2-channel type, input type, output type, and I/O mixed type.

### Part description



No.	Designation	Function	
1	Transmission indicator (Green)	Blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller.	
2	Indicator A	<b>SL-VCH10</b>	Input indicator (Green): Lights up when the input is turned ON.
		<b>SL-VCH11</b>	Output indicator (Orange): Lights up when the output is turned ON.
		<b>SL-VCH20</b>	Input 1 indicator (Green): Lights up when the input 1 is turned ON.
		<b>SL-VCH21</b>	Input indicator (Green): Lights up when the input is turned ON.
3	Indicator B	<b>SL-VCH22</b>	Output 1 indicator (Orange): Lights up when the output 1 is turned ON.
		<b>SL-VCH10</b>	—
		<b>SL-VCH11</b>	—
		<b>SL-VCH20</b>	Input 2 indicator (Green): Lights up when the input 2 is turned ON.
4	Address setting switches	<b>SL-VCH21</b>	Output indicator (Orange): Lights up when the output is turned ON.
		<b>SL-VCH22</b>	Output 2 indicator (Orange): Lights up when the output 2 is turned ON.
5	Output holding function setting switch (For <b>SL-VCH11</b> , <b>SL-VCH22</b> , and <b>SL-VCH21</b> only)	Used for setting of the output holding function. ON: After detection of a transmission signal error, the current output conditions will be held (output holding). OFF: After detection of a transmission signal error, the current output conditions will not be held (output OFF).	
6	<b>S-LINK V</b> side cable	Brown: +24V, Blue: 0V, White: D, Black: G	
7	I/O device side cable	<b>SL-VCH10</b> , <b>SL-VCH20</b>	Brown: +24V, Blue: 0V, Black: Input 1, Black / Gray: Input 2 (Note 1)
		<b>SL-VCH11</b> , <b>SL-VCH22</b>	Brown: +24V, Blue: 0V, Pink: Output 1, Pink / Gray: Output 2 (Note 2)
		<b>SL-VCH21</b>	Brown: +24V, Blue: 0V, Black: Input, Pink: Output

Notes: 1) The **SL-VCH10** will not use input 2 (black / gray).

2) The **SL-VCH11** will not use output 2 (pink / gray).

• Specifications


Type	Input unit		I/O mixed unit	Output unit	
	1-channel type	2-channel type	2-channel type	1-channel type	2-channel type
Model No.	<b>SL-VCH10</b>	<b>SL-VCH20</b>	<b>SL-VCH21</b>	<b>SL-VCH11</b>	<b>SL-VCH22</b>
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)				
Current consumption	20mA or less (When input is ON, including current input)	28mA or less (When 2 points of inputs are ON, including current input)	24mA or less (When input is ON, including current input. When output is ON)	16mA or less (When output is ON)	20mA or less (When 2 points of outputs are ON.)
Allowable passing current	Total: 0.5A or less				
Address setting	Using switches, in the range of 0 to 511				
Input	Photo-coupler input • Current input: 9mA or less • Operation voltage: ON voltage: 17V or more (between +24V and input) OFF voltage: 4V or less (between +24V and input) • Input impedance: Approx. 3.4kΩ			—	
Output	—		NPN open-collector transistor (photo-isolation) • Maximum sink current: 100mA • Applied voltage: 30V DC or less (between output and 0V) • Residual voltage: 1.5V or less (at 100mA sink current) 0.4V or less (at 16mA sink current)		
Output operation	—		The output transistor will be turned on if the output signal is sent from the signal transmission line.		
Short-circuit protection	—		—		
Number of I/O points	Input: 1 point	Input: 2 points	Input: 1 point / Output: 1 point	Output 1 point	Output 2 points
Indicators	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)			
	Input	Green LED (lights up when the input is turned ON)			—
	Output	—	Orange LED (lights up when the output is turned ON)		
Output holding	—		Incorporated		
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed) (Note), Storage: -20 to +70°C			
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH			
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)			
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure			
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure			
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each			
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each			
Material	Enclosure: Polycarbonate				
Cable	<b>S-LINK V</b> side: 0.5mm <sup>2</sup> 4-core flat cable, 0.6m long I/O device side: 0.5mm <sup>2</sup> 4-core flat cable, 0.4m long				
Weight	Approx. 55g				

Note: If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units. In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

# Specifications


## I/O circuit diagram

### <Input unit>




S-LINK V system side ← Internal circuit → Input device side  
 Note: The SL-VCH10 will not use input 2 (black / gray).

### <Output unit>



S-LINK V system side ← Internal circuit → Output device side  
 Note: The SL-VCH11 will not use output 2 (pink / gray).

### <I/O mixed unit>



\*1


Non-voltage contact, NPN open-collector transistor or DC 2-wire output

- Current input: 9mA or less
- Operation voltage:  
 ON voltage: 17V or more (between +24V and input)  
 OFF voltage: 4V or less (between +24V and input)
- Input impedance: Approx. 3.4kΩ


Symbols... ZD1, ZD2: Surge absorption zener diode  
 Tr1, Tr2 : NPN output transistor

## Dimensions (Unit: mm)

### <SL-VCH□>



### <MS-CH / DIN rail mounting holder>




## Input terminal


(**SL-VTB4**: 4-channel / **SL-VTB8**: 8-channel / **SL-VTB16**: 16-channel / **SL-VTB32**: 32-channel)

### • Part description


<SL-VTB4>




<SL-VTB8>



<SL-VTB16>



<SL-VTB32>



No.	Designation	Function
1	Input terminals	Used for connection of the input device.
2	Address setting switches	Used for setting of terminal address.
3	Not Used	Not used. (Setting to the OFF status is recommended.)
4	Power indicator (Green)	This indicator will light up when the power is supplied.
5	Input indicators (Green)	Each indicator will light up when the input signal of the corresponding channel is turned ON.
6	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.
7	Transmission cable connection terminals	Used for connection of the <b>S-LINK V</b> system transmission cable. To connect the local power supply unit, connect the cable to the +24V and 0V terminals.
8	Shorting piece	Used for shorting the line between +24V and '+' or between 0V and '-.' Remove this piece to use different power supply units for the input device and the input terminal respectively.


# Specifications

## • Specifications

Type	4-channel	8-channel	16-channel	32-channel
Model No.	<b>SL-VTB4</b>	<b>SL-VTB8</b>	<b>SL-VTB16</b>	<b>SL-VTB32</b>
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)			
Current consumption (Note 1)	Unit side	25mA or less	30mA or less	35mA or less
	Input side	45mA or less (When all points are ON, including current input)	75mA or less (When all points are ON, including current input)	150mA or less (When all points are ON, including current input)
Allowable passing current (Note 2)	Total: 1A or less	Total: 2A or less	Total: 4A or less	Total: 7A or less
Address setting	Using switches, in the range of 0 to 511			
Input	Photo-coupler input: • Current input: 9mA or less • Operation voltage: ON voltage: 17V or more (between +24V and input) OFF voltage: 4V or less (between +24V and input) • Input impedance: Approx. 3.3kΩ			
Number of input points	4 points	8 points	16 points	32 points
Indicators	Power supply	Green LED (lights up when there is power between the "24V DC" power supply terminal and "0V", and between "+" and "-")		
	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)		
	Input	Green LED (lights up when the input signal of the corresponding channel is turned ON)		
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed) (Note 3), Storage: -20 to +70°C		
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH		
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)		
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure		
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure		
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each		
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each		
Mounting	Installed on DIN rail or by tightening screws			
Tightening torque	Terminal screw: 0.5N·m or less, Mounting screw: 1.2N·m or less			
Material	Enclosure: ABS, Terminal area: PBT			
Weight	Approx. 90g	Approx. 130g	Approx. 220g	Approx. 225g

- Notes: 1) The current consumption value shown in the 'Unit side' area indicates the current consumption in the main circuit.  
 2) Each value includes the current consumption of this terminal and connected machine.  
 3) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
 In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

• Input circuit diagram and terminal layout drawing



- Notes: 1) A shorting piece is used for connection of +24V to '+' or 0V to '-'.  
 2) Remove the shorting piece to use different power supply units for the input device and the input terminal respectively.

\*1

Non-voltage contact, NPN open-collector transistor or DC 2-wire output

- Current input: 9mA or less
- Operation voltage:  
 ON voltage: 17V or more [between input and +24V]  
 OFF voltage: 4V or less [between input and +24V]
- Input impedance: Approx. 3.3kΩ

8	D	9	24VDC	10	+	11	0	12	1	13	2	14	3
NT1235	WHITE	BROWN											
1	G	2	0V	3	-	4	+	5	-	6	+	7	-
	BLACK	BLUE											

SL-VTB4 terminal nameplate

12	D	13	24VDC	14	+	15	0	16	1	17	2	18	3	19	4	20	5	21	6	22	7	
NT1235	WHITE	BROWN																				
1	G	2	0V	3	-	4	+	5	-	6	+	7	-	8	+	9	-	10	+	11	-	
	BLACK	BLUE																				

SL-VTB8 terminal nameplate

21	D	22	24VDC	23	+	24	+	25	0	26	1	27	2	28	3	29	4	30	5	31	6	32	7	33	8	34	9	35	10	36	11	37	12	38	13	39	14	40	15			
NT1236	WHITE	BROWN																																								
1	G	2	0V	3	-	4	-	5	+	6	-	7	+	8	-	9	+	10	-	11	+	12	-	13	+	14	-	15	+	16	-	17	+	18	-	19	+	20	-			
	BLACK	BLUE																																								

SL-VTB16 terminal nameplate


21	D	22	24VDC	23	+	24	+	25	1	26	3	27	5	28	7	29	9	30	11	31	13	32	15	33	17	34	19	35	21	36	23	37	25	38	27	39	29	40	31				
NT1236	WHITE	BROWN																																									
1	G	2	0V	3	-	4	-	5	0	6	2	7	4	8	6	9	8	10	10	11	12	12	14	13	16	14	18	15	20	16	22	17	24	18	26	19	28	20	30				
	BLACK	BLUE																																									

SL-VTB32 terminal nameplate


# Specifications

## • Dimensions (Unit: mm)


### <SL-VTB4>



### <SL-VTB8>



### <SL-VTB16, SL-VTB32>




Note: **SL-VTB32** has a different number of input indicators (green). For a detailed description, refer to page 103.

## Output terminal


(**SL-VTBP4**: 4-channel / **SL-VTBP8**: 8-channel / **SL-VTBP16**: 16-channel **SL-VTBP32**: 32-channel)

### • Part description


<SL-VTBP4>




<SL-VTBP8>



<SL-VTBP16>



<SL-VTBP32>



No.	Designation	Function
1	Output terminal	Used for connection of the output device.
2	Address setting switches	Used for setting of terminal address.
3	Output holding function setting switch	Used for setting of the output holding function. ON: Holds the current output conditions (output holding). OFF: Will not hold the current output conditions (output OFF).
4	Power indicator (Green)	This indicator will light up when the power is supplied.
5	Output indicators (Orange)	Each indicator will light up when the output signal of the corresponding channel is turned ON.
6	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.
7	Transmission cable connection terminals	Used for connection of the <b>S-LINK V</b> system transmission cable. To connect the local power supply unit, connect the cable to the +24V and 0V terminals.
8	Shorting piece	Used for shorting the line between +24V and '+' or between 0V and '-.' Remove this piece to use different power supply units for the output device and the output terminal respectively.


# Specifications

## • Specifications

Type	4-channel		8-channel		16-channel		32-channel		
Mode No.	SL-VTBP4		SL-VTBP8		SL-VTBP16		SL-VTBP32		
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)								
Current consumption (Note 1)	Unit side	25mA or less		30mA or less		40mA or less		45mA or less	
	Output side	40mA or less (When all points are ON)		60mA or less (When all points are ON)		100mA or less (When all points are ON)		180mA or less (When all points are ON)	
Allowable passing current (Note 2)	Total: 1A or less		Total: 2A or less		Total: 4A or less		Total: 7A or less		
Address setting	Using switches, in the range of 0 to 511								
Output	NPN open-collector transistor (photo-isolation)								
	<ul style="list-style-type: none"> <li>• Maximum sink current: 200mA</li> <li>• Applied voltage: 30V DC or less (between output and 0V)</li> <li>• Residual voltage: 1.5V or less (at 200mA sink current) 0.4V or less (at 16mA sink current)</li> </ul>								
	Output operation	The output transistor will be turned on if the output signal is sent from the signal transmission line.							
Short-circuit protection	Incorporated (Note 3)								
Number of output points	4 points		8 points		16 points		32 points		
Indicators	Power	Green LED (lights up when there is power between the "24V DC" power supply terminal and "0V", and between "+" and "-")							
	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)							
	Output	Orange LED (lights up when the output signal of the corresponding channel is turned ON)							
Output holding function	Incorporated								
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed) (Note 4), Storage: -20 to +70°C							
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH							
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)							
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure							
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure							
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each							
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each							
Mounting	Mounted on DIN rail or by tightening screws								
Tightening torque	Terminal screw: 0.5N·m or less, Mounting screw: 1.2N·m or less								
Material	Enclosure: ABS, Terminal area: PBT								
Weight	Approx. 90g		Approx. 130g		Approx. 220g		Approx. 225g		

- Notes: 1) The current consumption value shown in the 'Unit side' area indicates the current consumption in the main circuit.  
The current consumption value shown in the 'output side' area indicates the current consumption in the output circuit.
- 2) Each value includes the current consumption of this terminal and connected machine.
- 3) If one of the output channels is shorted, the short-circuit protective function will be activated to protect all the channels, and outputting signals to the external machine will be stopped. Eliminate the cause of the problem, and the system will be automatically restored.
- 4) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

• Output circuit diagram and terminal layout drawing



S-LINK V system side ← Internal circuit → Output device side

- Notes: 1) A shorting piece is used for connection of +24V to '+' or 0V to '-.'
- 2) Remove the shorting piece to use different power supply units for the output device and the output terminal respectively.

Symbols... Z<sub>D</sub>: Surge absorption zener diode  
T<sub>r</sub> : NPN output transistor

8	D	9	24VDC	10	+	11	0	12	1	13	2	14	3
NT1235 WHITE		BROWN											
1	G	2	0V	3	-	4	+	5	+	6	+	7	+
BLACK		BLUE											

SL-VTBP4 model nameplate

12	D	13	24VDC	14	+	15	0	16	1	17	2	18	3	19	4	20	5	21	6	22	7	
NT1237 WHITE		BROWN																				
1	G	2	0V	3	-	4	+	5	+	6	+	7	+	8	+	9	+	10	+	11	+	
BLACK		BLUE																				

SL-VTBP8 model nameplate

21	D	22	24VDC	23	+	24	+	25	0	26	1	27	2	28	3	29	4	30	5	31	6	32	7	33	8	34	9	35	10	36	11	37	12	38	13	39	14	40	15	
NT1238 WHITE		BROWN																																						
1	G	2	0V	3	-	4	-	5	+	6	+	7	+	8	+	9	+	10	+	11	+	12	+	13	+	14	+	15	+	16	+	17	+	18	+	19	+	20	+	
BLACK		BLUE																																						

SL-VTBP16 model nameplate


21	D	22	24VDC	23	+	24	+	25	1	26	3	27	5	28	7	29	9	30	11	31	13	32	15	33	17	34	19	35	21	36	23	37	25	38	27	39	29	40	31	
NT1239 WHITE		BROWN																																						
1	G	2	0V	3	-	4	-	5	0	6	2	7	4	8	6	9	8	10	10	11	12	12	14	13	16	14	18	15	20	16	22	17	24	18	26	19	28	20	30	
BLACK		BLUE																																						

SL-VTBP32 model nameplate


# Specifications

## • Dimensions (Unit: mm)


### <SL-VTBP4>



### <SL-VTBP8>



### <SL-VTBP16, SL-VTBP32>




Note: SL-VTBP32 has a different number of output indicators (orange). For a detailed description, refer to page 107.

Connector input unit

(SL-VT4J / VT4E: 4-channel, SL-VT8J / VT8E: 8-channel)

• Part description



No.	Designation	Function
1	Input device connector	Used for connection of the input device.
2	Address setting switches	Used for setting of terminal address.
3	Not Used	Not used. (Setting to the OFF status is recommended.)
4	Power indicator (Green)	This indicator will light up when the power is supplied.
5	Input indicators (Green)	Each indicator will light up when the input signal of the corresponding channel is turned ON.
6	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.


# Specifications

## • Specifications


Type	4-channel		8-channel	
	Connector type	e-CON connector type	Connector type	e-CON connector type
Model No.	<b>SL-VT4J</b>	<b>SL-VT4E</b>	<b>SL-VT8J</b>	<b>SL-VT8E</b>
Applicable connector	Snap male connector <b>SL-CP1, SL-CP2, SL-CP3</b>	e-CON conforming connector	Snap male connector <b>SL-CP1, SL-CP2, SL-CP3</b>	e-CON conforming connector
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)			
Current consumption	70mA or less (When all points are ON, including current input)		105mA or less (When all points are ON, including current input)	
Allowable passing current (Note 1)	Total: 2A or less			
Address setting	Using switches, in the range of 0 to 511			
Input	Photo-coupler input: • Current input: 9mA or less • Operation voltage: ON voltage: 17V or more (between input and +24V) OFF voltage: 4V or less (between input and +24V) • Input impedance: Approx. 3.3kΩ			
Number of input points	4 points		8 points	
Indicators	Power	Green LED (lights up when the power is supplied)		
	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)		
	Input	Green LED (lights up when the input signal of the corresponding channel is turned ON)		
Environmental resistance	Ambient temperature (Note 2) (Note 3)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C		
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH		
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)		
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure		
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure		
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each		
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each		
Mounting	Mounted on DIN rail or by tightening screws			
Tightening torque	Mounting screw: 0.8N·m or less			
Material	Enclosure: ABS, Installation base: POM			
Cable	0.5mm <sup>2</sup> 4-core flat cable, 0.6m long			
Weight	Approx. 75g		Approx. 80g	
Accessory	Connector I/O unit mounting base: 1 pc.			

- Notes: 1) Each value includes the current consumption of this unit and connected machine.  
 2) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
 In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.  
 3) In some cases, you cannot install the same connector input units close to each other, or connector input units and other I/O units close to each other. The distance between these units depends on the ambient temperature.  
 While referring to the following figure, secure enough distance between the units.

<To horizontally install the units>




<To vertically install the units>



• Input circuit diagram and terminal layout drawing


<SL-VT□J>



\*1

- Non-voltage contact, NPN open-collector transistor or DC 2-wire output
- Current input: 9mA or less
  - Operation voltage:  
ON voltage: 17V or more [between input and +24V]  
OFF voltage: 4V or less [between input and +24V]
  - Input impedance: Approx. 3.3kΩ


<SL-VT□E>




\*1

- Non-voltage contact, NPN open-collector transistor or DC 2-wire output
- Current input: 9mA or less
  - Operation voltage:  
ON voltage: 17V or more [between input and +24V]  
OFF voltage: 4V or less [between input and +24V]
  - Input impedance: Approx. 3.3kΩ

<SL-VT□J>




<SL-VT□E>




# Specifications

## • Dimensions (Unit: mm)


### <SL-VT4J>




### <SL-VT4E>



### <SL-VT8J>




### <SL-VT8E>



Connector output unit

(SL-VTP4J / VTP4E: 4-channel, SL-VTP8J / VTP8E: 8-channel)

• Part description



No.	Designation	Function
1	Output device connector	Used for connection of the output device.
2	Address setting switches	Used for setting of address.
3	Output holding function setting switch	Used for setting of the output holding function. ON: Holds the current output conditions (output holding). OFF: Will not hold the current output conditions (output OFF).
4	Power indicator (Green)	This indicator will light up when the power is supplied.
5	Output indicators (Orange)	Each indicator will light up when the output signal of the corresponding channel is turned ON.
6	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.


# Specifications

## • Specifications


Type	4-channel		8-channel	
	Connector type	e-CON connector type	Connector type	e-CON connector type
Model No.	<b>SL-VTP4J</b>	<b>SL-VTP4E</b>	<b>SL-VTP8J</b>	<b>SL-VTP8E</b>
Applicable connector	Snap male connector <b>SL-CP1, SL-CP2, SL-CP3</b>	e-CON conforming connector	Snap male connector <b>SL-CP1, SL-CP2, SL-CP3</b>	e-CON conforming connector
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)			
Current consumption	60mA or less (when all points are ON)		90mA or less (when all points are ON)	
Allowable passing current (Note)	Total: 2A or less			
Address setting	Using switches, in the range of 0 to 511			
Output	NPN open-collector transistor (photo-isolation)			
	<ul style="list-style-type: none"> <li>• Maximum sink current: 200mA</li> <li>• Applied voltage: 30V DC or less (between output and 0V)</li> <li>• Residual voltage: 1.5V or less (at 200mA sink current) 0.4V or less (at 16mA sink current)</li> </ul>			
	Output operation	The output transistor will be turned on if the output signal is sent from the signal transmission line.		
Short-circuit protection	Incorporated (Note 2)			
Number of output points	4 points		8 points	
Indicators	Power			
	Transmission			
	Output			
Output holding function	Incorporated			
Environmental resistance	Ambient temperature (Note 3, 4)			
	Ambient humidity			
	Noise immunity			
	Voltage withstandability			
	Insulation resistance			
	Vibration resistance			
	Shock resistance			
Mounting	Mounted on DIN rail or by tightening screws			
Tightening torque	Mounting screw: 0.8N·m or less			
Material	Enclosure: ABS, Installation base: POM			
Cable	0.5mm <sup>2</sup> 4-core flat cable, 0.6m long			
Weight	Approx. 75g		Approx. 80g	
Accessory	Connector I/O unit mounting base: 1 pc.			

- Notes: 1) Each value includes the current consumption of this unit and connected machine.  
 2) If one of the output channels is shorted, the short-circuit protective function will be activated to protect all the channels, and outputting signals to the external machine will be stopped. Eliminate the cause of the problem, and the system will be automatically restored.  
 3) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
 In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.  
 4) In some cases, you cannot install the same connector output units close to each other, or connector output units and other I/O units close to each other. The distance between these units depends on the ambient temperature.  
 While referring to the following figure, secure enough distance between the units.

<To horizontally install the units>




<To vertically install the units>




• Output circuit diagram and terminal layout drawing

<SL-VTP□J>




Symbols... Z<sub>D</sub>: Surge absorption zener diode  
T<sub>r</sub>: NPN output transistor

<SL-VTP□E>




Symbols... Z<sub>D</sub>: Surge absorption zener diode  
T<sub>r</sub>: NPN output transistor

<SL-VTP□J>




<SL-VTP□E>




# Specifications

## • Dimensions (Unit: mm)


### <SL-VTP4J>




### <SL-VTP4E>



### <SL-VTP8J>




### <SL-VTP8E>



## MIL connector input unit

(SL-VT16C1: 16-channel)

### • Part description



No.	Designation	Function
1	MIL connector for input device	Used for connection of the input device.
2	Address setting switches	Used for setting of terminal address.
3	Not Used	Not used. (Setting to the OFF status is recommended.)
4	Input indicators (Green)	Each indicator will light up when the input signal of the corresponding channel is turned ON.
5	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.

# Specifications

## • Specifications


Type	MIL connector input unit	
Model No.	<b>SL-VT16C1</b>	
Applicable connector	20-pin MIL connector (header) (Note 1)	
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)	
Current consumption	80mA or less (when all points are ON)	
Allowable passing current (Note 2)	Total: 1.2A or less	
Address setting	Using switches, in the range of 0 to 511	
Input	Photo-coupler input: <ul style="list-style-type: none"> <li>• Current input: 5mA or less</li> <li>• Operation voltage:  ON voltage: 17V or more (between input and +24V)  OFF voltage: 4V or less (between input and +24V)</li> <li>• Input impedance: Approx. 6.3kΩ</li> </ul>	
Number of input points	16 points	
Transmission indicator	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)	
Input indicator	Green LED (lights up when the input signal of the corresponding channel is turned ON)	
Environmental resistance	Ambient temperature (Note 3, 4)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each
Mounting	Mounted on DIN rail or by tightening screws	
Tightening torque	Mounting screw: 0.8N·m or less	
Material	Enclosure: ABS, Mounting base: POM	
Cable	0.5mm <sup>2</sup> 4-core flat cable, 0.6m long	
Weight	Approx. 80g	
Accessory	Connector I/O unit mounting base: 1 pc.	

Notes: 1) Purchase separately a compliant product with MIL-C-83503.


2) Each value includes the current consumption of this unit and connected machine.

3) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

4) In some cases, you cannot install the same **SL-VT16C1** units close to each other, or **SL-VT16C1** units and other I/O units close to each other. The distance between these units depends on the ambient temperature.  
While referring to the following figure, secure enough distance between the units.




To horizontally install the units



To vertically install the units




• Input circuit diagram and terminal layout drawing



\*1

- Non-voltage contact, NPN open-collector transistor or DC 2-wire output
- Current input: 5mA or less
  - Operation voltage:  
ON voltage: 17V or more [between input and +24V]  
OFF voltage: 4V or less [between input and +24V]
  - Input impedance: Approx. 6.3kΩ


• Dimensions (Unit: mm)



MIL connector output unit

(SL-VTP16C1, SL-VTP16C1-S: 16-channel)

● Part description




No.	Designation	Function
1	MIL connector for output device	Used for connection of the output machine. (The above figure shows the <b>SL-VTP16C1</b> . In the <b>SL-VTP16C1-S</b> , the MIL connector is in a different direction compared with that of the <b>SL-VTP16C1</b> . For a detailed description, refer to page 124.)
2	Address setting switches	Used for setting of address.
3	Output holding function setting switch	Used for setting of the output holding function. ON: Holds the current output conditions (output holding). OFF: Will not hold the current output conditions (output OFF).
4	Output indicators (Orange)	Each indicator will light up when the output signal of the corresponding channel is turned ON.
5	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.


• Specifications

Type	MIL connector output unit	
Model No.	SL-VTP16C1	SL-VTP16C1-S
Applicable connector	20-pin MIL connector (header) (Note 1)	
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)	
Current consumption	50mA or less (when all points are ON)	
Allowable passing current (Note 2)	Total: 1.2A or less	
Address setting	Using switches, in the range of 0 to 511	
Output	NPN open-collector transistor (photo-isolation)	
	<ul style="list-style-type: none"> <li>• Maximum sink current: 100mA</li> <li>• Applied voltage: 30V DC or less (between output and 0V)</li> <li>• Residual voltage: 1.5V or less (at 100mA sink current)</li> </ul>	
	0.4V or less (at 16mA sink current)	
Output operation	The output transistor will be turned on if the output signal is sent from the signal transmission line	
Short-circuit protection	Incorporated (Note 3)	
Number of output points	16 points	
Transmission indicator	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)	
Output indicator	Orange LED (lights up when the output signal of the corresponding channel is turned ON)	
Output holding function	Incorporated	
Environmental resistance	Ambient temperature (Note 4, 5)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each
Mounting	Mounted on DIN rail or by tightening screws	
Tightening torque	Mounting screw: 0.8N·m or less	
Material	Enclosure: ABS, Mounting base: POM	
Cable	0.5mm <sup>2</sup> 4-core flat cable, 0.6m long	
Weight	Approx. 80g	
Accessory	Connector I/O unit mounting base: 1 pc.	

- Notes: 1) Purchase separately a compliant product with MIL-C-83503.  
 2) Each value includes the current consumption of this unit and connected machine.  
 3) If one of the output channels is shorted, the short-circuit protective function will be activated to protect all the channels, and outputting signals to the external machine will be stopped. Eliminate the cause of the problem, and the system will be automatically restored.  
 4) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
 In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.  
 5) In some cases, you cannot install the same **SL-VTP16C1(-S)** units close to each other, or **SL-VTP16C1(-S)** units and other I/O units close to each other. The distance between these units depends on the ambient temperature.  
 While referring to the following figure, secure enough distance between the units.



To horizontally install the units





To vertically install the units




# Specifications

## • Output circuit diagram and terminal layout drawing




Symbols...  $Z_d$ : Surge absorption zener diode  
 $T_r$ : NPN output transistor

## • Dimensions (Unit: mm)



## Analogue input unit

### ● Part description



No.	Designation	Function															
1	Terminal connector	I	Current input terminal														
		COM	Analogue GND														
		V	Pressure input terminal														
		COM	Analogue GND														
		NC	Not connected														
		24V	Power supply for external synchronization input device +24V (output)														
		0V	Power supply for external synchronization input device 0V														
		ES	External synchronization input terminal														
2	Input range setting switch (Note)	1	NOT USED														
		2	NOT USED														
		3	RANGE-1	Switch for input range													
		4	RANGE-2														
		5	ES	Valid / Invalid of the external synchronization input is set. (ON side: valid) In case the external synchronization input is valid, A/D conversion is carried out only when the input is ON and the data is stored when it is OFF.													
		6	AVERAGE	Valid / Invalid of the averaging process is set. (ON side: valid) In case the averaging process is valid, the previously taken A/D conversion data (max. of 99 times) and the current data are averaged to carry out A/D conversion. The response time is approx. 50ms (Excluding the delay of <b>S-LINK V</b> response time)													
		7	HOLD	Valid / Invalid of the hold function is set. (ON side: valid) This is used along with PEAK / BOTTOM switch.													
		8	PEAK / BOTTOM	Can be used when the hold function is valid. (ON side: BOTTOM) When set to PEAK, the max. value of the data is maintained. When set to BOTTOM, the min. value of the data is maintained.													
		<table border="1"> <thead> <tr> <th>Input range</th> <th>RANGE-1</th> <th>RANGE-2</th> </tr> </thead> <tbody> <tr> <td>4 to 20mA</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>+1 to +5V</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>0 to +10V</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>-10 to +10V</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	Input range	RANGE-1	RANGE-2	4 to 20mA	OFF	OFF	+1 to +5V	ON	OFF	0 to +10V	OFF	ON	-10 to +10V	ON	ON
Input range	RANGE-1	RANGE-2															
4 to 20mA	OFF	OFF															
+1 to +5V	ON	OFF															
0 to +10V	OFF	ON															
-10 to +10V	ON	ON															
3	Address setting switch	Address is set.															
4	Power indicator (Green)	Lights up when the power is ON.															
5	Transmission indicator (Green)	Blinks to indicate the synchronization signal transmission from <b>S-LINK V</b> controller.															
6	External synchronizaion signal input indicator (Green)	Lights up when external synchronization signal is input.															
7	Error indicator (Red)	Lights up when an error occurs.															

Note: Each setting is independent respectively.

## Specifications

### • Specifications

Designation		Analogue input unit
Model No.		<b>SL-VTAD1</b>
Supply voltage		24V DC±10% (supplied from the <b>S-LINK V</b> controller or separate power supply)
Current consumption		80mA or less (excluding connecting device)
Address setting		0 to 511, settable with switch (Note 1, 2)
Resolution		1/4,000 (12 bits)
Total accuracy		Within ±0.8% F.S. (at -10 to +55°C ambient temperature)
Analogue input	Channel No.	1 channel
	Input range	Selectable with switch <ul style="list-style-type: none"> <li>• Current input: 4 to 20mA</li> <li>• Voltage input: +1 to +5V, 0 to +10V, -10 to +10V</li> </ul>
	Input impedance	Current input: Approx. 250Ω, Voltage input: Approx. 1MΩ
External synchronization input		Photocoupler input <ul style="list-style-type: none"> <li>• Input current: 9mA or less</li> <li>• Operation voltage:  ON voltage 17V or more (between input and +24V)  OFF voltage 4V or less (between input and +24V)</li> <li>• Input impedance: Approx. 3.3kΩ</li> </ul>
Data conversion time		Approx. 1ms (excluding the delay of <b>S-LINK V</b> system transmission time)
Occupied input No.		16 points
Indicators	Power	Green LED (lights up when the power is ON)
	Transmission	Green LED (blinks to indicate the synchronization signal transmission from <b>S-LINK V</b> controller)
	External synchronization signal input	Green LED (lights up when external synchronization signal is input)
	Error	Red LED (lights up when error occurs)
Environmental resistance	Ambient temperature (Note 3)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
Shock resistance		490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each
Mounting		Mounted on DIN rail or by tightening screws
Tightening torque		Mounting screw: 0.8N·m or less
Material		Enclosure: ABS, Mounting base: POM
Cable		0.5mm <sup>2</sup> 4-core flat cable, 0.6m long
Weight		Approx. 100g
Accessory		Analogue input unit mounting base: 1pc.

Notes: 1) The data of the address exceeding I/O control points is invalid.


2) Be sure to set the 'NOT USED' switch to 'OFF.' If the switch is set to 'ON,' this unit doesn't operate properly.

3) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.


In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

• Input circuit diagrams and terminal layout drawing


<Current input>



<Voltage input>




<External synchronization input>




\*1

- Non-voltage contact, NPN open-collector transistor or DC 2-wire output
- Current input: 9mA or less
  - Operation voltage:  
ON voltage: 17V or more [between input and +24V]  
OFF voltage: 4V or less [between input and +24V]
  - Input impedance: Approx. 3.3kΩ

When the shield cable is used, connect the shield wire to the frame ground etc. in the analogue output device side. However, take care that there may be cases where it is better not to connect the shield wire depending on the mounting conditions.




# Specifications




No.	Terminal	Function
1	I	Current input terminal
2	COM	Analogue GND
3	V	Voltage input terminal
4	COM	Analogue GND
5	NC	Not connected
6	24V	Power supply for external synchronization input device +24V (output)
7	0V	Power supply for external synchronization input device 0V
8	ES	External synchronization input terminal

## ● Analogue input and conversion data


### ● 4 to 20mA range




### ● +1 to +5V range



### ● 0 to +10V range



### ● -10 to +10V range



• **Data bit**


- Data bit has been allocated as shown in the table below.

Data bit	Signal
IN 0	Conversion data 0 bit (LSB)
IN 1	Conversion data 1 bit
IN 2	Conversion data 2 bit
IN 3	Conversion data 3 bit
IN 4	Conversion data 4 bit
IN 5	Conversion data 5 bit
IN 6	Conversion data 6 bit
IN 7	Conversion data 7 bit
IN 8	Conversion data 8 bit
IN 9	Conversion data 9 bit
IN 10	Conversion data 10 bit
IN 11	Conversion data 11 bit (MSB)
IN 12	Input range 1
IN 13	Input range 2
IN 14	External synchronization input
IN 15	Error

• **Conversion process**


<Time chart for normal conversion>

- A/D conversion in normal conversion is carried out every approx. 500µs. When taking in the conversion data (internal process), the latest A/D conversion data and current data are averaged.




<Time chart for averaging process conversion>

- A/D conversion in averaging process conversion is carried out every approx. 500µs. When taking in the conversion data (internal process), the previously taken A/D conversion data (max. of 99 times) and the current data are averaged. When the data to take in exceeds 100 times, the earliest A/D conversion data is automatically erased. For example, in case the data to take is 101th, the A/D conversion data of 2nd to 101th are averaged. At this time, the 1st A/D conversion data is automatically erased.




# Specifications

## • Dimensions (Unit: mm)



## Analogue output unit

- Part description



No.	Description	Function	
1	Terminal block connector	I	Current output terminal (4 to 20mA)
		COM	Analogue GND
		V1	Voltage output terminal (+1 to +5V)
		COM	Analogue GND
		V2	Voltage output terminal (0 to +10V)
		COM	Analogue GND
		V3	Voltage output terminal ( $\pm 10V$ )
		COM	Analogue GND
2	Address setting switch	Address is set.	
3	Output hold setting switch	It is used to set the output hold function.	
4	Power indicator (Green)	Lights up when the power is ON.	
5	Transmission indicator (Green)	Blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller	

## Specifications

### • Specifications


Designation		Analogue output unit
Model No.		<b>SL-VTDA1</b>
Supply voltage		24V DC±10% (supplied from the <b>S-LINK V</b> controller or separate power supply)
Current consumption		90mA or less (excluding connecting device)
Address setting		0 to 511, settable with switch (Note 1)
Resolution		1/4,000 (12 bits)
Total accuracy		Within ±0.8%F.S. (at -10 to +55°C ambient temperature)
Analogue output	Channel No.	1 channel
	Output range	Selectable with switch <ul style="list-style-type: none"> <li>• Current output: 4 to 20mA</li> <li>• Voltage output: +1 to +5V 0 to +10V -10 to +10V</li> </ul>
	Output allowable load resistance	Current output: 250Ω or less, Voltage output: 1kΩ or more
Data conversion time		Approx. 1ms (excluding the delay of <b>S-LINK V</b> system transmission time)
Occupied output No.		12 points
Power indicator		Green LED (lights up when the power is ON)
Transmission indicator		Green LED (blinks to indicate the synchronization signal transmission from <b>S-LINK V</b> controller)
Output holding function		Incorporated
Environmental resistance	Ambient temperature (Note 2)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
Shock resistance		490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each
Mounting		Mounted on DIN rail or by tightening screws
Tightening torque		Mounting screw: 0.8N·m or less
Material		Enclosure: ABS, Mounting base: POM
Cable		0.5mm <sup>2</sup> 4-core flat cable, 0.6m long
Weight		Approx. 100g
Accessory		Analogue output unit mounting base: 1pc.

Notes: 1) The data of the address exceeding I/O control points is invalid.



2) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.

In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.

• Output circuit diagrams and terminal layout drawing




When the shield cable is used, connect the shield wire to the frame ground etc. in the analogue input device side. However, take care that there may be cases where it is better not to connect the shield wire depending on the mounting conditions.




No.	Terminal	Function
1	I	Current output terminal (4 to 20mA)
2	COM	Analogue GND
3	V1	Voltage output terminal (+1 to +5V)
4	COM	Analogue GND
5	V2	Voltage output terminal (0 to +10V)
6	COM	Analogue GND
7	V3	Voltage output terminal (-10 to +10V)
8	COM	Analogue GND

● Analogue output and conversion data


● 4 to 20mA range




● +1 to +5V range



● 0 to +10V range



● -10 to +10V range




● Data bit

• Data bit has been allocated as shown in the table below.

Data bit	Signal
OUT 0	Conversion data 0 bit (LSB)
OUT 1	Conversion data 1 bit
OUT 2	Conversion data 2 bit
OUT 3	Conversion data 3 bit
OUT 4	Conversion data 4 bit
OUT 5	Conversion data 5 bit
OUT 6	Conversion data 6 bit
OUT 7	Conversion data 7 bit
OUT 8	Conversion data 8 bit
OUT 9	Conversion data 9 bit
OUT 10	Conversion data 10 bit
OUT 11	Conversion data 11 bit (MSB)

• Dimensions (Unit: mm)




Relay output terminal


(SL-VTPR4: 4-channel, SL-VTPR8: 8-channel)

● Part description

<SL-VTPR4>



<SL-VTPR8>



No.	Designation	Function
1	Address setting switches	Used for setting of the terminal address.
2	Output holding function setting switch	Used for setting of the output holding function. ON: Hold the current output conditions (output holding). OFF: Will not hold the current output conditions (output OFF).
3	Power indicator (Green)	This indicator will light up when the power is supplied.
4	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.
5	Operation indicator (Orange)	Lights up when each output relay is turned ON.
6	Relay remover key	Use this key to remove the output relays.
7	Output relay	PA-N relay APAN3124 manufactured by Panasonic Corporation. (Note)
8	Terminal block	Used for connection of output devices.

Note: You can replace the output relays.

● Specifications

Type	4-channel	8-channel	
Model No.	<b>SL-VTPR4</b>	<b>SL-VTPR8</b>	
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)		
Current consumption	90mA or less (When all points are ON)	150mA or less (When all points are ON)	
Address setting	Using switches, in the range of 0 to 511		
Output	Relay contact 1a (Note 1) • Switching capacity: 50V, 3A AC (resister load) However, if compatibility with the CE is not necessary, use of 250V, 3A AC is possible. 30V, 3A DC (resister load) • Electrical service life: 100,000 times of operation or more (rated load, switching frequency of 20 times/min) • Mechanical service life: 20,000,000 times of operation or more (switching frequency of 180 times/min)		
	Output operation	The output relay is turned ON if the output signal from the signal transmission line is turned ON.	
Number of output points	4 points	8 points	
Indicators	Power	Green LED (lights up when the power is supplied)	
	Transmission	Green LED (blinks when the synchronization signal is sent from the <b>S-LINK V</b> controller)	
	Operation	Orange LED (lights up when each channel relay is turned ON)	
Output holding function	Incorporated		
Environmental resistance	Ambient temperature (Note 2)	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C	
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH	
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)	
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure	
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure	
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each	
	Shock resistance	490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for two hours each	
Mounting	Mounted on DIN rail or by tightening screws		
Tightening torque	Mounting screw: 0.8N·m or less		
Material	Enclosure: PC-ABS resin, Cover: Polycarbonate, DIN rail stopper: POM, Relay remover key: POM		
Cable	0.5mm <sup>2</sup> 4-core flat cable, 0.6m long		
Weight	Approx. 100g	Approx. 160g	
Accessories	Cover: 1 pc., Switch cap: 1 pc., Relay remover key: 1 pc.		


Notes: 1) This product is incorporated with the PA-N relay manufactured by Panasonic Corporation. However, when you replace the relay, you can also use the PhotoMOS relay manufactured by Panasonic Corporation.  
 For a detailed description, refer to the Instruction Manual enclosed with the **SL-VTPR**.

2) If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
 In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.


\*Ambient temperature and number of photoMOS relay ON points - Load current characteristics

The upper limit value of the load current depends on the ambient temperature and the number of photoMOS relay ON points.


**SL-VTPR8+AQZ202D**




**SL-VTPR8+AQZ204D**



**SL-VTPR8+AQZ205D**




**SL-VTPR8+AQZ207D**




# Specifications

## • Output circuit diagram (for 1 channel) and terminal layout drawing




### <SL-VTPR4>



Output	Output 0	Output 1	Output 2	Output 3
Terminal No.	5	6	7	8
	1	2	3	4


### <SL-VTPR8>




Output	Output 0	Output 1	Output 2	Output 3	Output 4	Output 5	Output 6	Output 7
Terminal No.	9	10	11	12	13	14	15	16
	1	2	3	4	5	6	7	8

## • Dimensions (Unit: mm)

### <SL-VTPR4>



### <SL-VTPR8>




## Input module

(**SL-VM8**: 8-channel, **SL-VM16**: 16-channel)

### • Specifications


Type	8-channel	16-channel
Model No.	<b>SL-VM8</b>	<b>SL-VM16</b>
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)	
Current consumption (24V DC)	18mA or less (Note 1)	20mA or less (Note 1)
Address setting	0 to 511 (Set by No.19 to 28)	
Input	Photo-coupler input: • Current input: 6mA or less • Operation voltage: ON voltage: 17V or more [between COM. (+) and IN] OFF voltage: 4V or less [between COM. (+) and IN] • Input impedance: Approx. 6.5kΩ	
Number of input points	8 points	16 points
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
Weight	Approx. 15g	

- Notes: 1) This value does not include the current consumption of the connected input device.  
 2) The power supply circuit of this product does not have any short-circuit protective function. Adopt a short-circuit protective function, such as a fuse, for the power supply circuit.  
 3) In some cases, you cannot install the same **SL-VM16** units close to each other, or **SL-VM16** unit and **SL-VMP16** unit close to each other. The distance between these units depends on the ambient temperature. While referring to the following figure, secure enough distance between the units.



# Specifications


## • Input circuit diagram and pin layout drawing



\*1

Non-voltage contact, NPN open-collector transistor or DC 2-wire output


- Current input: 6mA or less
- Operation voltage:
  - ON voltage: 17V or more [between COM. (+) and IN]
  - OFF voltage: 4V or less [between COM. (+) and IN]
- Input impedance: Approx. 6.5kΩ



Pin No.	Description	Pin No.	Description
1	COM. (+)	18	N.C.
2	IN 0	19	ADD. (256)
3	IN 1	20	ADD. (128)
4	IN 2	21	ADD. (64)
5	IN 3	22	ADD. (32)
6	IN 4	23	ADD. (16)
7	IN 5	24	ADD. (8)
8	IN 6	25	ADD. (4)
9	IN 7	26	ADD. (2)
10	IN 8	27	ADD. (1)
11	IN 9	28	ADD. (COM.)
12	IN 10	29	N.C.
13	IN 11	30	GND
14	IN 12	31	SEND
15	IN 13	32	G
16	IN 14	33	D
17	IN 15	34	0V
-	-	35	+24V

- Notes: 1) In case of connecting DC 2-wire output device to the input, a bleeder resistance  $R_B$  may be needed separately between COM. (+) and IN.
- 2) Pin No.10 to 17 of the **SL-VM8** will be the N.C. pins (non-connected pins).
- 3) Pin No.28 [ADD. (COM.)] is shorted to pin No.19 to 27 [ADD. (256) to ADD. (1)], and sum total of their address numbers will be the first address.
- 4) Pin No.34 (0V), pin No.32 (G), pin No.30 (GND), and pin No.28 [ADD. (COM.)] are electrically insulated inside the unit. Do not short these pins.

## • Dimensions (Unit: mm)




## Output module

(**SL-VMP8**: 8-channel, **SL-VMP16**: 16-channel)


### • Specifications

Type	8-channel	16-channel	
Model No.	<b>SL-VMP8</b>	<b>SL-VMP16</b>	
Supply voltage	24V DC±10% (Supplied from <b>S-LINK V</b> controller or separate power supply)		
Current consumption (24V DC)	60mA or less (Note 1)	95mA or less (Note 1)	
Address setting	0 to 511 (Set by pins No. 19 to 28)		
Output	NPN open-collector transistor (photo-isolation) • Maximum sink current: 100mA • Applied voltage: 30V DC or less (between output and 0V) • Residual voltage: 1.5V or less (at 100mA sink current) 0.4V or less (at 16mA sink current)		
	Output operation	The output transistor will be turned on if the output signal is sent from the signal transmission line.	
	Short-circuit protection	Incorporated (Note 2)	
Number of output points	8 points	16 points	
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C	
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH	
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)	
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each	
Weight	Approx. 15g		


- Notes: 1) This value does not include the current consumption and the output load current of the connected output machine.  
 2) If one of the output channels is shorted, the short-circuit protective function will be activated to protect all the channels, and outputting signals to the external machine will be stopped. Eliminate the cause of the problem, and the system will be automatically restored.  
 3) The power supply circuit of this product does not have any short-circuit protective function. Adopt a short-circuit protective function, such as a fuse, for the power supply circuit.  
 4) In some cases, you cannot install the same **SL-VMP16** units close to each other, or **SL-VMP16** unit and **SL-VM16** unit close to each other. The distance between these units depends on the ambient temperature. While referring to the following figure, secure enough distance between the units.



● Output circuit diagram and pin layout drawing




Symbols... Z<sub>D</sub>: Surge absorption zener diode  
Tr : NPN output transistor



Pin No.	Description	Pin No.	Description
1	COM. (-) Output common	-	-
2	OUT 0	19	ADD. (256)
3	OUT 1	20	ADD. (128)
4	OUT 2	21	ADD. (64)
5	OUT 3	22	ADD. (32)
6	OUT 4	23	ADD. (16)
7	OUT 5	24	ADD. (8)
8	OUT 6	25	ADD. (4)
9	OUT 7	26	ADD. (2)
10	OUT 8	27	ADD. (1)
11	OUT 9	28	ADD. (COM.)
12	OUT 10	29	HOLD Hold setting input (Note 3)
13	OUT 11	30	GND Grounding
14	OUT 12	31	SEND Transmission indicator output
15	OUT 13	32	G Transmission signal input
16	OUT 14	33	D Transmission signal input
17	OUT 15	34	0V
18	N.C. Non-connection	35	+24V Power input


- Notes: 1) Pin No.10 to 17 of the **SL-VMP8** will be the N.C. pins (non-connected pins).  
 2) Pin No.28 [ADD. (COM.)] is shorted to pin No.19 to 27 [ADD. (256) to ADD. (1)], and sum total of their address numbers will be the first address.  
 3) Open the line between pin No.29 (HOLD) and pin No.28 [ADD. (COM.)] to set the 'HOLD OFF' mode. Short this line to set the 'HOLD ON' mode.  
 4) Pin No.34 (0V), pin No.32 (G), pin No.30 (GND), and pin No.28 [ADD. (COM.)] are electrically insulated inside the unit. Do not short these pins.

● Dimensions (Unit: mm)



## Picking switch

- Part description



No.	Designation	Function
1	Infrared communication part	Exclusive address setting remote controller <b>SL-VAR1</b> (optional) signal transmission and reception department.
2	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.
3	Lamp	You can select the LED color (red, green, or blue) or two-stage indication mode. *For a detailed description of two-stage indication mode, refer to page 144.
4	4 pin type snap male connector	An <b>SL-CP2</b> is included as a connector to connect the main cable and branch cable of the <b>S-LINK V</b> .
5	Lever switch	When the lever switch is tilted 15° or more, the input goes ON.

# Specifications

## • Specifications

Designation	Picking switch	
Model No.	<b>SL-VPK01</b>	
Supply voltage	24V DC±10% (supplied from the <b>S-LINK V</b> controller or separate power supply)	
Current consumption	24V DC line 25mA or less (when lamp is ON)	
Transmission specification	Based on <b>S-LINK V</b> protocol	
Transmission mode	B mode, C mode	
Connecting method	Multi-drop connection	
Address settings	Input address (lever switch): 0 to 255 Output address (lamp): Select an offset of +32, +64, +128 or +256 for the input address Set with the address setting remote controller <b>SL-VAR1</b> (Ver.1.00 or later) (optional).	
Input operation	On when the lever switch is tilted 15° or more or when the lever switch is pulled 1.6mm or more vertically (Note 1)	
Number of I/O	Lever input: 1 point, Lamp output: 1 point	
Lamp	Lamp color (LED): Select from green, red, blue, and green / blue (Note 2). When the output signal from the signal transmission line is ON: Lamp lights up. When the output signal from the signal transmission line is OFF: Lamp turns OFF.	
Transmission indicator	Green LED (blinks to indicate the synchronization signal transmission from <b>S-LINK V</b> controller)	
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation allowed), Storage: -20 to +60°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp-p (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	50MΩ, or more, with 250V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm in X, Y and Z directions for three times each
	Shock resistance	98m/s <sup>2</sup> acceleration in X, Y and Z directions for three times each
Mounting	Mounted on pipe	
Material	Product case: Polycarbonate, Lamp cover: Polycarbonate Rear case: SGMCC (Steel plate treated with high corrosion resistant hot-dip plating) Pipe mounting holder: SPCC (Cold-rolled steel plate)	
Cable	0.5mm <sup>2</sup> 4-core cabtyre cable, 0.15m long with connector ( <b>SL-CP2</b> )	
Weight	Approx. 200g	
Accessory	ø28 pipe mounting holder: 1 pc., Hexagon socket head cop screw for fixing holder [M6 (length: 15mm)]: 1 pc.	



This product cannot be used in mode A (transmission mode).

- Notes 1) Pulling load is less than 19.6N. Make sure that stress by forcible bend or pulling is not applied directly to the lever switch.  
2) Selecting "green / blue" as the lamp color sets the lamp to two-stage indication mode.


### <Two-stage indication mode>

- In two-stage indication mode, the lamp changes from lighting up in green to blinking in blue.

### Overview of operation


- When the signal output from the signal transmission line to the lamp address ("output signal") turns ON, the lamp lights up in green.
- The lever switch input turns ON while the output signal is ON.
- When the output signal turns OFF, the lamp starts blinking in blue.
- When the output signal turns ON once more and then OFF, the lamp stops blinking in blue and turns OFF.

**Timing chart**




S-LINK V Number of I/O points	Lamp signal T (ms)		S-LINK V Number of I/O points	Lamp signal T (ms)	
	B mode	C mode		B mode	C mode
32	10.84	43.36	288	48.47	193.89
64	15.54	62.18	320	53.18	212.70
96	20.25	80.99	352	57.88	231.52
128	24.95	99.81	384	62.58	250.34
160	29.66	118.62	416	67.29	269.15
192	34.36	137.44	448	71.99	287.97
224	39.06	156.26	480	76.70	306.78
256	43.77	175.07	512	81.40	325.60

● **Dimensions (Unit: mm)**



Picking switch for shutter


● Part description



No.	Designation	Function
1	Infrared communication part	Exclusive address setting remote controller <b>SL-VAR1</b> (optional) signal transmission and reception department.
2	Transmission indicator (Green)	This indicator will blink when the synchronization signal is sent from the <b>S-LINK V</b> controller.
3	Lamp	You can select the LED color (red, green, or blue) or two-stage indication mode. *For a detailed description of two-stage indication mode, refer to page 147.
4	4 pin type snap male connector	An <b>SL-CP2</b> is included as a connector to connect the main cable and branch cable of the <b>S-LINK V</b> .
5	Lever switch	Operating the lever switch turns the input ON.
6	Movable arm	The arm to which the shutter is attached

● Specifications

Designation	Picking switch for shutter	
Model No.	<b>SL-VPK02</b>	
Supply voltage	24V DC±10% (supplied from the <b>S-LINK V</b> controller or separate power supply)	
Current consumption	24V DC line 25mA or less (when lamp is ON), Current for shutter operation: 450mA or less	
Transmission specification	Based on <b>S-LINK V</b> protocol	
Transmission mode	B mode, C mode	
Connecting method	Multi-drop connection	
Address settings	Input address (lever switch): 0 to 255 Output address (lamp, shutter): Select an offset of +32, +64, +128 or +256 for the input address Set with the address setting remote controller <b>SL-VAR1</b> (Ver.1.01 or later) (optional).	
Input operation	Tilting the lever switch at an angle between 15° and 30° turns the input ON, or pulling the lever switch approx. 2mm or more turns the input ON. (Note 1)	
Number of I/O	Lever input: 1 point, Lamp or shutter output: 1 point	
Lamp	Lamp color (LED): Select from green, red, blue, and green / blue (Note 2). When the output signal from the signal transmission line is ON: Lamp lights up. When the output signal from the signal transmission line is OFF: Lamp turns OFF.	
Transmission indicator	Green LED (blinks to indicate the synchronization signal transmission from <b>S-LINK V</b> controller)	
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation allowed), Storage: -20 to +60°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp-p (with noise simulator)
	Voltage withstandability	500V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	50MΩ, or more, with 250V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm in X, Y and Z directions for three times each
	Shock resistance	98m/s <sup>2</sup> acceleration in X, Y and Z directions for three times each
Mounting	Mounted on pipe	
Material	Front cover: Polycarbonate, Lamp cover: Polycarbonate, Rear case: ABS, Pipe mounting holder :SPCC Driving shaft: SUM, Arm: SPCC	
Cable	0.5mm <sup>2</sup> 4-core cabtyre cable, 0.15m long with connector ( <b>SL-CP2</b> )	
Weight	Approx. 250g	
Accessory	ø28 Pipe mounting holder: 1 pc., Arm plate: 1 pc., Plate-fixing screws [M4(length: 12mm)]: 2 pcs. Plate-fixing spring washer: 2 pcs., Holder-fixing socket head hex bolt [M6 (length: 15mm)]: 1 pc.	

	This product cannot be used in mode A (transmission mode).
-------------------------------------------------------------------------------------	------------------------------------------------------------

Notes 1) Pulling load is less than 19.6N. Make sure that stress by forcible bend or pulling is not applied directly to the lever switch.  
2) Selecting “green / blue” as the lamp color sets the lamp to two-stage indication mode.

<Two-stage indication mode>


- In two-stage indication mode, the lamp changes from lighting up in green to blinking in blue.

**Overview of operation**

- When the signal output from the signal transmission line to the lamp address (“output signal”) turns ON, the lamp lights up in green.
- The lever switch input turns ON while the output signal is ON.
- When the output signal turns OFF, the lamp starts blinking in blue.
- When the output signal turns ON once more and then OFF, the lamp stops blinking in blue and turns OFF.



# Specifications

## Timing chart




S-LINK V Number of I/O points	Lamp signal T (ms)		S-LINK V Number of I/O points	Lamp signal T (ms)	
	B mode	C mode		B mode	C mode
32	5.42	21.68	288	24.24	96.94
64	7.77	31.09	320	26.59	106.35
96	10.12	40.50	352	28.94	115.76
128	12.48	49.90	384	31.29	125.17
160	14.83	59.31	416	33.64	134.58
192	17.18	68.72	448	36.00	143.98
224	19.53	78.13	480	38.35	153.39
256	21.88	87.54	512	40.70	162.80

## • Dimensions (Unit: mm)



## Address setting remote controller

### ● Part description




No.	Designation	Function
1	Infrared communication part	The light emitting and receiving part for infrared communication. (Position the infrared communication part so that it faces the picking switch <b>SL-VPK0</b> at a distance of 100mm or less.)
2	SEND indicator (Red)	Blinks at the time of signal transmission.
3	Setting item display (Yellow)	Displays the setting mode in 7 segments.
4	Setting contents display (Red)	Displays the setting contents in 7 segments.
5	UP / DOWN key	Adjustment key for setting input.
6	STD BY key	Power key. Pressing this key will change between ON / OFF.
7	LEFT / RIGHT key	Setting mode and input digit change key.
8	ENTER key	Determines the setting contents.
9	WRITE key	Writes the settings made with the remote controller to the <b>SL-VPK0</b> .
10	READ key	Loads the picking switch <b>SL-VPK0</b> settings.
11	ESCAPE key	Press this key to delete the set contents.
12	RECV key	Blinks when a signal is being received.

# Specifications

## • Specifications

Designation	Address setting remote controller	
Model No.	<b>SL-VAR1</b>	
Version	Ver.101	
Compatible model	<b>SL-VPK01, SL-VPK02</b>	
Power supply	AAA alkaline batteries: 2 pcs	
Battery life	24 hours continuous use (Ambient temperature: +25°C)	
Auto sleep	Incorporated (3 minutes)	
Transmission method	Infrared (using the Association for Electric Home Appliances format)	
Emitting element	Infrared LED (940nm)	
Receiving element	Remote controller sensor module	
Subcarrier frequency	36.7kHz	
Setting distance	100mm or less	
Setting name display	7 segments yellow LED	
Setting content display	7 segments red LED	
SEND indicator	Red LED (Blinks at the time of signal transmission.)	
RECV indicator	Green LED (Blinks when a signal is being received.)	
Setting mode	<ul style="list-style-type: none"> <li>• Selected model: <b>SL-VPK01, SL-VPK02</b></li> <li>• Input address setting: 0 to 255</li> <li>• Address off set: +32, +64, +128, +256</li> <li>• Lamp color selection: Sets the lamp display color.</li> <li>• Shutter opening angle (<b>SL-VPK02</b> only)</li> <li>• Shutter closing angle (<b>SL-VPK02</b> only)</li> <li>• Shutter closing delay (<b>SL-VPK02</b> only)</li> <li>• Default reset: Resets settings to the factory defaults.</li> </ul>	
Environmental resistance	Protection	IP20
	Ambient temperature	+5 to +45°C (No dew condensation), Storage: 0 to +55°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
Material	Product case: ABS, Operation Panel: Polycarbonate, Communication window cover: Polycarbonate Silicone Cover: Silicone, Mounting clips: Nylon, Key Ring: SWRM6	
Weight	Approx. 160g	


## • Dimensions (Unit: mm)



## End unit

Each unit of the **S-LINK V** system needs at least one end unit.

### • Part description



No.	Designation	Function
1	Power indicator (Green)	This indicator will light up when the power is supplied.
2	Signal line connection indicator (Orange)	This indicator will light up when the signal waveform is confirmed.

### • Specifications


Designation		End Unit
Model No.		<b>SL-VEU</b>
Supply voltage		24V DC±10%
Current consumption		10mA or less
Power indicator		Green LED (lights up when the power is supplied)
Signal line connection indicator		Orange LED (lights up when the signal waveform is confirmed)
Environmental resistance	Ambient temperature	-10 to +55°C (No dew condensation or icing allowed), Storage: -20 to +70°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width Common: 1,000Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Voltage withstandability	1,000V AC for one min. between all terminals connected together and enclosure
	Insulation resistance	20MΩ, or more, with 500V DC megger between all terminals connected together and enclosure
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
Shock resistance		490m/s <sup>2</sup> acceleration (approx. 50G) in X, Y and Z directions for three times each
Mounting		Mounted on DIN rail or by tightening screws (Using <b>MS-CH</b> )
Tightening torque		<b>MS-CH</b> : 1.2N·m or less
Material		Enclosure: Polycarbonate, DIN rail mounting holder: ABS
Cable		0.5mm <sup>2</sup> 4-core flat cable, 0.6m long
Weight		Approx. 45g (including <b>MS-CH</b> )
Accessory		<b>MS-CH</b> (DIN rail mounting holder): 1 pc.

Note: If this product is stored in the control panel together with the other units, the temperature may rise above the specified operation temperature due to the heat generated by the other units.  
In this case, install a cooling fan, etc. so that the ambient temperature can be in the specified range.


# Specifications

## • Dimensions (Unit: mm)

### <SL-VEU>



### <MS-CH>




## Handy monitor






For a detailed description of the handy monitor (SL-VHM1), refer to the 'Handy Monitor (SL-VHM1) Instruction Manual.'

### • Part description




# Specifications

No.	Designation		Function	
1	S-LINK V terminal block connector	1: F.G.	Receives +24V, 0V, and F.G. from the external power supply unit, and supplies +24V, 0V, D, and G to the I/O units. In addition, the error output signal is output to the external device.	
		2: 24V		
		3: 0V		
		4: +24V		
		5: 0V		
		6: D		
		7: 0V		
		8: ERR		
2	Operation mode selector switch (power switch)		Selects the master mode, power-off mode, or slave mode.	
3	Error indicator × 6 (Red)		Lights up when an error occurs in the master mode, blinks when the error is canceled (turns off when the ERROR CLEAR key is pressed).	
4	ERROR CLEAR key		After occurrence of an error, if the error indicator (red) starts blinking (the cause of the error is eliminated), press this key. The error indicator will light off.	
5	CONTROL side	Address display (Red)	The displayed item depends on the mode ('RUN,' 'CHECK', or 'CONFIG' mode). Use the mode selector switch to switch the mode.	
			<p><b>&lt;RUN mode&gt;</b></p> <ul style="list-style-type: none"> <li>Each transmission mode (3 modes in total) will be indicated by the following character, and the LED of each character will sequentially light up just like rotating clockwise.</li> </ul> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>A Mode</p>  </div> <div style="text-align: center;"> <p>B Mode</p>  </div> <div style="text-align: center;"> <p>C Mode</p>  </div> </div> <ul style="list-style-type: none"> <li>If an error occurs, the error message will appear.</li> </ul>	
			<p><b>&lt;CHECK mode&gt;</b></p> <ul style="list-style-type: none"> <li>The number of connected nodes will be displayed first. After that, each time you press the SELECT key, the recognized addresses will be displayed one after another.</li> </ul> <p>Number of connected nodes: Using the decimal or hexadecimal number, the number of I/O units will be displayed.</p> <p>Address: Using the decimal or hexadecimal number, the addresses of the I/O units will be displayed sequentially.</p> <p>Note: In the hexadecimal number display mode, the hexadecimal number indicator (orange) will light up.</p>	
			<p><b>&lt;CONFIG mode&gt;</b></p> <ul style="list-style-type: none"> <li>Settings will be displayed sequentially. To switch the displayed setting, use the SELECT key.</li> <li>When the RUN mode is switched to the CONFIG mode, different item will be displayed compared with the displayed item just after power-on.</li> </ul>	
6	ENTER key		Press the ENTER key to determine the set condition value. In the system setting mode, press and hold the ENTER key for 3 seconds or more. The system will be set.	
7	SELECT keys		Use these keys to switch the displayed item or set item. Also use these keys to change the set condition value.	
8	Mode selector switch		Switches the mode ('RUN,' 'CHECK', or 'CONFIG' mode).	
9	Hexadecimal number display mode indicator (Orange)		Indicates the current display mode of the address display. • ON: The hexadecimal number display mode is selected. • OFF: The decimal number display mode is selected.	
10	Transmission mode indicator (Green)		This indicator will blink during transmission (when the transmission signal is being output). The indicator blinking cycle depends on the transmission speed.	
11	ADDRESS SET side	Address display (Red)		Displays the input address or the output address.
12		ENTER key		Starts setting an address or determines an address. You can also use this key to change the displayed address.
13		SELECT keys		Use these keys to set address values or to change the displayed address.
14		Input address indicator (Green)		Lights up when the address display on the ADDRESS SET side displays the input address.
15		Output address indicator (Orange)		Lights up when the address display on the ADDRESS SET side displays the output address.
16	Data monitor indicator (Orange)		Lights up when signals of 16 specified output addresses (the first address is specified) are turned ON.	
17	Data input validity indicator (Green)		Lights up when data input is valid (if data input using the data input switch is possible.)	
18	Data input VALID / INVALID selector key		Switches the data input mode to 'VALID' or 'INVALID.' Press and hold this switch for 1 second or more to switch the data input mode.	
19	Data input switches		Inputs data by inputting 16 addresses of signals to the S-LINK V system.	

## • Specifications


Designation	Handy monitor	
Model No.	<b>SL-VHM1</b>	
Supply voltage	24V DC <sup>+10%</sup> / <sub>-5%</sub>	
Current consumption	500mA or less (excluding the connected unit drive power)	
Allowable passing current	7A or less	
Number of connectable units	1 unit for 1 system (common to both master mode and slave mode)	
Operation mode	Master mode and slave mode (Selected by mode selector switch) Master mode: Controller function + I/O test function Slave mode: I/O test function	
Transmission mode indicator	Green LED (blinks when synchronization signal is input)	
Hexadecimal number indicator	Orange LED (lights up when the address display is in the hexadecimal number display mode)	
Control function	Setting and operation	For setting and operation, use the address display on the CONTROL side, RUN / CHECK / CONFIG mode selector switch on the CONTROL side, SELECT keys (2 types) on the CONTROL side, and the ENTER key on the CONTROL side.
	Address display on CONTROL side	3 digit red LED (displays the number of connected nodes, recognized address, error address, etc.)
	Error indicator	Red LED × 6 [lights up when an error occurs, blinks when the error is canceled. (turns off when the ERROR CLEAR key is pressed.)]
	ERROR CLEAR key	Push-button type
	Error output	When an error occurs: Hi (24V) When the error is canceled or when normal transmission is performed: Lo (0V) • Maximum sink current: 100mA • Residual current: 1.5V or less (at 100mA sink current)
I/O test function	Number of I/O points	16 input points, 16 output points
	Address setting	For address setting, use the address display on the ADDRESS SET side, SELECT keys (2 types) on the ADDRESS SET side, and ENTER key on the ADDRESS SET side.
	Address display on ADDRESS SET side	3 digit red LED (displays the set address during address setting operation)
	Input address indicator	Green LED (lights up when the address display area displays the input address)
	Output address indicator	Orange LED (lights up when the address display area displays the output address)
	Data monitor indicator	Orange LED × 16 [lights up when signals of 16 specified output addresses (the first address is specified) are turned ON.]
	Data input validity indicator	Green LED (Lights up when data input is valid)
	Data input VALID / INVALID selector key	Push-button type
Environmental resistance	Ambient temperature	0 to +55°C (No dew condensation), Storage: -20 to +75°C
	Ambient humidity	35 to 85% RH, Storage: 35 to 85% RH
	Noise immunity	Power line: 500Vp, 10ms cycle, 1μs pulse width (with noise simulator)
	Vibration resistance	10 to 150Hz frequency, 0.75mm amplitude or maximum acceleration 49m/s <sup>2</sup> in X, Y and Z directions for two hours each
	Shock resistance	294m/s <sup>2</sup> acceleration (30G approx.) in X, Y and Z directions for three times each
Weight	Approx. 380g	
Accessory	Strap: 1 pc.	

## • Terminal layout drawing



- Notes:
- 1) Before starting wiring work, be sure to turn off the power.  
If you start wiring work without turning off the power, the **S-LINK V** controller and the **SL-VHM1** may malfunction.
  - 2) To use the **SL-VHM1** in the master mode, be sure to disconnect the other **S-LINK V** controllers from the main line.
  - 3) To use the **SL-VHM1** in the slave mode, do not connect the power to the **SL-VHM1**.

## • Dimensions (Unit: mm)



Cable

Type	Model No.	Cable length	Conductor cross section	Conductor resistance	Allowable passing current
Exclusive 4-core flat cable	SL-RCM100□	100m	0.5mm <sup>2</sup>	Approx. 0.04Ω/m	7A or less (At ambient temperature of 25°C)
	SL-RCM200	200m			

Hook-up connector




The **SL-J**□ connector can be used for the exclusive 4-core flat cable only.  
To use the other cabtyre cable (commercially available), be sure to use the junction connector commercially available.

Use the **SL-J**□ to connect or branch the exclusive 4-core flat cables.


Designation	Model No.	Applicable cable	Conductor cross section	Allowable passing current	Allowable voltage	Exclusive pliers
Hook-up connector	<b>SL-J1A</b>	Exclusive 4-core flat cable	0.5mm <sup>2</sup> to 0.5mm <sup>2</sup>	7A or less (At ambient temperature of 25°C)	30V DC or less	<b>SL-JPS</b>
Hook-up connector for cable extension	<b>SL-J3A</b>					
Hook-up connector for cable end	<b>SL-JK</b>		0.5mm <sup>2</sup>	1A or less when <b>SL-CP1</b> is used 2A or less when <b>SL-CP2</b> is used 3A or less when <b>SL-CP3</b> is used		
Hook-up connector for 'T' - branch	<b>SL-JK1</b>					
Snap male connector	<b>SL-CP1</b>	Applicable lead wire sheath material: Vinyl chloride or soft polyethylene Applicable lead wire diameter: ø0.7 to ø1.2mm	0.08 to 0.2mm <sup>2</sup> (AWG28 to AWG24)	1A or less		<b>SL-JPC</b>
	<b>SL-CP2</b>	Applicable lead wire sheath material: Vinyl chloride or soft polyethylene Applicable lead wire diameter: ø1.1 to ø1.6mm	0.3mm <sup>2</sup> (AWG22)	2A or less		
	<b>SL-CP3</b>	Applicable lead wire sheath material: Vinyl chloride or soft polyethylene Applicable lead wire diameter: ø1.7 to ø2.5mm	0.5mm <sup>2</sup> (AWG20)	3A or less		
Snap female connector	<b>SL-CJ1</b>	Applicable lead wire sheath material: Vinyl chloride or soft polyethylene Applicable lead wire diameter: ø0.7 to ø1.2mm	0.08 to 0.2mm <sup>2</sup> (AWG28 to AWG24)	1A or less		<b>SL-JPC</b>
	<b>SL-CJ2</b>	Applicable lead wire sheath material: Vinyl chloride or soft polyethylene Applicable lead wire diameter: ø1.1 to ø1.6mm	0.3mm <sup>2</sup> (AWG22)	2A or less		

## • Dimensions (Unit: mm)


### <SL-J1A>




### <SL-J3A>




### <SL-JK, SL-JK1>




### <SL-CP1, SL-CP2>



### <SL-CP3>



### <SL-CJ1, SL-CJ2>



## List of programmable logic controllers (PLC) (upper models)

This section shows the list of programmable logic controllers (PLC) and their manufacturers in order to clarify the programmable controllers that can control each unit of the **S-LINK V** system.

### CAUTION

Select PLC I/O connector compatible with your PLC.  
Use of a wrong PLC I/O connector may damage the system.

#### <PLC input connectors>

Model No.	Applicable manufacturer	Applicable PLC	Applicable input module			
SL-VS1	Panasonic Industrial Devices SUNX Co., Ltd.	FPΣ (excluding FPG-C32T)	FPG-XY64D2T (X side)			
		FP2	FP2-X32D2			
		FP7	AFP7X32D2			
		FP3, FP10S, FP10SH	AFP33027-F			
	Toshiba Machine Co., Ltd.	TC200	TC64DI			
SL-VS2	Fuji Electric FA Components & Systems Co., Ltd.	NS series	NS-X64-1 NS-XY64-1 (X side)			
		F55	NV1X3204 NV1X3204-W NV1X3206			
			F70	NC1X3204 NC1X3204-3 NC1X3206 NC1X6404 NC1X6406 NC1W6406T (X side)		
				F80H, F120H, F120S, F140S, F15XS	FTU125A FTU126A FTU127C FTU612A (X side)	
		AnS			A1SX41 A1SX41-S1 A1SX42 A1SX42-S1 A1SH42 (X side) A1SH42-S1 (X side)	
					AnN, AnA, AnU, QnA, QnAs	AX42 AH42 (X side)
						Q series
			A2CJ	AJ35TC1-32D		
			Fuji Electric FA Components & Systems Co., Ltd.	SX series	NP1X3206-W NP1X6406-W	
			SL-VS4	Sharp Manufacturing Systems Corp.	JW20, JW20H, JW30H	JW-234N JW-264N
		JW50H			JW-34NC JW-64NC	
					OMRON Corp.	CJ1 series
		CS1	CS1W-ID231 CS1W-ID261 CS1W-MD261 (X side)			
CVM1, CV, C500, C1000H, C2000H	C500-ID219 C200H-ID216 C200H-ID217					
C200H series	C200H-ID216 C200H-ID217					
CQM1	CQM1-ID213					
SL-VS5	Yokogawa Electric Corp.	FA500	XD64-6N WD64-6N (X side)			
		FA-M3, FA-M3R	F3XD32-3N F3XD64-3N			

Note: The **SL-VS1** is MIL connector (40-pin connector) conforming to the MIL specifications.  
The other connectors are the 360-type 40-pin connectors manufactured by Fujitsu Component Ltd.

# List of Models

Model No.	Applicable manufacturer	Applicable PLC	Applicable input module
SL-VS5	Hitachi Ltd.	EH-150 series	EH-XD32
	TOSHIBA Corp.	T3	DI-335 DI-335H
SL-VS6	Hitachi Industrial Equipment Systems Co., Ltd.	H series	XDC24D2H XDC24D3H
SL-VS7	YASKAWA Electric Corp.	GL20, GL40S, GL60S, GL60H, GL70H	B2605
SL-VS8	Rockwell Automation Japan (Allen-Bradley)	SLC500	1746-IV32

Note: The **SL-VS6** and **SL-VS8** are MIL connectors (40-pin connectors) conforming to the MIL specifications.  
The other connectors are the 360-type 40-pin connectors manufactured by Fujitsu Component Ltd.

## <PLC output connectors>

Model No.	Applicable manufacturer	Applicable PLC	Applicable output module	
SL-VP1	Panasonic Industrial Devices SUNX Co., Ltd.	FPΣ (excluding FPG-C32T)	FPG-XY64D2T (Y side)	
		FP2	FP2-Y32T	
		FP7	AFP7Y32T	
		FP3, FP10S, FP10SH	AFP33487-F	
	Toshiba Machine Co., Ltd.	TC200	TC64DON	
SL-VP2	Fuji Electric FA Components & Systems Co., Ltd.	NS series	NS-Y64-T1 NS-XY64-1 (Y side)	
		F55	NV1Y32T05P1 NC1Y32T05P1	
		F70	NC1Y64T05P1-1 NC1W6406T (Y side)	
		F80H, F120H, F120S, F140S, F15XS	FTU222A FTU227C FTU612A (Y side)	
		AnS	A1SY41 A1SY42 A1SH42 (Y side) A1SH42-S1 (Y side)	
		AnN, AnA, AnU, QnA, QnAs	AY42 AH42 (Y side) QY41P QY42P QH42P (Y side)	
	Fuji Electric FA Components & Systems Co., Ltd.	SX series	AJ35TC1-32T NP1Y32T09P1 NP1Y64T09P1	
SL-VP3	Mitsubishi Electric Corp.	A2CJ	AJ35TC1-32T	
		Q series	QY41P QY42P QH42P (Y side)	
		A2CJ	AJ35TC1-32T	
SL-VP4	Sharp Manufacturing Systems Corp.	JW20, JW20H, JW30H	JW-232S JW-262S	
		JW50H	JW-32SC JW-62SC	
SL-VP5	OMRON Corp.	CJ1 series	CJ1W-OD231 CJ1W-OD261 CJ1W-MD261 (Y side)	
		CS1	CS1W-OD231 CS1W-OD261 CS1W-MD261 (Y side)	
		CVM1, CV, C500, C1000H, C2000H	C500-OD213 C200H-OD218 C200H-OD219	
		C200H series	C200H-OD218 C200H-OD219	
		CQM1	CQM1-OD213	
	Yokogawa Electric Corp.	FA500	YD64-1A WD64-6N (Y side)	
		FA-M3, FA-M3R	F3YD32-1A F3YD64-1A	
		Hitachi Ltd.	EH-150 series	EH-YT32
		TOSHIBA Corp.	T3	DO-335
		YASKAWA Electric Corp.	GL20, GL40S, GL60S, GL60H, GL70H	B2604
SL-VP6	Hitachi Industrial Equipment Systems Co., Ltd.	H series	YTR24DH YTR24D3H	
SL-VP8	Rockwell Automation Japan (Allen-Bradley)	SLC500	1746-OV32	

Note: The **SL-VP1**, **SL-VP6**, and **SL-VP8** are MIL connectors (40-pin connectors) conforming to the MIL specifications.  
The other connectors are the 360-type 40-pin connectors manufactured by Fujitsu Component Ltd.

## Controller

Designation	Model No.	Description
<b>S-LINK V</b> controller	<b>SL-VCU1</b>	This controller controls the signal transmission of the entire system. In addition, this controller always monitors the signal transmission line. If a problem, such as disconnection, is detected, the controller will localize the problem point, and displays the error address.
Bus direct-connection type <b>S-LINK V</b> controller for <b>FP2 / FP2SH</b> series	<b>SL-VFP2</b>	This controller can be directly connected to the bus line of the <b>FP2</b> series.
Bus direct-connection type <b>S-LINK V</b> controller for <b>FP7</b> series	<b>SL-VFP7</b>	This controller can be directly connected to the bus line of the <b>FP7</b> series
Bus direct-connection type <b>S-LINK V</b> controller for MELSEC-Q series PLC manufactured by Mitsubishi Electric Corp.	<b>SL-VMEL-Q</b>	This controller can be directly connected to the bus line of the MELSEC-Q series PLC manufactured by Mitsubishi Electric Corp.
<b>S-LINK V</b> gateway controller for CC-Link	<b>SL-VGU1-C</b>	This <b>S-LINK V</b> gateway controller conforms to the specifications of the CC-Link open network proposed by CC-Link Association.
<b>S-LINK V</b> gateway controller for DeviceNet	<b>SL-VGU1-D</b>	This <b>S-LINK V</b> gateway controller conforms to the specifications of the DeviceNet open network proposed by ODVA.
<b>S-LINK V</b> gateway controller for EtherCAT	<b>SL-VGU1-EC</b>	This <b>S-LINK V</b> gateway controller conforms to the specifications of the EtherCAT open network proposed by ETG.
<b>S-LINK V</b> gateway controller for RS-485 / RS-232C	<b>SL-VGU1-485</b>	This <b>S-LINK V</b> gateway controller conforms to the specifications of the RS-485 / RS-232C.

## Control board

Designation	Model No.	Description
<b>S-LINK V</b> control board for PCI bus	<b>SL-VPCI</b>	Insert this control board into the extension slot (PCI bus) of the personal computer to control the <b>S-LINK V</b> system.
<b>S-LINK V</b> control board for VME bus	<b>SL-VVMES2</b>	This control board is directly connected to the VME bus line to control the <b>S-LINK V</b> system. Since this control board is incorporated with 2 ports (512 points, each) for I/O machines, use of this control board enables control of up to 1,024 points of I/O devices.

## Control module

Designation	Model No.	Description
<b>S-LINK V</b> control module	<b>SL-VMC1</b>	This is a hybrid IC module. The <b>S-LINK V</b> controller is mounted on the printed circuit board. This module enables free designing of the system.

## List of Models

### List of I/O units

Designation		Model No.	Description	
I/O unit	1-channel input unit	<b>SL-VCH10</b>	Input: 1 point	Enables connection of 1 point of the input device.
	2-channel input unit	<b>SL-VCH20</b>	Input: 2 points	Enables connection of 2 points of the input device.
	2-channel I/O mixed unit	<b>SL-VCH21</b>	Input: 1 point Output: 1 point	Enables connection of 1 point of the input device and 1 point of the output device.
	1-channel output unit	<b>SL-VCH11</b>	Output: 1 point	Enables connection of 1 point of the output device.
	2-channel output unit	<b>SL-VCH22</b>	Output: 2 points	Enables connection of 2 points of the output device.
I/O terminal	4-channel input terminal	<b>SL-VTB4</b>	Input: 4 points	These terminals enable connection of 4 points, 8 points, 16 points, or 32 points of the input device. Since a power supply terminal for the input device is installed for every 2 channels, simple wiring will be possible (excluding the <b>SL-VTB32</b> ).
	8-channel input terminal	<b>SL-VTB8</b>	Input: 8 points	
	16-channel input terminal	<b>SL-VTB16</b>	Input: 16 points	
	32-channel input terminal	<b>SL-VTB32</b>	Input: 32 points	
	4-channel output terminal	<b>SL-VTBP4</b>	Output: 4 points	These terminals enable connection of 4 points, 8 points, 16 points, or 32 points of the output device. In addition, the output holding function is adopted for these terminals. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
	8-channel output terminal	<b>SL-VTBP8</b>	Output: 8 points	
	16-channel output terminal	<b>SL-VTBP16</b>	Output: 16 points	
	32-channel output terminal	<b>SL-VTBP32</b>	Output: 32 points	
Connector I/O unit	4-channel connector input unit	<b>SL-VT4J</b>	Input: 4 points	Using the snap male connector ( <b>SL-CP□</b> ), up to 4 points or 8 points of the input device can be easily connected.
	8-channel connector input unit	<b>SL-VT8J</b>	Input: 8 points	
	4-channel e-CON type connector input unit	<b>SL-VT4E</b>	Output: 4 points	Using the e-CON compliant connector, up to 4 points or 8 points of the input device can be easily connected.
	8-channel e-CON type connector input unit	<b>SL-VT8E</b>	Output: 8 points	
	4-channel connector output unit	<b>SL-VTP4J</b>	Output: 4 points	Using the snap male connector ( <b>SL-CP□</b> ), up to 4 points or 8 points of the output device can be easily connected. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
	8-channel connector output unit	<b>SL-VTP8J</b>	Output: 8 points	
	4-channel e-CON type connector output unit	<b>SL-VTP4E</b>	Output: 4 points	Using the e-CON compliant connector, up to 4 points or 8 points of the output device can be easily connected. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
	8-channel e-CON type connector output unit	<b>SL-VTP8E</b>	Output: 8 points	
	16-channel MIL connector input unit	<b>SL-VT16C1</b>	Input: 16 points	Since the MIL connector can be used for connection, this small-sized unit can connect up to 16 points of the input device.
	16-channel MIL connector output unit	<b>SL-VTP16C1</b>	Output: 16 points	Since the MIL connector can be used for connection, this small-sized unit can connect up to 16 points of the output device. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
<b>SL-VTP16C1-S</b>				
Analogue input unit		<b>SL-VTAD1</b>	Input: 1 point	1 point of the analogue input device can be connected.
Analogue output unit		<b>SL-VTDA1</b>	Output: 1 point	1 point of the analogue output device can be connected. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
Relay output terminal	4-channel relay output terminal	<b>SL-VTPR4</b>	Output: 4 points	These relay output terminals have 4 or 8 output points. Relays can be easily replaced. In addition, the output holding function is adopted for these terminals. For this reason, if the signal transmission line has a problem, the output conditions just before occurrence of the problem will be held.
	8-channel relay output terminal	<b>SL-VTPR8</b>	Output: 8 points	
I/O module	8-channel input module	<b>SL-VM8</b>	Input: 8 points	These modules are the IC type that enables external installation of the address setting switches and indicators. These modules therefore enable more flexible designing.
	16-channel input module	<b>SL-VM16</b>	Input: 16 points	
	8-channel output module	<b>SL-VMP8</b>	Output: 8 points	
	16-channel output module	<b>SL-VMP16</b>	Output: 16 points	
Picking switch		<b>SL-VPK01</b>	This picking switch, which is designed to be mounted on a pipe, supports use of a remote controller to set and check its address, lamp color, and other settings.	
Picking switch for shutter		<b>SL-VPK01</b>	This picking switch, which is designed to be mounted on a pipe, supports use of a remote controller to set and check its address, lamp color, and other settings. This switch has a movable arm to which the shutter can be attached.	

## List of connectors

Designation	Model No.	Description
Hook-up connector	<b>SL-J1A</b>	This connector enables a 'T' - branch of the exclusive 4-core flat cable. For 0.5mm <sup>2</sup> to 0.5mm <sup>2</sup> (Gray)
Hook-up connector for cable extension	<b>SL-J3A</b>	Used for extension of the exclusive 4-core flat cable. For 0.5mm <sup>2</sup> to 0.5mm <sup>2</sup> (Black)
Hook-up connector for cable end	<b>SL-JK</b>	If the snap male connector ( <b>SL-CP</b> ) is used together, this hook-up connector ( <b>SL-JK</b> ) enables connection of the I/O unit to the end of the exclusive 4-core flat cable (0.5mm <sup>2</sup> ). (Light blue)
Hook-up connector for 'T' - branch	<b>SL-JK1</b>	If the snap male connector ( <b>SL-CP</b> ) is used together, this hook-up connector ( <b>SL-JK1</b> ) enables connection of the I/O unit to any point of the exclusive 4-core flat cable (0.5mm <sup>2</sup> ). (Blue)
Snap male connector	<b>SL-CP1</b>	For 0.08 to 0.2mm <sup>2</sup> Lead wire diameter: ø0.7 to ø1.2mm (White)
	<b>SL-CP2</b>	For 0.3mm <sup>2</sup> Lead wire diameter: ø1.1 to ø1.6mm (Black)
	<b>SL-CP3</b>	For 0.5mm <sup>2</sup> Lead wire diameter: ø1.7 to ø2.5mm (Bluish green)
Snap female connector	<b>SL-CJ1</b>	For 0.08 to 0.2mm <sup>2</sup> Lead wire diameter: ø0.7 to ø1.2mm (White)
	<b>SL-CJ2</b>	For 0.3mm <sup>2</sup> Lead wire diameter: ø1.1 to ø1.6mm (Black)



We can provide connectors in units of 10-connector sets.  
If you need connectors, please let us know how many sets you need (1 set: 10 pcs.)

## Handy monitor

Designation	Model No.	Description
Handy monitor	<b>SL-VHM1</b>	This monitor can be connected to any point of the signal transmission line, and enables monitoring of the I/O conditions in units of 16 points. In addition, this monitor is incorporated with the <b>S-LINK V</b> controller functions. For this reason, even in the middle of installation work, this monitor can carry out I/O check for a divided conveyor, or the like, without activating the <b>S-LINK V</b> controller.

## Address setting remote controller

Designation	Model No.	Description
Address setting remote controller	<b>SL-VAR1</b>	This remote controller is designed specifically to select the <b>SL-VPK0</b> address and lamp color and to change its address offset. It can also send and receive all settings at once using infrared communications.

## List of Models

### Others

Designation	Model No.	Description	
S-LINK V control cable	SL-VC1000	Length: 1m	Used for connection of the PLC I/O connector to the S-LINK V controller.
	SL-VC2000	Length: 2m	
S-LINK V connector link cable	SL-VF70	Length: 70mm	Used for connection of the PLC I/O connectors to each other.
	SL-VF150	Length: 150mm	
	SL-VF250	Length: 250mm	
Exclusive 4-core flat cable	SL-RCM100	Length: 100m (D line: White)	These flat cables are specially designed for the S-LINK system only. Conductor cross section: 0.5mm <sup>2</sup> 4-core Outer diameter: 2.5mm x 4
	SL-RCM100-PK	Length: 100m (D line: White / Pink)	
	SL-RCM100-GN	Length: 100m (D line: White / Green)	
	SL-RCM100-GY	Length: 100m (D line: White / Gray)	
	SL-RCM200	Length: 200m (D line: White)	
Exclusive hook-up pliers	SL-JPS	Enables one-touch hook-up of the hook-up connector (SL-J□).	
	SL-JPC	Enables one-touch hook-up of the hook-up connector (SL-CJ□ / CP1 / CP2).	
	SL-JPE	Enables one-touch hook-up of the hook-up connector (SL-CP3).	
End unit	SL-VEU	Connect this unit to the end of the main line.	
DIN rail mounting holder	MS-CH	Used for installation of the I/O unit or the end unit on the DIN rail. (Supplied with the SL-VEU)	
Screw mounting holder	MS-SLH	Used for installation of the I/O unit or the end unit. (In addition to the screws supplied with the holder, prepare additional two M4 pan head screws.)	
Address label	SL-VMA1	Affix this label to various S-LINK V units for easy identification of the set addresses.	
Address label (4-color set)	SL-VMA1-SET	4 colors (White / Pink / Green / Gray) of address labels for each system are included as a set.	



- MS-CH is also available as an option. Model No.: MS-CH×10 (10 pcs./ set)
- SL-VMA1 is for 2 systems (0 to 255 × 2 pcs., 256 to 511 × 2 pcs.) as a set.
- SL-VMA1-SET is for 4 systems (0 to 255 × 4 pcs., 256 to 511 × 4 pcs.) as a set.

# **Chapter 5**

# **Troubleshooting**

---


---

# Troubleshooting


This section describes how to solve the problems.  
If your **S-LINK V** system does not operate properly, refer to this section.

## Flowchart for taking corrective action for detected error


You can check the detected error using the LED indicators or the address display of the controller.  
After checking the detected error, solve the problem as shown below:




### <For S-LINK V controller>




<For S-LINK V control board>






Notes: 1) For the control board, it is not necessary to switch the mode.  
 2) For the control board, the number of recognized nodes in the in-board memory is smaller than the actual number of nodes.

## Flowchart for power supply condition check





- Notes: 1) If the control board is used, check the error number shown by the in-board memory.  
 2) If an error occur, the transmission of **S-LINK V** system will automatically recover when the cause is removed. However, the error record remains. For release, refer to page 172.  
 3) If incorrectly set the same addresses to the several units, the fewer number of units will display on the controller.


## How to identify error unit after error detection

If an error occurs, switch the transmission mode to the CHECK mode. In this mode, you can identify the address of the problem unit.


**1** : PLC I/O unit (The white number is the connector number.)

**32** : S-LINK V I/O unit (The number shows the address of the unit.)


### <Example 1>




### <Example 2>



### <Example 3>



### <Example 4>




Operation	Description / Function	Example 1	Example 2	Example 3	Example 4
Switch the mode selection switch to CHECK.	Displays the number of PLC I/O connectors having a problem.				
Press <b>▶</b> key.	Displays the number of nodes of the I/O unit having a problem.				
Press <b>▶</b> key. Press <b>▶</b> key. (Repeatedly press the key to display all the data.)	Sequentially displays the connector numbers of the PLC I/O connectors having a problem from the smallest number to the largest number.		 ↓ 		 ↓ 
Press <b>▶</b> key. Press <b>▶</b> key. (Repeatedly press the key to display all the data.)	Sequentially displays the addresses of the I/O units having a problem from the smallest address number to the largest address number.	 ↓ 			 ↓ 

Notes: 1) Use **▶** key to display the numbers in the reversed order.

2) Press and hold SELECT key (**◀** or **▶** key) to switch the displayed number at a fast speed.

### <For example 1>



## How to extinguish error indicator

### **WARNING**

Before canceling the error, be sure to confirm the details of the error, and then turn off the power. After power-off, be sure to eliminate the cause of the error, and then turn on the power again. If the power is not turned off, a serious problem may occur.

To stop the error indicator from blinking, or to erase the error number displayed on the address display, check that the mode selection switch is set to 'RUN,' and then press the ◀|, |▶, and ENTER buttons at the same time. However, if the cause of the error is not eliminated, pressing the above buttons will not extinguish the error indicator.

If the **SL-VFP2, SL-VFP7, SL-VMEL-Q, SL-VPCI, SL-VVMES2, SL-VGU1-C, SL-VGU1-D, SL-VGU1-EC, or SL-VGU1-485** is adopted, also use the software function to extinguish the error indicator.

## Utilization of output holding function

### **WARNING**

Before setting the output holding function, be sure to fully understand the details of this function. If the output holding function is not activated, a serious problem may occur.

Select the output unit operation for the output holding function. If a transmission error occurs, the output unit will operate in accordance with the selected operation. However, if the power is not supplied to the output unit, the output holding function will not be activated. If the normal transmission is restarted, normal operation will be performed.

- **Output holding function: ON**
  - If a transmission error is detected, the output conditions detected just before occurrence of the error will be held.
- **Output holding function: OFF**
  - If a transmission error is detected, all the outputs will be turned off.

#### Examples of use:

##### <Output holding function: ON>

- Use this function if the transfer unit uses the vacuum pick-up function.
- Use this function if a manifold is used for operation of the pressure unit.
- Use this function if non-holding of the current conditions may damage the machine (workpieces).

##### <Output holding function: OFF>

- Use this function if a transfer unit is adopted to perform line transfer operation.
- Use this function if a motor is adopted as the drive unit.
- Use this function if the items being transferred will be obstacles at resetting operation.



We have predicted the cases that need this function, and listed above as examples. However, to actually set the output holding function for your system, consider the environmental conditions of your system.

# Appendix

---

---


# Appendix

## List of error numbers

If the **S-LINK V** system causes an error, the error indicator, address display, and error output will inform the error. Check the details of the error, and take optimum measures.

Error No.	Cause of error	Transmission after detecting error	Remedy
Error 0	Defective system (controller)	Transmission will be stopped.	Please contact us.
Error 1	Short-circuit between +24V and D	Transmission will be stopped. Eliminate the cause of the error. 5 seconds later, the system will be automatically reset.	Refer to page 166.
Error 2	Short-circuit between D and G		
Error 3	Malfunction or disconnection of recognized I/O unit or PLC I/O connector	Transmission will be continuously performed.	
Error 4	Addition of unrecognized unit		
Error 5	<ul style="list-style-type: none"><li>• Shorted output terminal of output unit</li><li>• Cutting off of I/O machine drive power</li></ul>		
Error 6	This error may occur if system setting is not carried out properly.	If system setting is completed without fail, the system will be automatically reset.	

## Flowchart for error detection



Note: Before following the above procedure, be sure to set the mode selection switch to 'RUN.'

## Selection of connector link cable

### <Description of symbols shown in figures>

70 : **SL-VF70** (70mm)

150: **SL-VF150** (150mm)




250: **SL-VF250** (250mm)

#### • Modules using SL-VS1 and SL-VP1

FPG-XY64D2T  
(Panasonic Industrial Devices SUNX)



FP2-X32D2, FP2-Y32T  
(Panasonic Industrial Devices SUNX)

AFP33027-F, AFP33487-F  
(Panasonic Industrial Devices SUNX)



TC64DI, TC64DON (Toshiba Machine)



AFP7X32D2, AFP7Y32T  
(Panasonic Industrial Devices SUNX)



#### • Modules using SL-VS2 and SL-VP2



NS-X64-1, NS-XY64-1, NS-Y64-T1  
(Fuji Electric FA Components & Systems)

NV1X3204, NV1X3204-W, NV1X3206, NV1Y32T05P1  
(Fuji Electric FA Components & Systems)




NC1X3204, NC1X3204-3, NC1X3206, NC1X6404, NC1X6406  
NC1W6406T, NC1Y32T05P1, NC1Y64T05P1-1  
(Fuji Electric FA Components & Systems)

FTU125A, FTU126A, FTU127C, FTU612A, FTU222A  
FTU227C (Fuji Electric FA Components & Systems)




● Module using SL-VS3 and SL-VP3


A1SX41, A1SX41-S1, A1SX42, A1SX42-S1, A1SH42  
A1SH42-S1, A1SY41, A1SY42 (Mitsubishi Electric)




AX42, AH42, AJ35TC1-32D, AY42, AJ35TC1-32T (Mitsubishi Electric)



QX41, QX42, QH42P, QY41P, QY42P (Mitsubishi Electric)




NP1X3206-W, NP1X6406-W, NP1Y32T09P1, NP1Y64T09P1  
(Fuji Electric FA Components & Systems)




● Module using SL-VS4 and SL-VP4

JW-234N, JW-264N, JW-232S, JW-262S  
(Sharp Manufacturing Systems)




JW-34NC, JW-64NC, JW-32SC, JW-62SC  
(Sharp Manufacturing Systems)



● Modules using SL-VS5 and SL-VP5


CJ1W-ID231, CJ1W-ID261, CJ1W-MD261, CJ1W-OD231, CJ1W-OD261  
 CS1W-ID231, CS1W-ID261, CS1W-MD261, CS1W-OD231, CS1W-OD261  
 C200H-ID216, C200H-ID217, C200H-OD218, C200H-OD219 (OMRON)

<OMRON CJ1 series/CS1 series /C200H series>




CQM1-ID213, CQM1-OD213 (OMRON)

<OMRON CQM1>




F3XD32-3N, F3XD64-3N, F3YD32-1A, F3YD64-1A  
 (Yokogawa Electric)

<Yokogawa FA-M3 / FA-M3R>




DI-335, DI-335H, DO-335 (TOSHIBA)

<TOSHIBA T3>




C500-ID219, C500-OD213 (OMRON)

<OMRON CVM1/CV /C1000H/C2000H /C500>




XD64-6N, WD64-6N, YD64-1A (Yokogawa Electric)

<Yokogawa FA500>




EH-XD32, EH-YT32 (Hitachi)

<Hitachi EH-150 series>



B2604 (YASUKAWA Electric)


<YASUKAWA GL20/GL40S/ GL60S/GL60H/ GL70H>



● Modules using SL-VS6 and SL-VP6

XDC24D2H, XDC24D3H, YTR24DH, YTR24D3H (Hitachi Industrial Equipment Systems)


<Hitachi H series>



● Modules using SL-VS7 and SL-VP5

B2605 (YASUKAWA Electric)

<YASUKAWA GL20/GL40S/GL60S/GL60H/GL70H>




● Modules using SL-VS8 and SL-VP8

1746-IV32, 1746-OV32


[Rockwell Automation Japan (Allen-Bradley)]

<Allen-Bradley SLC500>




## Setting of connector numbers, addresses, and number of I/O control points

To set the PLC I/O connector numbers, I/O unit addresses, and number of I/O control points, refer to pages 33, 72 and following pages.



### Setting example 1

PLC I/O connector		I/O	PLC I/O connector model	Address
No.	Connector No.			
1	0	Input	SL-VS	0 to 31
2	1		SL-VS	32 to 63
3	2	Output	SL-VP	64 to 95
4	3		SL-VP	96 to 127




For setting example 1, set the number of I/O control points to '128.'

If the number of I/O control points is set to '128,' data will not be refreshed for addresses subsequent to address 128.

If you set an address number to more than '128' by mistake, the controller cannot recognize the I/O unit.

### Setting example 2

PLC I/O connector		I/O	PLC I/O connector model	Address
No.	Connector No.			
1	0	Input	SL-VS	0 to 31
2	8		SL-VS	256 to 287
3	1	Output	SL-VP	32 to 63
4	9		SL-VP	288 to 319



For setting example 2, set the number of I/O control points to '320.'

If the number of I/O control points is set to '320,' data will not be refreshed for addresses subsequent to address 320.

If you set an address number to more than '320' by mistake, the controller cannot recognize the I/O unit.

The controller can recognize the I/O unit having an address number between 64 and 255. The PLC, however, cannot communicate with the I/O unit having such an address number because there is no PLC I/O connector for such address numbers.

## Glossary

Term	Description
<b>A</b>	
Address	Number showing the address For the <b>S-LINK V</b> system, this number should be set for each I/O unit.
<b>B</b>	
bit	Contraction of 'binary digit.' Binary numbers will be set for bits. In other words, '0' or '1' will be set for each bit.
bps	Abbreviation of 'bit per second.' This is a unit showing how many bits can be sent in 1 second.
Branch line	Line branched from the main line
<b>C</b>	
Cabtyre cable	Cable consisting of several insulated wires that are covered with a strong sheath
CHECK mode	In this mode, you can check the I/O unit recognition conditions using the controller. If operation is performed in the CHECK mode, transmission with the I/O units will be carried out, and the I/O signals will be refreshed just like the RUN mode.
Common (COM.)	Common (COM.) Line [+24V = COM. (+), 0V = COM. (-)] common to controller and I/O units
CONFIG mode	In this mode, you can set the transmission mode, number of I/O control points, and error output operation. In addition, system setting and default setting are possible in this mode. However, various settings and default setting are possible in the CONFIG mode just after power-on only. During operation in the CONFIG mode, transmission with the I/O units will not be performed. This means that refreshing of I/O signals will not be carried out.
Connector cap	This cap is attached to the end of each PLC I/O connector.
Connector number	Number assigned to each PLC I/O connector ( <b>SL-VS</b> □, <b>SL-VP</b> □)
CPU module	PLC module having the functions of the central processing unit (CPU)
<b>D</b>	
DIN rail	This rail conforms to the DIN EN 50022 German industrial standards.
<b>E</b>	
Error number	Code indicated by the controller after detection of an error
Error output	Signal output from the controller after detection of an error The output terminal can be changed using the controller.
Exclusive (4-core) flat cable	<b>SL-RCM</b> □. The exclusive (hook-up) connectors can be used. This is a flat cable having 4 cores and cable conductor cross section of 0.5mm <sup>2</sup> .
Exclusive (hook-up) connector	Exclusive (hook-up) <b>SL-J</b> □, <b>SL-CP</b> □, and <b>SL-CJ</b> □ If you use this connector and exclusive tool, wiring can be easily performed.
<b>F</b>	
Failsafe	Design adopted for the system to ensure safety even if the system performs abnormal operation or malfunctions
<b>H</b>	
Hexadecimal number	Hexadecimal number expressed by numbers 0 to 9 and alphabetic characters A, B, C, D, E, and F
Hook-up connector	<b>SL-J</b> □, <b>SL-CP</b> □, <b>SL-CJ</b> □, etc.
<b>I</b>	
Interference between signals	Interference between signals also referred to as crosstalk or collision. This is a problem caused by an undesirable signal sent from the other transmission line.
Interlock	Method to prohibit the entire or partial machine operation in order to ensure safe operation of the system or machine and to prevent accidents until certain conditions are met
Isolation (Photo-isolation)	To electrically separate the external circuit from the internal circuit using a photo-coupler, etc. in order to reduce the influence of external noise in the I/O area
<b>L</b>	
Leakage current	Electric current that flows through the output area in the output OFF mode
LED	Abbreviation of 'light emitting diode.' This diode will emit light if electric current flows through the diode.
<b>M</b>	
Main line	Longest route from the controller to the line end
Maximum transmission distance	Maximum main line length controllable for the controller. This length depends on the transmission mode, number of nodes, and conductor cross section of the transmission cable.
Maximum load current (Output sink current)	Maximum current used by the output unit

## Appendix

Term	Description
<b>N</b>	
Node	Number of I/O units / 1 unit = 1 node
Number of I/O	Total number of signals that are used by the controller to control the input and output points areas
<b>O</b>	
OFF voltage	Voltage to keep the input unit at the OFF status
ON voltage	Voltage to keep the input unit at the ON status
Open collector output	One of no-contact output terminals. This terminal is the collector terminal (final output) of the transistor and is used as the terminal for connection to the external load. There are two types of open collector outputs: NPN and PNP types. Select the optimum type for the transistor.
<b>P</b>	
Parallel communication	A signal line is prepared for each data bit in order to carry out the simultaneous communication.
PLC	Abbreviation of 'programmable logic controller.' A PLC normally means the sequence control unit of stored program type.
PLC input module	This module converts the external signals received from the operation units and various sensors into logical signals. This module can be attached to and removed from the PLC.
PLC output module	This module converts the logical signals into different signals that can be used for operation of the external units. This module can be attached to and removed from the PLC.
Power supply capacity	Design adopted for the system to ensure safety even if the system performs abnormal operation or malfunctions
Protocol	Rule preliminarily determined to clarify how to transfer data between the controller and the units
<b>R</b>	
Refreshing time	Time required for data transfer between the controller and the I/O units
Response delay	When the signal of the external connection terminal is changed, it takes some time for the other terminal to respond the change in the signal. This time difference is referred to as the response delay.
RUN mode	This mode is used for normal operation of the controller. In this mode, the controller will communicate with the I/O units and refresh the I/O signals.
<b>S</b>	
Serial communication	Data bits are arranged in series from the viewpoint of time, and transmission will be carried out using one transmission line by sequentially outputting data
Shorting piece	Metal piece used for shorting the power supply terminal to the common terminal at the I/O terminal
Shorting piece (Controller)	Metal piece used for shorting the power supply terminal of the controller to the power supply terminal of the transmission cable
<b>T</b>	
Total cable length	Sum total of the main line length and branch line lengths This length depends on the transmission mode.
Transmission cable	This cable is used for connection of I/O units that are controlled by the <b>S-LINK V</b> protocol. This cable consists of 4 wires: +24V and 0V power supply line wires and D and G signal transmission line wires.
Transmission mode	In this mode, the controller will communicate with the I/O units.
Troubleshooting	To investigate the cause of a problem (malfunction of a unit, etc.), and to solve the problem or taking measures against the problem while following the specified procedure
<b>V</b>	
VCTF cable	Vinyl cabtyre round cable specified in JIS C 3306 For the <b>S-LINK V</b> system, you can use the non-shielded vinyl cabtyre round cable having conductor cross section of 0.3 to 2.0mm <sup>2</sup> .
Voltage drop	Voltage drop occurs in the power supply cable due to the cable resistance.

# FAX Sheet for Asking Question

If you have a question about the **S-LINK V** system (regarding designing, installation, etc.), copy this page, and then write your question in details. After that, fax the written sheet. We will answer your question.

Please enter necessary data.

Date: \_\_\_\_\_

Description

---



---



---



---



---

### System check items:

No. of nodes	units
Communication distance	m
Total cable length	m
Power supply capacity	A
Type and cross section of communication cable (                      mm <sup>2</sup> )	
Existence of end unit	
Exists (   units) / Does not exist	

### Controller check items:

Communication mode
A   ·   B   ·   C
I/O control points
points

Items indicated in CHECK mode	
Number of connected PLC connectors	units
Number of connected nodes (I/O units)	units
Recognized connector number of connected PLC connector:	
Recognized address of connected I/O unit:	

Address \_\_\_\_\_

TEL \_\_\_\_\_

FAX \_\_\_\_\_

E-mail \_\_\_\_\_

Company name \_\_\_\_\_

Section name \_\_\_\_\_

Name \_\_\_\_\_

---

# MEMO



# GENERAL TERMS AND CONDITIONS

Please read this document carefully with respect to our product warranty policy before using our Panasonic Industrial Devices SUNX products ("Products"). If you have any questions or comments regarding do's and don'ts of the Products, please consult your local Panasonic Industrial Devices SUNX authorized dealer for the correct use and application of the Products.

## 1. WARRANTIES:

- (1) Subject to the exclusions stated in 2 (EXCLUSIONS) herein below, Panasonic Industrial Devices SUNX warrants the Products to be free of defects in material and workmanship for a period of one (1) year from the date of shipment under normal usage in environments commonly found in manufacturing industry.
- (2) Any Products found to be defective must be shipped to Panasonic Industrial Devices SUNX with all shipping costs paid by Purchaser or offered to Panasonic Industrial Devices SUNX for inspection and examination. Upon examination by Panasonic Industrial Devices SUNX, Panasonic Industrial Devices SUNX will, at its sole discretion, repair or replace at no charge, or refund the purchase price of, any Products found to be defective.

## 2. EXCLUSIONS:

- (1) This warranty does not apply to defects resulting from any cause:
  - (i) which was due to abuse, misuse, mishandling, improper installation, improper interfacing, or improper repair by Purchaser;
  - (ii) which was due to unauthorized modification by Purchaser, in part or in whole, whether in structure, performance or specification;
  - (iii) which was not discoverable by a person with the state-of-the-art scientific and technical knowledge at the time of manufacture;
  - (iv) which was due to an operation or use by Purchaser outside of the limits of operation or environment specified by Panasonic Industrial Devices SUNX;
  - (v) which was due to normal wear and tear;
  - (vi) which was due to Force Majeure; and
  - (vii) which was due to any use or application expressly discouraged by Panasonic Industrial Devices SUNX in 4 (CAUTIONS FOR SAFE USE) hereunder.
- (2) This warranty extends only to the first purchaser for application, and is not transferable to any person or entity which purchased from such purchaser for application.

## 3. DISCLAIMERS

- (1) Panasonic Industrial Devices SUNX's sole obligation and liability under this warranty is limited to the repair or replacement, or refund of the purchase price, of a defective Product, at Panasonic Industrial Devices SUNX's option.
- (2) THE REPAIR, REPLACEMENT, OR REFUND IS THE EXCLUSIVE REMEDY OF THE PURCHASER, AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE HEREBY EXPRESSLY DISCLAIMED. IN NO EVENT SHALL PANASONIC INDUSTRIAL DEVICES SUNX AND ITS AFFILIATED ENTITIES BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCTS, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, GENERAL TERMS AND CONDITIONS 4 OR ANY DAMAGES RESULTING FROM LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF INFORMATION, LOSS OR INACCURACY OF DATA, LOSS OF PROFITS, LOSS OF SAVINGS, THE COST OF PROCUREMENT OF SUBSTITUTED GOODS, SERVICES OR TECHNOLOGIES, OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS.

## 4. CAUTIONS FOR SAFE USE

- (1) The applications shown in the catalogue are only suggestions, and it is Purchaser's sole responsibility to ascertain the fitness and suitability of the Products for any particular application, as well as to abide by Purchaser's applicable local laws and regulations, if any.
- (2) Never use the Products NOT rated or designated as "SAFETY SENSOR" in any application involving risk to life or property. When such a use is made by Purchaser, such Purchaser shall indemnify and hold harmless Panasonic Industrial Devices SUNX from any liability or damage whatsoever arising out of or in relation to such use.
- (3) In incorporating the Products to any equipment, facilities or systems, it is highly recommended to employ fail-safe designs, including but not limited to a redundant +++design, flame propagation prevention design, and malfunction prevention design so as not to cause any risk of bodily injury, fire accident, or social damage due to any failure of such equipment, facilities or systems.
- (4) The Products are each intended for use only in environments commonly found in manufacturing industry, and, unless expressly allowed in the catalogue, specification or otherwise, shall not be used in, or incorporated into, any equipment, facilities or systems, such as those:
  - (a) which are used for the protection of human life or body parts;
  - (b) which are used outdoors or in environments subject to any likelihood of chemical contamination or electromagnetic influence;
  - (c) which are likely to be used beyond the limits of operations or environments specified by Panasonic Industrial Devices SUNX in the catalogue or otherwise;
  - (d) which may cause risk to life or property, such as nuclear energy control equipment, transportation equipment (whether on rail or land, or in air or at sea), and medical equipment;
  - (e) which are operated continuously each day for 24 hours; and
  - (f) which otherwise require a high level of safety performance similar to that required in those equipment, facilities or systems as listed in (a) through (e) above.

## 5. EXPORT CONTROL LAWS

In some jurisdictions, the Products may be subject to local export laws and regulations. If any diversion or re-export is to be made, Purchaser is advised to abide by such local export laws and regulations, if any, at its own responsibility.

---

Please contact .....

## **Panasonic Corporation**

Panasonic Industrial Devices SUNX Co., Ltd.  
<https://panasonic.net/id/pidsx/global>

Please visit our website for inquiries and about our sales network.

© Panasonic Industrial Devices SUNX Co., Ltd. 2020  
September, 2020 PRINTED IN JAPAN WUME-SLINKV-9