

FP7 Communication Cassette (AFP7CCET1) Firmware Ver.1.03

Information you need to know before using the software (Essential reading)

About Firmware Ver.1.03

Communication Cassette (AFP7CCET1) Firmware Ver.1.03 is used to upgrade the communication cassette to Ver.1.03. To install this firmware, take the method below;

- Install this firmware to download free tool software '[Configurator WD IP address Search Tool](#)', and open [Firmware upgrade] in the [edit] of the tool bar.

Version-Up Information (Ver.1.02 to Ver.1.03) (August 29, 2016 update)

- There was a bug during general-purpose communication.

The communication will stop when transmitting and receiving the data happens at the same time.

This bug has been fixed.

Version-Up Information (Ver.1.00 to Ver.1.02) (November 14, 2014 update)

- Error of the TCP / IP timeout behavior has been corrected.
- When data with ET-LAN header has been received by the general-purpose communication, error where delete the ET-LAN header has been fixed.
- It has been fixed that the mode of the cassette is in initialization mode, in the OFF state for the switch1 (initialization mode switch).

Caution

Be aware of the following points listed below.

This software is freeware. The copyright for this software is held by Panasonic Industrial Devices SUNX Co., Ltd. By using this software it is assumed that you agree to "Conditions of Use" presented below.

Conditions of Use

- Panasonic Industrial Devices SUNX does not warrant anything regarding the use of this software.
- Panasonic Industrial Devices SUNX will not assume responsibility of any sort for direct, indirect, repercussive, resulting or special damage that results from using this software or from the operation of the software itself.
- Panasonic Industrial Devices SUNX does not restrict the use, copying or distribution of this software.

However, when copying or distributing, Panasonic Industrial Devices SUNX prohibits the procurement of fees other than the cost of media, and prohibits the applying of restrictions in use of the software.

System Requirements

Make sure that the computer on which you intend to run the software meets the minimum specifications listed below.

OS	Windows 2000 / XP / Vista / 7
Available hard disk space	More than 2 MB
Recommended CPU	Pentium 100 MHz or better
Recommended system RAM	More than 32 MB (depends on OS)
Recommended display resolution	800 * 600 or more
Recommended color depth	High color (16 bits) or better